

HYDRAULIC EXCAVATOR

**SHOP
MANUAL**

model

SK09SR

INDEX

1	SPECIFICATIONS
2	MAINTENANCE
3	SYSTEM
4	DISASSEMBLING
5	TROUBLESHOOTING
6	ENGINE
7	INSTALLATION PROCEDURES ATTACHMENTS

PDF



DOWNLOAD



SPECIFICATIONS

MAINTENANCE

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

E/G

OPT

KOBELCO

Book Code No. **S5PA0001E** ②

00-0-1 ②

This page is blank because of editing convenience.



INDEX

SK09SR

Book Code No. Issed Year-Month				Title	Index No.
S5PA0101E 2000-4	S5PA0101E ① 2001-7		SPECIFICATIONS	PRELIMINARY REMARKS	PA01
S5PA0201E 2000-4	S5PA0201E ① 2001-7	S5PA0201E ② 2003-2		SPECIFICATIONS	PA02
S5PA0301E 2000-4	S5PA0301E ① 2001-7	S5PA0301E ② 2003-2		ATTACHMENT DIMENSIONS	PA03
S5PA1101E 2000-4	S5PA1101E ① 2001-7	S5PA1101E ② 2003-2	MAINTENANCE	TOOLS	PA11
S5PA1201E 2000-4				STANDARD MAINTENANCE TIME TABLE	PA12
S5PA1301E 2000-4	S5PA1301E ① 2001-7			MAINTENANCE STANDARDS AND TEST PROCEDURES	PA13
—					
S5PA2201E 2000-4	S5PA2201E ① 2001-7	S5PA2201E ② 2003-2	SYSTEM	HYDRAULIC SYSTEM	PA22
S5PA2301E 2000-4	S5PA2301E ① 2001-7	S5PA2301E ② 2003-2		ELECTRICAL SYSTEM	PA23
S5PA2401E 2000-4	S5PA2401E ① 2001-7	S5PA2401E ② 2003-2		COMPONENTS SYSTEM	PA24
—					
—					
S5PA3101E 2000-4			DISASSEMBLING	WHOLE DISASSEMBLING & ASSEMBLING	PA31
S5PA3201E 2000-4	S5PA3201E ① 2001-7	S5PA3201E ② 2003-2		ATTACHMENTS	PA32
S5PA3301E 2000-4	S5PA3301E ① 2001-7	S5PA3301E ② 2003-2		UPPER SLEWING STRUCTURE	PA33
S5PA3401E 2000-4		S5PA3401E ① 2003-2		TRAVEL SYSTEM	PA34
—					
S5PA4201E 2000-4			TROUBLESHOOTING	HYDRAULIC SYSTEM	PA42
S5PA4301E 2000-4				ELECTRICAL SYSTEM	PA43
S5PA4401E 2000-4		S5PA4401E ① 2003-2		ENGINE	PA44
S5PA5101E 2000-4			E/G	ENGINE	PA51
			OPT		

SAFETY PRECAUTIONS

1.1 GENERAL SAFETY INFORMATION

 **WARNING** 

Do Not operate or perform any maintenance on this machine until all instructions found in the OPERATION & MAINTENANCE MANUAL have been thoroughly read and understood. Improper operation or maintenance of this machine may cause accidents and could result in serious injury or death. Always keep the manual in the operator's seat pocket. If it is missing or damaged, place an order with an authorized KOBELCO Distributor for a replacement. If you have any questions, please consult an authorized KOBELCO Distributor.

1. Most accidents, which occur during operation, are due to neglect of precautionary measures and safety rules. Sufficient care should be taken to avoid these accidents. Erroneous operation, lubrication or maintenance services are very dangerous and may cause injury or death of personnel. Therefore all precautionary measures, NOTES, DANGERS, WARNINGS and CAUTIONS contained in the manual and on the machine should be read and understood by all personnel before starting any work with or on the machine.
2. Operation, inspection, and maintenance should be carefully carried out, and safety must be given the first priority. Messages of safety are indicated with marks. The safety information contained in the manual is intended only to supplement safety codes, insurance requirements, local laws, rules and regulations.
3. Messages of safety appear in the manual and on the machine : All messages of safety are identified by eighter word of "DANGER", "WARNING" and "CAUTION".
 - a. **DANGER-** Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury and is represented as follows:

 **DANGER** 

- b. **WARNING-** Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury and is represented as follows:



 **WARNING** 

- c. **CAUTION-** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against possible damage to the machine and its components and is represented as follows:

 **CAUTION** 

4. It is very difficult to forecast every danger that may occur during operation. However, safety can be ensured by fully understanding proper operating procedures for this machine according to methods recommended by KOBELCO.
5. While operating the machine, be sure to perform work with great care, so as not to damage the machine, or allow accidents to occur.
6. Continue studying the manual until all Safety, Operation and Maintenance procedures are completely understood by all persons working with the machine.

1.2 SAFETY PRECAUTIONS

 **WARNING** 

The proper and safe lubrication and maintenance for this machine, recommended by KOBELCO, are outlined in the OPERATOR'S MANUAL for the machine. Improper performance of lubrication or maintenance procedures are dangerous and could result in injury or death. Read and understand the MANUAL before performing any lubrication or maintenance.


The serviceman or mechanic may be unfamiliar with many of the systems on this machine. This makes it important to use caution when performing service work. A knowledge of the system and or components is important before the removal or disassembly of any component.

Because of the size of some of the machine components, the serviceman or mechanic should check the weights noted in this manual. Use proper lifting procedures when removing any components. Weight of components table is shown in the section ; SPECIFICATIONS.

SAFETY PRECAUTIONS

The following is a list of basic precautions that must always be observed.

1. Read and understand all Warning plates and decal on the machine before Operating, Maintaining or Repairing this machine.
2. Always wear protective glasses and protective shoes when working around machines. In particular, wear protective glasses when using hammers, punches or drifts on any part of the machine or attachments. Use welders gloves, hood/goggles, apron and the protective clothing appropriate to the welding job being performed. Do not wear loose fitting or torn clothing. Remove all rings from fingers, loose jewelry, confine long hair and loose clothing before working on this machinery.
3. Disconnect the battery and hang a "Do Not Operate" tag in the Operators Compartment. Remove ignition keys.
4. If possible, make all repairs with the machine parked on a level, hard surface. Block the machine so it does not roll while working on or under the machine. Hang a "Do Not Operate" tag in the Operators Compartment.
5. Do not work on any machine that is supported only by lift, jacks or a hoist. Always use blocks or jack stands, capable of supporting the machine, before performing any disassembly.
6. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Always make sure all raised components are blocked correctly and be alert for possible pressure when disconnecting any device from a system that utilizes pressure.
7. Lower the bucket, dozer, or other attachments to the ground before performing any work on the machine. If this cannot be done, make sure the bucket, dozer, ripper or other attachment is blocked correctly to prevent it from dropping unexpectedly.
8. Use steps and grab handles when mounting or dismounting a machine. Clean any mud or debris from steps, walkways or work platforms before using. Always face to the machine when using steps, ladders and walkways. When it is not possible to use the designed access system, provide ladders, scaffolds, or work platforms to perform safe repair operations.
9. To avoid back injury, use a hoist when lifting components which weigh 20kg (45lbs) or more. Make sure all chains, hooks, slings, etc., are in good condition and are the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
10. To avoid burns, be alert for hot parts on machines which have just been stopped and hot fluids in lines, tubes and compartments.
11. Be careful when removing cover plates. Gradually back off the last two capscrews or nuts located at opposite ends of the cover or device and carefully pry cover loose to relieve any spring or other pressure, before removing the last two capscrews or nuts completely.
12. Be careful when removing filler caps, breathers and plugs on the machine. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the machine has just been stopped because fluids can be hot.
13. Always use the proper tools that are in good condition and that are suited for the job at hand. Be sure you understand how to use them before performing any service work.
14. Reinstall all fasteners with the same part number. Do not use a lesser quality fastener if replacements are necessary.
15. Repairs which require welding should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of the parent metal. Make sure to disconnect battery before any welding procedures are attempted.





Thank you very much
for your reading.
Please click here
to get more information.