

# 290GLC Excavator Repair

## REPAIR TECHNICAL MANUAL

**290GLC (PIN: 1FF290GX\_\_E705001-; 1FF290GX\_\_D705001- ;1FF290GX\_\_  
\_C705001-)**

**TM12178 01NOV15 (ENGLISH)**

For complete service information also see:

290GLC Excavator Diagnostic	TM12172
JDLink (MTG) Technical Manual	TM114519
PowerTech Plus 4.5L and 6.8L Diesel Engines Level 14 Electronic Fuel System With Denso HPCR	CTM320
Super Caddy Oil Cleanup Procedure	CTM310
6068 PowerTech OEM Diesel Engines Above 130kW (174 hp) (Interim 4/Stage III B platform)	CTM104
PowerTech 4.5L & 6.8L Diesel Engine Tier 1/Stage I, Tier 2/Stage II, Tier 3/Stage IIIA, Tier 3/Stage IIA Tier 3/Stage III, (Base Engine)	CTM1006
JDLINK/ZXLINK Machine Monitoring System	CTM10006

**PDF**



**DOWNLOAD**



John Deere Construction and Forestry

## Table of contents

### **FOREWORD**

### **TECHNICAL INFORMATION FEEDBACK FORM**

#### **Section 00 - GENERAL INFORMATION**

Group 0001 - Safety

Group 0003 - Torque Values

#### **Section 0100 - TRACKS**

Group 0130 - Track System

#### **Section 02 - AXLES, DIFFERENTIALS AND SUSPENSION SYSTEMS**

Group 0250 - Axle Shaft, Bearings, and Reduction Gears

Group 0260 - Hydraulic System

#### **Section 0400 - ENGINE**

Group 0400 - Removal and Installation

#### **Section 0500 - ENGINE AUXILIARY SYSTEM**

Group 0510 - Cooling Systems

Group 0520 - Intake System

Group 0530 - External Exhaust System

Group 0560 - External Fuel Supply Systems

#### **Section 0700 - DAMPENER DRIVE (FLEX COUPLING)**

Group 0752 - Elements

#### **Section 1700 - FRAME OR SUPPORTING STRUCTURE**

Group 1740 - Frame Installation

Group 1749 - Chassis Weights

#### **Section 1800 - OPERATOR'S STATION**

Group 1800 - Removal and Installation

Group 1810 - Operator Enclosure

Group 1821 - Seat and Seat Belt

Group 1830 - Heating and Air Conditioning

#### **Section 3300 - EXCAVATOR**

Group 3302 - Buckets

Group 3340 - Frames

Group 3360 - Hydraulic System

#### **Section 4300 - SWING OR PIVOTING SYSTEM**

Group 4350 - Mechanical Drive Elements

Group 4360 - Hydraulic System

#### **Section 9900 - DEALER FABRICATED TOOLS**

Group 9900 - Dealer Fabricated Tools



## Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

**CAUTION:**

---

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.



Thank you very much  
for your reading.  
Please click here  
to get more information.