WORKSHOP MANUAL TRACTOR

M100GX,M110GX,M126GX,M128GX,M128GX,M128GX,M128GX-FS,M13PPF DOWNLOAD -FS

Kubota

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the M100GX, M110GX, M126GX, M128GX, M128GX-FS, M135GX and M135GX-FS. It contains 4 parts: "Information", "General", "Mechanism" and "Servicing".

Information

This section primarily contains information below.

- Safety First
- · Safety Decal
- · Specification
- · Dimension

■ General

This section primarily contains information below.

- · Engine Identification
- · Model Identification
- · General Precautions
- · Maintenance Check List
- Check and Maintenance
- · Special Tools

■ Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y021-01870 / 9Y021-18200) for the diesel engine / tractor mechanism that this workshop manual does not include.

Servicing

This section primarily contains information below.

- Troubleshooting
- Servicing Specifications
- · Tightening Torques
- · Checking, Disassembling and Servicing

Regarding the servicing of Common Rail System (CRS), refer to "DIAGNOSIS MANUAL" (9Y120-01920, 9Y120-01860).

Regarding the servicing of Diesel Particulate Filter (DPF), refer to "DIESEL PARTICULATE FILTER HANDLING MANUAL" (9Y121-08130).

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes many models, information or illustrations and photographs can show more than one model.

August, 2012

© KUBOTA Corporation 2012

Record of Revisions

For pdf, use search function {Search word} to find all the revised locations.

Last digit of the Code No.	Issue month	Main Revised Point and Corrective Measures (Search word)	Reference Page
2	2014.07	Correct specifications Adding the informations (DPF regeneration system of Default)	I-21, I-22, I-26 1-M42
		Version) • Adding the information (When reassembling)	2-S47, 7-S17
		 Correcting the tightening torque Correcting tightening torque Correcting tightening torque Correcting the flow rate 	2-S50 3-S3 3-S5 7-S3, 7-S6, 7-S8, 7-S10
		Correcting the relief pressure	7-S4, 7-S10
		 Correcting the clearance Correcting errors of DTC (Diagnostic Trouble Code) 	7-S26 8-S12, 8-S16
		 Adding the informations Correcting errors 	8-S17 8-S100, 8-S101, 8-S102, 8-S103, 8-S104
		Adding Tightening torque	9-S8, 9-S55
3	2015.03	 Changing the title from "M100GX, M110GX, M126GX, M135GX, M135GX-FS" to "M100GX, M110GX, M126GX, M128GX, M128GX-FS, M135GX, M135GX-FS" Adding M100GX, M128GX, M128GX-FS for Europe Adding the maintenance for Europe 	-
4	2015.07	Balancer shaft bearing replacing tool changed.	G-122, G-124, G-125, G-126, 1-S145
5	2015.11	Wrong Correction The topic "Adjusting Air Conditioner Belt Tension [M100GX, M110GX]" was moved to [4] CHECK POINTS OF EVERY 100 HOURS from [5] CHECK POINTS OF EVERY 200 HOURS	G-31
		Wrong Correction Rated pressure for hydraulic flow test was corrected.	7-S3, 7-S4, 7-S6, 7-S8
		Wrong Correction Engine speed as a condition for checking relief valve setting pressure was corrected.	7-S4, 7-S10

Last digit of the Code No.	Issue month	Main Revised Point and Corrective Measures {Search word}	Reference Page
5	2015.11	Wrong Correction Additional line was drawn in the electric circuit because a wiring between battery and starter was missed in the previouse circuit. Reference page: The diagram at the end of the book.	8-M1, 8-M2, 8-M3, 8-M4, 8-M28, 8-M33
		Wrong Correction Correct: Black/White wiring connects to terminal 5 of main key switch. Reference page: The diagram at the end of the book.	8-M1, 8-M2, 8-M3, 8-M4, 8-S93, 8-S94
		Wrong Correction Terminal no. of hand throttle lever sensor was corrected. Reference page: The diagram at the end of the book.	8-M10
		Wrong Correction Wiring color between shuttle rotation sensor and main ECU was corrected. Reference page: The diagram at the end of the book.	8-M10
		Wrong Correction Electric circuit for front wiper motor was corrected. Reference page: The diagram at the end of the book.	8-M11
		Wrong Correction Correct: (7) Glow Relay, (8) Starter Relay	8-M19
		Wrong Correction Correct: (1) Turn Signal Relay LH, (4) Turn Signal Relay Relay RH	8-M26
		Wrong Correction E-R30 Unload Solenoid> E-H30 Unload Solenoid	8-S12
		Wrong Correction "Fail safe control or symptom caused by error" for the item ""N" blinks at range shift display (2)" was corrected	8-S17
		Wrong Correction Item no. 64 is "Suspension pressure sensor". Item no. 65 is "Suspension stroke sensor".	8-\$69
		Topic "Sensor Resistance" was added.	8-S108
		Wrong Correction Correct: Voltage across the terminal 1 - chassis is approx. battery voltage.	8-S112
		Topic "Temperature Sensor (Build in Air Flow Sensor) Resistance" was added.	8-S115
		Wrong Correction Correct: Wiring color for terminal 1 is Blue/Yellow	8-S122
		Wrong Correction Correct: Terminals to measure the hand throttle lever sensor resistance are terminal 2.3 and terminal 2.4.	9 6400
		terminal 2-3 and terminal 2-4	8-S122



Thank you very much for your reading.

Please click here to get more information.