

200 and 900 Series Cutting Platforms
40 and 90 Series Corn Heads
50 and 50A Series Row Crop Heads

John Deere Harvester Works
TM1581 (03OCT94)

LITHO IN U.S.A.
ENGLISH

Cutting Platforms, Corn Heads and Row Crop Heads

TM1581 (03OCT94)

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90


10
05
1
-UN-23AUG88
TS227

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-UN-23AUG88
TS291

10
05
2


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.




X9811 -JUN-23AUG88

DX,FLUID -19-03MAR93

PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.




TS230 -JUN-24MAY88

DX,PARK -19-04JUN90

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



DX,LOWER -19-04JUN90


TS229 -UN-23AUG88

10
05

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




DX,LOOSE -19-04JUN90

TS228 -UN-23AUG88

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



DX,AIR -19-04JUN90

TS220 -UN-23AUG88

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX,LIGHT -19-04JUN90

TS223 -UN-23AUG88

PROTECT AGAINST NOISE

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.




DX,NOISE -19-03MAR93

TS207 -UN-23AUG88

WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.



DX,CLEAN -19-04JUN90

T6642EJ -UN-18OCT88

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



DX,REPAIR -19-04JUN90

10
575
-UN-08NOV69
TS779

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



DX,DRAIN -19-03MAR93

-UN-26NOV90
TS1133

LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



DX,LIVE -19-25SEP92


TS231 -19-07OCT88

10
05
6

SERIAL NUMBER

The serial number is on a plate located on the top left-hand end of the cutting platform.

When ordering parts, always bring the serial number from the serial number plate. This will help your John Deere dealer in giving you fast service.



TM1581,10A -19-03OCT94

10
10

H42762
-UN-09NOV90

The serial number is on a plate located on the right-hand end of the row-crop head.

Record your row-crop head serial number in the space provided on the illustration. Provide this serial number to your dealer when ordering parts.



TM1581,10B -19-03OCT94

H42466
-UN-12JAN91

The serial number is on a plate located on the right-hand end of the corn head.

Record your corn head serial number in the space above. Give this serial number to your dealer when ordering parts.



TM1581,10C -19-03OCT94

H42848
-UN-29NOV90

Identification/Serial Number

10
10
2

200 SERIES PLATFORMS

Specifications given in this manual are intended for service ONLY and do not include normal factory manufacturing tolerances.

(Specifications and design subject to change without notice)

Rigid Cutterbar Platform Model	Cutting Width	Combine Model
213	3 812 mm (12 ft. 6 in.)	4420, 4425, 6600, 6620, 7700, 7720
215	4 422 mm (14 ft. 6 in.)	4420, 4425, 6600, 6620, 7700, 7720, 8820
216	4 727 mm (15 ft. 6 in.)	4420, 4425, 6600, 6620, SideHill, 6620, 7700, 7720, 8820
218	5 336 mm (17 ft. 6 in.)	4420, 4425, 6600, 6620, 7700, 7720, 8820
220	5 846 mm (19 ft. 6 in.)	4420, 6600, 6620, 7700, 7720, 8820
222	6 556 mm (21 ft. 6 in.)	6600, 6620, 7700, 7720, 8820
224	7 165 mm (23 ft. 6 in.)	6600, 6620, 7700, 7720, 8820
230	8 994 mm (29 ft. 6 in.)	7700, 7720, 8820
Flex Cutterbar Platform Model		
213	3 812 mm (12 ft. 6 in.)	4420, 4425, 6600, 6620, 7700, 7720
215	4 422 mm (14 ft. 6 in.)	4420, 4425, 6620, SideHill, 6620, 7720, 8820
216	4 727 mm (15 ft. 6 in.)	4420, 4425, 6620, SideHill, 6620, 7720, 8820
218	5 336 mm (17 ft. 6 in.)	4420, 4425, 6620, 7720, 8820
220	5 846 mm (19 ft. 6 in.)	4420, 6620, 7720, 8820
222	6 556 mm (21 ft. 6 in.)	6620, 7720, 8820
224	7 165 mm (23 ft. 6 in.)	6620, 7720, 8820

NOTE: Conversion parts are available to convert 213, 215, 216, 220 and 222 Model platforms for use with the SideHill 6600 and 6620 Combines. The 215 flex and 216 flex and rigid platforms are also available with factory installed parts as noted above.

Specifications

900 SERIES PLATFORMS

Specifications given in this manual are intended for service only and do not include normal factory manufacturing tolerances.

Rigid Cutterbar			
Platform Model	Cutting Width	Gathering Width	Combine Model
918	5334 mm (17 ft. 6 in.)	5.5 m (18 ft.)	4435, 6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
920 and 920 Rice	5944 mm (19 ft. 6 in.)	6.1 m (20 ft.)	6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
922 and 922 Rice	6556 mm (21 ft. 6 in.)	6.7 m (22 ft.)	6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
925 and 925 Rice	7620 mm (25 ft.)	7.8 m (25 ft. 6 in.)	6620, 7720, 7722, 8820, 9400, 9500, 9600, SideHill 9500, CTS
930 and 930 Rice	8992 mm (29 ft. 6 in.)	9.1 m (30 ft.)	7720, 8820, 9500, 9600, SideHill 9500, CTS
Flex Cutterbar			
Platform Model	Cutting Width	Gathering Width	Combine Model
913	3810 mm (12 ft. 6 in.)	3.8 m (12 ft. 5 in.)	4435, 6620, 7720, 9400, 9500, 9600, SideHill 9500, CTS
915	4572 mm (15 ft.)	4.5 m (14 ft. 11 in.)	4435, 6620 SideHill, 6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
918	5334 mm (17 ft. 6 in.)	5.3 m (17 ft. 5 in.)	4435, 6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
920	5944 mm (19 ft. 6 in.)	5.9 m (19 ft. 5 in.)	6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
922	6554 mm (21 ft. 6 in.)	6.6 m (21 ft. 5 in.)	6620, 7720, 8820, 9400, 9500, 9600 SideHill 9500, CTS
925	7620 mm (25 ft.)	7.6 m (24 ft. 11 in.)	6620, 7720, 8820, 9400, 9500, 9600, SideHill 9500, CTS
930	8992 mm (29 ft. 6 in.)	9.0 m (29 ft. 5 in.)	7720, 8820, 9500, 9600 SideHill 9500, CTS

(Specifications and design subject to change without notice.)

HX1581,1015.AC -19-03OCT94

10
15
3

Specifications

10
15
4

Cutterbar:

Type Enclosed wobble drive
Extension (rigid) 102 mm (4 in.) forward and 102 mm (4 in.) rearward 203 mm (8 in.) max.
Tilt range 9 degrees
Flexible cutterbar float range 90 mm (3-1/2 in.)
Cutterbar length 152 mm (6 in.) less than platform width, except for 915 and 925 models
Knife sections Heavy-duty, overserrated
Guards Forged steel, heat-treated

Knife Speed: (measured at sheave rpm)

539 cpm on Flexible Platforms
562 cpm on Rigid Platforms

Reel: (pickup)

Number of slats 6 (with DURA-FLO fingers)
Diameter 1067 mm (42 in.)

Reel: (slat)

Number of slats 5
Diameter 1016 mm (40 in.)

Reel Controls:

Height control Hydraulic
Speed control Hydraulic
Operating speeds (Pickup 5—44 rpm) (Slat 8—66 rpm)

Platform Auger:

Diameter 610 mm (24 in.)
Operating speed 169 rpm std. 135 rpm opt.

HX1581,1015,AD -19-03OCT94

Specifications

10
15
5

918 DRAPER PLATFORM

“Specifications given in this manual are intended for service only and do not include normal factory manufacturing tolerances.”

Combine Models 9500, 9600, 7720 and 8820

Platform Drive Shaft 521 rpm

Cutter Bar

Type Enclosed wobble drive

Cutterbar length 5.33 m (17.5 ft.)

Knife sections Chrome plated, heavy-duty, overserrated

Guards Forged steel heat-treated

Knife Speed (measured with 521 rpm backshaft speed) 491 cpm

Pickup Reel

Number of slats 6 (with spring steel fingers)

Diameter 1320 mm (52 in.)

Reel Controls

Height control Hydraulic

Speed control Hydraulic

Operating speeds 3-30 rpm

Auger

Diameter 610 mm (24 in.)

Operating speed 169 rpm

Retractable auger fingers

Number of fingers 12

Diameter 16 mm (5/8 in.)

With break-a-way notch

Reach 152 mm (6 in.)

Torque required to seat new finger 70 N·m (50 lb-ft) (maximum)

Platform weight 1696 kg (3740 lb)

TM1581,HX15.C -19-03OCT94

Specifications

40 SERIES CORN HEAD

Specifications given in the manual are intended for service only and do not include normal factory manufacturing tolerances.

CORN HEAD MODEL	MACHINE MODEL	NUMBER OF ROWS	CORN HEAD MODEL	MACHINE MODEL	NUMBER OF ROWS
443	Forage Harvester	4	644	6620 Combine	6
	4420 Combine			7720 Combine	
	4425 Combine			8820 Combine	
	4435 Combine			9400 Combine	
	6620 Combine			9500 Combine	
444	Forage Harvester	4	645	6620 Combine	6
	4420 Combine			7720 Combine	
	4425 Combine			8820 Combine	
	6620 Combine			9400 Combine	
	SideHill 6620 Combine			9500 Combine	
	7720 Combine			9600 Combine	
	9400 Combine			CTS Combine	
	9500 Combine				
	SideHill 9500 Combine				
	546			6620 Combine	
SideHill 6620 Combine		8820 Combine			
7720 Combine		9500 Combine			
8820 Combine		9600 Combine			
9400 Combine		CTS Combine			
9500 Combine					
SideHill 9500 Combine					
9600 Combine					
CTS Combine					
643		6620 Combine	6	1243	8820 Combine
	SideHill 6620 Combine	9600 Combine			
	7720 Combine				
	8820 Combine				
	9400 Combine				
	9500 Combine				
	SideHill 9500 Combine				
	9600 Combine				
	CTS Combine				

TM1581,HX15,D -19-03OCT94

Specifications

Gatherer Points	Low profile floating type hinged above gatherer chains
Center and Outer Gatherer Sheets	hinged, quick-removable
Type of Gatherer Chains	Heavy-duty 555 endless steel roller chain (no master connecting link)
Minimum Clearance Between Gatherer Chains and Ground	32 mm (1-1/4 in.)
Row Unit Drive	Enclosed gear box with gears submerged in lubricant; driven by single input hex. shaft
Gatherer Chain Adjustment	Spring loaded- self-adjusting
Stalk Rolls	Spiral-pointed, flute-type (2 per row unit)
Deck Plate Adjustment	Bolt adjusted
Slip Clutch	One per row unit plus auger drive
Trash Knives	Full length one piece heat-treated steel

HX1581,1015,AE -19-03OCT94

10
15
7

Specifications

Approximate Overall Width for Storage—

443	3454 mm (11 ft. 4 in.)
444	3708 mm (13 ft. 6 in.)
546	4928 mm (16 ft. 2 in.)
643	4928 mm (16 ft. 2 in.)
644	5791 mm (19 ft.)
645	6096 mm (20 ft.)
843	6299 mm (20 ft. 8 in.)
844	7820 mm (25 ft. 8 in.)
1243	9347 mm (30 ft. 8 in.)

Approximate Overall Length for
Storage—All Corn

Heads	3048 mm (10 ft.)
-------	-------	------------------

Approximate Shipping Weight of
Corn Head—(Includes Shipping Skid)

443	1129 kg (2488 lb.)
444	1184 kg (2610 lb.)
546	1472 kg (3245 lb.)
643	1590 kg (3505 lb.)
644	1855 kg (4090 lb.)
645	1901 kg (4190 lb.)
843	2243 kg (4944 lb.)
844	2470 kg (5466 lb.)
1243	3332 kg (7340 lb.)

(Specifications and design subject to change without notice.)

HX1581,1015,AF -19-03OCT94

Specifications

90 SERIES CORN HEAD

Specifications given in the manual are intended for service only and do not include normal factory manufacturing tolerances.

CORN HEAD MODEL	MACHINE MODEL	NUMBER OF ROWS	CORN HEAD MODEL	MACHINE MODEL	NUMBER OF ROWS
493	Forage Harvester 4420 Combine 4425 Combine 4435 Combine 6620 Combine	4	694	6620 Combine 7720 Combine 8820 Combine 9400 Combine 9500 Combine 9600 Combine CTS Combine	6
494	Forage Harvester 4420 Combine 4425 Combine 6620 Combine SideHill 6620 Combine 7720 Combine 9400 Combine 9500 Combine SideHill 9500 Combine	4	893	7720 Combine 8820 Combine 9500 Combine 9600 Combine CTS Combine	8
			894	8820 Combine 9600 Combine CTS Combine	8
594	6620 Combine SideHill 6620 Combine 7720 Combine 8820 Combine 9400 Combine 9500 Combine SideHill 9500 Combine 9600 Combine CTS Combine	5	1293	8820 Combine 9600 Combine	12
693	6620 Combine 7720 Combine 8820 Combine 9400 Combine 9500 Combine 9600 Combine CTS Combine	6			
693 SH	SideHill 6620 Combine SideHill 9500 Combine	6			

TM1581,HX15,E -19-03OCT94

Specifications

10
15
10

Gatherer Points	Low profile floating type hinged above gatherer chains
Center and Outer Gatherers	hinged, quick-removable
Type of Gatherer Chains	Heavy-duty 555 endless steel roller chain with chromed pins (no master connecting link)
Minimum Clearance Between Gatherer Chains and Ground	32 mm (1-1/4-in.)
Row Unit Drive	Enclosed gear box with gears submerged in lubricant; driven by single input hex. shaft
Gatherer Chain Adjustment	Spring-loaded self-adjusting
Stalk Rolls	Spiral-pointed, flute-type (2 per row unit)
Deck Plate Adjustment	Bolt adjusted (Optional) Hydraulic adjusted
Slip Clutch	One per row unit plus auger drive
Trash Knives	Full length one piece heat-treated steel

HX1581,1015,AG -19-03OCT94

Specifications

Approximate Overall Width for Storage—

493	3454 mm (11 ft. 4 in.)
494	3708 mm (13 ft. 6 in.)
594	4928 mm (16 ft. 2 in.)
693	4928 mm (16 ft. 2 in.)
693 SH	4928 mm (16 ft. 2 in.)
694	5791 mm (19 ft.)
695	6096 mm (20 ft.)
893	6299 mm (20 ft. 2 in.)
894	7820 mm (25 ft. 8 in.)
1293	9347 mm (30 ft. 8 in.)

Approximate Overall Length
for Storage—All Corn

Heads	3000 mm (9 ft. 10-in.)
Points folded up (service position)	2400 mm (7 ft. 11-in.)

Approximate Shipping Weight

of Corn Head—(Includes Shipping Skid)

493	1129 kg (2488 lb.)
494	1184 kg (2610 lb.)
594	1472 kg (3245 lb.)
693	1590 kg (3505 lb.)
693 SH	1590 kg (3505 lb.)
694	1855 kg (4090 lb.)
695	1901 kg (1855 lb.)
893	2243 kg (4944 lb.)
894	2470 kg (5466 lb.)
1293	3332 kg (7340 lb.)

(Specifications and design subject to change without notice.)

CRNHD,90SP,C -19-14SEP93

10
15
11

10
15
12

50 AND 50A SERIES ROW CROP

(Specifications and design subject to change without notice.)

Specifications given in this manual are intended for service only and do not include normal factory manufacturing tolerances.

ROW-CROP HEAD MODEL	COMBINE MODEL	NUMBER OF ROWS
454 and 454A	4420, 4425, 4435, 6620, SideHill 6620, 7720, 7721 9400, 9500	4
653 and 653A	4420, 6220, SideHill 6620, 7720, 8820, 9400, 9500, 9600	6
654 and 654A	6620, 7720, 8820 9400, 9500, 9600	6
655 and 655A	7720, 8820, 9500, 9600	6
853 and 853A	7720, 8820, 9500, 9600	8

Auger

(Retractable Finger Feeding)

Diameter	24 in. (610 mm)
Speed	100 to 165 rpm
Torque to seat fingers	20 lb-ft (27 N·m)

Crop Gatherer

Type	Belted chains
Gatherer belt speed	215 to 352 rpm
Drive	Chain
Gatherer points	Adjustable and floating
Row unit sheets	Swing-out

Rotary Knives

Type	Rotary 6 blade with adjustable shear
Speed	202 to 331 rpm
Cuts per minute	1212 to 1986
Blade material	High-carbon steel, heat treated cutting edge

Stationary Knives

Type	Fixed
Knife material	Heat-treated cutting edge

Skid Shoes

Type	Self-aligning, adjustable to three positions
Float range	6 in. (152 mm)

Specifications

Approximate Overall Width

454 and 454A	4 m	(13 ft.)
653 and 653A	4.7 m	(15 ft. 6 in.)
654 and 654A	6.3 m	(20 ft. 8 in.)
655 and 655A	6.4 m	(21 ft.)
853 and 853A	6.5 m	(21 ft. 2 in.)

Approximate Overall Length

(All row-crop heads) 3.3 m (11 ft.)

Approximate Shipping Weight












454 and 454A	1 220 kg (2880 lbs.)
653 and 653A	1 530 kg (3570 lbs.)
654 and 654A	1 905 kg (4420 lbs.)
655 and 655A	2 063 kg (4550 lbs.)
853 and 853A	2 155 kg (5000 lbs.)

(Specifications and design subject to change without notice.)

HX1581,1015,AI -19-03OCT94

10
15
13

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

SAE Grade and Head Markings	1 or 2 ^b	5	5.1	5.2	8	8.2
	NO MARK 					
SAE Grade and Nut Markings	2	5		8		
	NO MARK 					

TS1162 -19-04MAR91

Size	Grade 1				Grade 2 ^b				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	240	175	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	400	300	510	375	400	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.


Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

METRIC BOLT AND CAP SCREW TORQUE VALUES



Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	255	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

Specifications

10
15
16

Group 05

200 and 900 Series Cutting Platforms

TORQUE VALUES

	Torque N·m (Lb-Ft.)
Auger finger crank cap screws	70 N·m (50)
Auger fingers in plastic bearings	16 N·m (12)
Slip Clutch nuts	70 N·m (50)
Knife head holder slotted nut	160 N·m (120)
Knife head holder cap screws	115 N·m (85)
Cutterbar drive case wobble shaft bearings (rolling torque)	0.34 to 0.56 N·m (3 to 5 lb-in.)
Cutterbar drive case cover cap screws	48 N·m (30)
Cutterbar drive case sheave lock nut	150 N·m (110)
Cutterbar drive case to mounting cap screws	270 N·m (200)
Cutterbar drive arm to yoke shaft slotted nut	270 N·m (200)
Cutterbar angle to drive case mounting round head bolts	45 N·m (35)
Left-hand stabilizer socket nut (flex platforms only)	135 N·m (100)

1581,10005,AAA -19-03OCT94

SPECIAL TOOLS

Number	Use
*JDC3 Fluted Driver	<p>To remove and install the special six-point 5/16 in. screws in the auger finger guides.</p> <p>NOTE: To use JDC3 driver with a 1/4 in. socket, a common 1/4 to 3/8 in. adapter is required for use with a 3/8 in. ratchet.</p>
*JDO1 Puller	To remove cutterbar drive arm.

H30649 -UN-23FEB89



H30649

JDC3 Fluted Driver

HX1581,10005,B -19-03OCT94

GENERAL INFORMATION

After the crop is cut by the cutterbar, the reel lays the material back into the floor of the platform. Flights on the platform auger move the material to the center of the platform. Retracting fingers in the auger feed the material to the feeder house conveyor chain.

The platform auger is chain driven from a sprocket on the right-hand side.

A slip clutch, located on the right-hand drive shaft, protects the auger from damage.


1401,10005.A -19-12SEP91

AUGER REMOVAL


1. Start engine, raise reel and lower platform to ground. Shut off engine and lower both reel lift safety stops (A).
2. Loosen adjusting screw (both sides) and slide reel to its extreme forward position on support arms (B). Tighten adjusting screws. Place a bolt in the front cross hole of each reel arm to prevent the reel from slipping off the arms.

CAUTION: The reel is heavy. Attach a suitable hoist or lift to it when positioning the lift cylinders.

3. Remove cotter pin and drilled pin (both sides) and raise reel to its highest position (C). Replace drilled pins and cotter pins. Remove hoist.
4. Loosen tightener, remove connecting link and remove chain (D).
5. Support auger with a wood block and remove nut, washer and sprocket (E).



H30654
-UN-05DEC91




H30655
-UN-05DEC91


TM1581,HX100,CA-19-18AUG94

200 and 900 Series Cutting Platforms/Auger Removal

6. Support auger with a wood block under flighting. Loosen set screw and remove locking collar (A).
7. Loosen, but do not remove, the three round head bolts in the bearing retainers (B).
8. Remove four round head bolts and pull plate, with eyebolts and bearing attached, off shaft (C).




9. Pull up on tightener and remove belt from sheaves (D).
10. Remove four round head bolts and remove sheave with support (E).



1401,10005,C -19-12SEP91


11. Remove four round head bolts and remove tightener assembly with spring and mounting plate (A).



12. Loosen clamping cap screw in auger support (B).

13. Support auger with a wood block under auger flighting. Remove two round head bolts and pull auger support from shaft (C).


14. Remove three round head bolts and remove plate with eyebolt (D).



HX,1401,1005,AA-19-16DEC92

15. Slide auger all the way to the right. Pull left-hand end of auger out and under reel. Continue to pull auger out of platform.

⚠ CAUTION: Pickup reel fingers are sharp. Be careful when working under reel.



1401,10005,E -19-12SEP91

INSPECTION AND REPAIR

Inspect all parts of the auger for damage or excessive wear. Replace parts as necessary.

See "Auger Shafts, Cranks and Fingers" for additional information concerning the platform auger.

1401,10005,B8 -19-12SEP91


AUGER SHAFTS, CRANKS AND FINGERS

Removal

The auger does not have to be removed from the platform to repair shafts, cranks and fingers.

To provide adequate working space in which to repair platform auger shafts, cranks and fingers:

1. Raise reel to its highest position.
2. Position reel to its extreme forward position. Place a bolt in the front cross hole of each reel arm to prevent the reel from slipping off the arms.

 **CAUTION: Always lower the safety stops when working under the reel.**

3. Use JDC3 fluted driver for removal of finger guide screws (2). See "Special Tools".


TM1581,HX100,B -19-03OCT94

REPAIR AND ASSEMBLY

When assembling parts in the auger, tighten parts to the following specifications:

Cap screws in cranks 70 N·m (7 kg) (50 lb-ft.)

1401,10005,B9 -19-12SEP91



H38636

- | | | | |
|--|-------------------------------|------------------------------|-----------------|
| 1—Screw | 6—Spring Pin | 11—Shaft Key, 3/16 x 3/4 in. | 16—Ball Bearing |
| 2—Guide Cap | 7A—Bearing (—Early) | 12—Crank | 17—Lock Nut |
| 3—Guide | 7B—Bearing (Late—) | 13—Set Screw, 1/4 x 1/4 in. | 18—Pin |
| 4A—Finger (—Early) | 8—Screw, 5/16 x 1-3/4 in. | 14—Locking Collar | 19—Shaft |
| 4B—Finger (Late—) | 9—Shaft | 15—Bearing Flange | |
| 5—Washer, 11/32 x 3/4 x 0.075 in. (42635-535210) | 10—Cap Screw, 3/8 x 2-1/4 in. | | |

1. The auger does not have to be removed to repair shafts, cranks and fingers.


2. Use JDC3 fluted driver for removal of finger guide screws (1). See "Special Tools".

3. When assembling parts in the auger, tighten parts to the following specifications:

- | | |
|-----------------------------------|--------------------|
| Cap Screws (10) in cranks (12) | 70 N·m (50 lb-ft.) |
| Auger fingers in plastic bearings | 16 N·m (12 lb-ft.) |

1581,10005,AAC -19-03OCT94

AUGER DRIVE



- | | | | |
|-------------------------------------|--|---|--|
| 1—Drive Shaft | 11—Ball Bearing | 20—Washer, 25/32 x 1-5/8 x 0.180 In. | 28—Spring |
| 2—Drive Shaft Shield | 12—Washer, 1-9/32 x 1-11/16 x 0.060 In. | 21—Nut, 3/4 In. | 29—Spacer |
| 3—Support (220, 222 and 224 Models) | 13—Round Head Bolt, 1/2 x 2-3/4 In. | 22—Support Bracket (213, 215, 216 and 218 Models) | 30—Slip Clutch Retainer |
| 4—Set Screw (2 Used) | 14—Washer, 17/32 x 1-1/16 x 0.090 In. (3 Used) | 23—Angle Support | 31—Slip Clutch Jaw (2 Used) |
| 5—Locking Collar (2 Used) | 15—Spacer (2 Used) | 24—Snap Ring | 32—Slip Clutch Collar |
| 6—Round Head Bolt, 3/8 x 3/4 In. | 16—Tightener Sprocket | 25—Slip Clutch Shield | 33—Thrust Washer |
| 7—Bearing Flange (4 Used) | 17—Chain | 26—Nut, 3/8 In. (8 Used) | 34—Slip Clutch Driver |
| 8—Ball Bearing | 18—Drive Sprockets | 27—Washer, 17/32 x 1-1/4 x 0.180 In. (4 Used) | 35—Round Head Bolt, 3/8 x 4-1/4 In. (4 Used) |
| 9—Drive Shaft Shield | 19—Woodruff Key, 1/4 x 7/8 In. (2 Used) | | 36—Washer |
| 10—Snap Ring | | | 37—Nut, 3/4 In. |


Exploded View of Cross Auger Drive

TM1581,HX100,C -19-03OCT94

100
05
8

H29730 -JUN-26SEP91

SIDEHILL AUGER DRIVES



- | | | | |
|--|--|---------------------------------------|----------------------------|
| 1—Round Head Bolt, 3/8 x 4-1/4 In. (4 Used) | 10—Bushing (2 Used) | 19—Washer, 17/32 x 1-1/16 x 0.090 In. | 26—Nut, 3/4 In. |
| 2—Drive Shaft | 11—Drive Shaft | 20—Spacer | 27—Snap Ring |
| 3—Washer (2 Used) | 12—Round Head Bolt, 3/8 x 3/4 In. (12 Used) | 21—Tightener Sprocket | 28—Slip Clutch Shield |
| 4—Slip Clutch Jaws (2 Used) | 13—Bearing Flange (2 Used) | 22—Chain | 29—Drive Shaft Shield |
| 5—Slip Clutch Retainer | 14—Ball Bearing | 23—Drive Sprocket | 30—Bearing Flange (2 Used) |
| 6—Spacer (2 Used) | 15—Set Screw | 24—Woodruff Key, 1/4 x 7/8 In. | 31—Ball Bearing |
| 7—Spring | 16—Locking Collar | 25—Washer, 25/32 x 1-5/8 x 0.180 In. | 32—Support Angle |
| 8—Washer, 17/32 x 1-1/4 x 0.180 In. (4 Used) | 17—Washer, 1-9/32 x 1-11/16 x 0.060 In. (3 Used) | | 33—Bracket |
| 9—Nut, 3/8 In. (8 Used) | 18—Round Head Bolt, 1/2 x 2 In. | | 34—Shield |

TM1581,HX100,D -19-03OCT94


AUGER DRIVE SLIP CLUTCH

The auger is protected by a slip clutch located next to the quick-coupler on the right-hand drive shaft.

Operate the platform with all four springs in the slip clutch.

When installing the slip clutch springs, the two nuts used to compress the spring must be tight against the spacer and are jammed together. Tighten nuts to 70 N·m (7 kg) (50 lb-ft) torque. Thrust washer surfaces should be periodically greased.

IMPORTANT: Check retaining nuts on slip clutch in severe crop conditions. Frequent slipping of the slip clutch jaws will tend to loosen these nuts.



H38997 -UN-13OCT88

TM1581,HX100,E -19-03OCT94

GUARDS AND KNIVES

General Information

The knife is basically a multiple series of shears. To cut properly, the knife must run smoothly in the cutterbar and every knife section must rest on the guard in position to make a shear cut. This means the guards, wearing plate and knife clips must be in good condition and set correctly. If these parts are loose or worn, the knife will chew and tear the crop instead of cutting it.



1401,10005,K -19-12SEP91

HYDRAULIC CYLINDER SAFETY STOP

! CAUTION: Engine must be off and key removed.

! CAUTION: Cracking of hydraulic line fittings to lower feeder house results in an immediate dropping of feeder house and header.


Hold handle (A) and release safety stop by removing spring locking pin (B). Lift stop off of latch and lower it down onto cylinder. Insert spring locking pin in handle.



HX,1401,10005AA-19-03OCT94

REMOVAL AND INSTALLATION OF GUARDS AND KNIVES

1. Loosen cap screws (A), remove cotter pin (D) and loosen slotted nut (E).
2. Strike a blow in from the front while prying up on adjusting block (B) until it breaks free.
3. Remove two cap screws (A) securing the adjusting block (B) to arm (C), then remove knife.
4. If a new knife is to be installed, remove adjusting block (B) from old knife by removing slotted nut (E).
5. To install knife, replace but do not tighten cap screws (A). Torque slotted nut (E) to 230 N·m (170 lb-ft).



- A—Cap Screws
- B—Adjusting Block
- C—Drive Arm
- D—Cotter Pin
- E—Slotted Nut

TM1581,HX100,F -19-03OCT94



100
05
12

H38583 -UN-13OCT88

KNIFE DRIVE ARM CLAMP ADJUSTMENT

If the drive arm clamp is incorrectly adjusted, the outer left-hand knife half section will rub on the upper or lower lip of the left-hand outer guard. Adjust this clamp as follows:

1. Loosen cap screws (A) and slide knife head up or down until outer left-hand section rests lightly on the outer left-hand guard upper lip without binding, as shown at the arrow. Tighten cap screws (A) to 115 N·m (85 lb-ft.).
2. If binding cannot be eliminated by this adjustment, replace the arc-welded knife drive case mounting frame.




TM1581, HX100, G -19-03OCT94

SETTING KNIFE REGISTER

The knife is registered at the factory and does NOT need to be registered unless drive arm (A) is removed from yoke shaft (B).

With yoke shaft (B) at maximum clockwise rotation (C), the first full knife section must be centered (D) on the inner prong of the first knife guard.

- A—Drive Arm
- B—Yoke Shaft
- C—Maximum Clockwise Rotation
- D—Knife Section



H38585

TM1581, HX100, H -19-03OCT94

H38585
-UN-26AUG91

GUARD ALIGNMENT


1. Cutterbar must be straight before aligning guards.

CAUTION: Always lower both reel cylinder stops when working under the reel.

2. Use a hammer and tap end of guard up or down to get a shear cut between section and guard. Tighten bolt as each guard is aligned.

NOTE: Guard lip must be parallel with shear edge of guard. Note location of knife as indicated by arrow.


3. If replacing guards, align new guards to insure a shear cut.



H26595

Setting Guard Down

H26595
-UN-05DEC91



H26596

Setting Guard Up

H26596
-UN-05DEC91

TM1581, HX100, I -19-03OCT94



ADJUSTING HOLD DOWN CLIPS

CAUTION: Always lower reel lift safety stops when working under reel.


Knife hold down clips (A) must keep sections from lifting off guards (E) and permit knife (C) to slide without binding.

1. Set clips (A) after guards (E) are aligned.
2. Tap clips (A) up or down until knife (C) will slide under clips without binding.
3. After setting clips (A), see that knife (C) works freely.

A—Knife Hold-Down Clip
B—Wearing Plate
C—Knife
D—Round Head Bolt and Nut
E—Knife Guard



Adjusting Clips Downward



Adjusting Clips Upward

TM1581,HX100,J -19-03OCT94

100-05-15
-UN-13OCT88
H38849

-UN-14DEC90
H42420

-UN-14DEC90
H42421


ADJUSTING WEARING PLATES

Wear plates (B) are located along entire length of knife back (E) and are adjustable for wear on knife back. Edges of wearing plates must line up with knife back along its entire length.

1. Hold knife (C) forward with fingers and adjust wearing plates forward in the slots and parallel against knife back except for the left-hand wear plate closest to the knife head which should be pushed rearward.

IMPORTANT: Do not drive with a hammer or pry up with a screwdriver.

2. After moving wearing plates (B) forward, or after replacing them, secure bolts (D) to 62 N·m (45 lb-ft).



- A—Hold Down Clip
- B—Wear Plate
- C—Knife
- D—Bolt
- E—Knife Back

TM1581,HX100,K -19-03OCT94

KNIFE SECTION SERVICE KIT


A service kit is available from your John Deere dealer to replace the sections in 1.8 m (6 ft.) of cutterbar at one time.

This kit contains all of the necessary hardware, sections and instructions.

900CP,SE,H -19-24JAN91


REPLACING KNIFE SECTIONS

1. Remove guards if needed.
2. Remove nuts (A) on section.
3. Tap or pry up section (B) and discard.



TM1581,HX100,L -19-03OCT94

4. Drive out any damaged bolts (A) with punch.
5. Replace bolts (A), if needed, by driving in from below with a hammer (B). Do not use nut to draw bolt up. Bolt must be driven in flush to knife back (C).
6. Install new section. Torque nuts to 12 N·m (9 lb-ft). Nuts must have taper going down into section.
7. Install guard if needed.



H38854

1581,10005,ZA -19-03OCT94

H38854 -UN-13OCT88


100
05
17

ADJUSTING NON-CLOG CUTTERBAR GUARDS (ATTACHMENT)

1. Tap clips (A) up or down until knife (C) will slide under clips without binding.
2. After setting clips (A), be certain knife (C) works freely.

NOTE: (Flex platforms only) Remove outer clip on outer right-hand skid show when installing non-clog guards.


- A—Knife Hold Down Clip
- B—Wearing Plate
- C—Knife
- D—Round Head Bolt
- E—Knife Guard



H42423

-UN-14DEC90


H42423



H42420

-UN-14DEC90

H42420



H42421

-UN-14DEC90

H42421

TM1581,HX100,M -19-03OCT94

AUGER FINGERS

1. Use JDC3 driver to remove two finger guide screws and remove guide.

NOTE: Use driver with 1/4 to 3/8 in. adapter.

2. Remove access hole covers in auger.

3. Use 1/2 in. socket on a ratchet and 1/2 in. wrench. Reach through two access holes and remove cap screw with lock nut. Remove broken parts.

4. Install new parts and torque cap screw to 16 N·m (12 lb-ft). Install guide.

H30649 -UN-23FEB89



H30649



-UN-13OCT88

H31987


TM1581,HX100,N -19-03OCT94

CUTTERBAR DRIVE CASE

General Information

The knife is driven by an enclosed “wobble joint” drive. All moving parts in the drive are enclosed and operate in 0.95 L (one quart) of John Deere API GL-5 Gear Lubricant.

1. Loosen belt and slip it off drive case sheave (A).
2. Remove two cap screws attaching knife head to drive arm (B).
3. Remove five round-head bolts (three on 213, 215 and 216 platforms) attaching mounting to cutterbar angle (C).
4. Remove two round head bolts attaching mounting to skid plate (D).
5. Lift drive case with mounting off platform (E).



H30662

-UN-05DEC91

H30662


TM1581,HX100,O -19-03OCT94

200 and 900 Series Cutting Platforms/Cutterbar Drive Case

6. Remove cotter pin, slotted nut and washer (A) and use a puller to pull drive arm from shaft.

7. Remove four cap screws and remove mounting from drive case (B).


NOTE: Procedure is same for counterbalance knife drive arm.



100
05
19
-UN-15JUN89
H30663

HX1581,10005,DA-19-03OCT94

8. Remove lock nut and washer (A) and use a puller to pull sheave from wobble shaft.




-UN-15JUN89
H30664

1401,10005,S -19-12SEP91

DISASSEMBLY


1. Remove six cap screws (A) from housing cover (B).



E13174 -UN-07JUN89

1401,10005,T -19-12SEP91

2. Remove housing cover (C) and yoke cap (D).




H45118 -UN-10SEP92

3. Remove yoke and wobble shaft assembly (E) by tilting yoke and sliding from housing (F).

4. Replace yoke and wobble shaft assembly from parts if needed.

NOTE: Yoke and spindles are not available in service parts.




H45119 -UN-10SEP92

1581,10005,ZB -19-03OCT94

5. Place wobble shaft (A) in vise. Do not clamp vise onto shaft. Place drive sheave onto shaft or make a special holding tool (B). To make holding tool, use old drive sheave and remove the center of the sheave.


6. Loosen old stake and remove nut (C) from the wobble shaft.



Yoke Removed for Clarity

TM1581,HX100,CE-19-18AUG94

7. Press wobble shaft (A) from housing (B). Be certain to press on unfinished surface (C) of shaft.




Yoke Removed for Clarity

TM1581,HX100,CF-19-18AUG94

INSPECTING DRIVE CASE COMPONENTS

1. Wash all parts thoroughly in a clean solvent and dry. Clean all oil out of knife drive case.
2. Inspect all parts for wear or damage. Replace, if necessary.
3. Check for irregular wear patterns, nicks, etc.
4. Check bearings for roughness. Be certain bearings rotate freely and all rollers are in place.
5. Inspect housing cover and yoke cap for wear. Inspect all bearings and threads on wobble shaft. Inspect splines on yoke shaft.
6. Check bearings (B) and (C) in cap assembly (A). Press out and replace if necessary.




A—Cap
 B—Inner Bearing
 C—Outer Bearing
 D—Oil Seal
 E—O-Ring

HX,1401,1005,AK-19-16DEC92

H45122 -UN-10SEP92

7. Check cover assembly (A) including bearing (B) and seal (C). Replace if necessary.

A—Cover
 B—Bearing
 C—Oil Seal





HX,1401,1005,AL-19-16DEC92

H45123 -UN-10SEP92

100
 05
 22

INSTALL DRIVE CASE BEARINGS

1. Since a drawn cup (DC) bearing has a press-fit in its housing, an installation tool similar to the one illustrated must be used.
2. A standard arbor press, used with the correct tool, makes an adequate assembly machine. The press fit eliminates the need for snap rings or shoulders to hold the bearings in place axially.
3. Always assemble bearing with stamped end (end with identification markings) against angled should of pressing tool.
4. Never drive bearing into housing with a hammer or other impact tool, even in conjunction with proper assembly mandrel.
5. Never press bearing tightly against a shoulder in housing. If it is necessary to use a shouldered housing, the depth of housing bore must be sufficient to make certain that housing shoulder fillet, as well as shoulder face, clears the bearing.
6. Use a positive stop on press tool to locate bearing properly in housing. The assembly tool should have a leader or pilot to aid in starting bearing true in housing, as shown.
7. The ball detent on the drawing is used to assist in aligning rollers during installation and to hold bearing on the installation tool.
8. If a DC bearing has to be removed from a through bored housing, a tool similar to the installation tool shown, without the stop, may be used.
9. The outside shell of a drawn cup (DC) bearing is precision drawn from strip steel. In heat-treating operation, the shell may go out of round. When DC bearing is pressed into a true round housing of proper size and wall thickness, it becomes round and is sized properly for satisfactory bearing performance. For this reason, it is impossible to inspect an unmounted drawn cup bearing by measuring its outside diameter.




- A—0.38 mm (1/64 in.)
less than housing bore
- B—0.08 mm (0.003 in.)
less than shaft diameter
- C—Distance bearing will
be inset into housing 0.25 mm
(0.010 in. min.)
- D—Pilot length should be
bearing width less 8 mm
(11/32 in.)
- E—Approx. 1/2 dimension D
- F—Stamped end of bearing

TM1581,HX100,CG-19-18AUG94

100
05
24

ASSEMBLE KNIFE DRIVE CASE

1. Press bearing cups and cones (A) in housing.




Yoke Removed for Clarity

E15729
-UN-07JUN89

TM1581,HX100,CH-19-18AUG94

2. Tighten stake nut until the bearings have a rolling torque of 0.34 to 0.56 N·m (3 to 5 lb-ft.).
3. To check, place a 3/4 in. nut (B) on wobble shaft (A) and check as shown.
4. Stake nut to wobble shaft using punch.




Yoke Removed for Clarity

E15732
-UN-03OCT88

TM1581,HX100,CI-19-18AUG94


5. Check oil seal and bearing (A). Press and replace if necessary.



100
05
25
-UN-10SEP92
H45124

TM1581,HX100,CJ-19-18AUG94

6. Install yoke and shaft assembly (A) by tilting yoke and sliding into housing (B).



-UN-07JUN89
E15734


TM1581,HX100,CK-19-18AUG94

7. Install cap assembly on housing. Tighten bolts to 271 N·m (200 lb-ft) torque.



E26494 -UN-04OCT89

8. Apply TY15130 Form-In-Place Gaskets on housing cover (B) and install on housing. Torque bolts (A) to 45 N·m (30 lb-ft).



E13174 -UN-07JUN89

9. Install sheave and washer. Tighten nut to 150 N·m (110 lb-ft) torque. Tap nut with hammer and re-torque to 150 N·m (110 lb-ft).

TM1581,HX100,CL-19-18AUG94



INSTALLATION

1. Locate drive arm with counterweight in mounting.
2. Attach mounting to drive case with four cap screws (A). Tighten cap screws to 271 N·m (200 lb-ft) torque.
3. Attach drive arm to yoke shaft with washer and slotted nut (B). Tighten slotted nut to 270 N·m (200 lb-ft) torque. Strike knife arm several times with hammer to seat knife arm on tapered shaft and retighten to one slot past 270 N·m (200 lb-ft) torque. Insert and spread cotter pin.
4. Place drive case with mounting on platform and secure to skid plate with three round head bolts (C).
5. Attach cutterbar angle to mounting with five round head bolts (D). Tighten round head bolts to 45 N·m (35 lb-ft) torque.
6. Attach knife head to drive arm (E) with two cap screws. Tighten cap screws to 115 N·m (85 lb-ft) torque.
7. Fill drive case with approximately 0.95 L (one quart) of John Deere API GL-5 Gear Lubricant to 89 mm (3-1/2 in.) below breather hole (F).


IMPORTANT: Overfilling can cause leakage, overheating and internal damage.

8. Install drive belt on sheaves (G).

NOTE: Procedure is same for counterbalance knife arm.



KNIFE DRIVE CASE



100
05
28

H44796 -UN-03AUG92

HX,1401,1005,AR-19-16DEC92


200 and 900 Series Cutting Platforms/Knife Drive Case

1—Lock Nut	14—Nut	26—Screw, 1/2 x 1-1/2 in. (2 used)	35—Cap Screw, 1/2 x 1 in. (2 used) Flex
2—Washer	15—Cap Screw, 5/16 x 5/8 in. (2 used)	27—Bolt, 5/8 x 2 in. (4 used)	36—O-Ring
3—Sheave	16—Shield	28—Washer	37—Bearing, Inner
4—Seal	17—Relief Valve	29—Nut	38—Bearing, Outer
5—Bearing	18—Bushing, 3/8 x 1/8 in.	30—Cap Screw, 1/2 x 1-3/4 in.	39—Seal
6—Cover	19—Needle Bearing	31—Washer	40A—Support
7—Cap Screw, 5/16 x 1 in. (6 used)	20—Seal	32—Clamp	40B—Support
8—Sealant	21—Housing	33A—Arm	41—Shield
9—Shaft	22—Bushing (2 used)	33B—Arm	42—Bolt (2 used)
10—Bearing Cone (2 used)	23—Yoke	34—Cap Screw, 1/2 x 1-1/4 in. (3 used) Flex	43—Bolt (3 used)
11—Housing	24—Drive		
12—Spindle (2 used)	25—Cotter Pin, 5 x 50 mm		
13—Disk (2 used)			

TM1581,HX100,S -19-03OCT94

100
05
29

CUTTERBAR DRIVE SHAFT



- | | | | |
|--|----------------------------------|------------------------|------------------------------|
| 1—Nut, 3/4 in. | 6—Locking Collar | 11—Ball Bearing | 18—Snap Ring |
| 2—Washer, 25/32 x 1-5/8
x 0.180 in. | 7—Bearing Flange (4 used) | 12—Support | 19—Shield |
| 3—Drive Sheave | 8—Ball Bearing | 13—Support Bracket | 20—Bearing |
| 4—Belt | 9—Woodruff Key,
1/4 x 7/8 in. | 14—Bolt, 1/8 x 3/4 in. | 21—Snap Ring (—635100) |
| 5—Set Screw,
1/4 x 1/4 in. (2 used) | 10A—Drive Shaft | 15—Sprocket | 22—Lock Washer
(635101—) |
| | 10B—Drive Shaft | 16—Shield | 23—Lock Nut (635101—) |
| | | 17—Drive Shaft Shield | |


Exploded View of Cutterbar Drive

TM1581,HX100,T -19-03OCT94

H44797 -JUN-09AUG92

REPLACING CUTTERBAR DRIVE BELT

1. Remove left-hand long divider point from flex platforms. Remove belt by pulling handle (A) rearward and slipping belt from under tightener.
2. Loosen nuts (B) and remove bolts (C).
3. Slip new belt behind support.
4. Position belt in sheave grooves. Pull handle (A) rearward and slip belt under tightener.
5. Replace bolts (C) and tighten nuts (B).




TM1581,HX100,U -19-03OCT94

ADJUSTING FIXED IDLER POSITION

When operating a rigid platform with the cutterbar fully extended or in the mid position, idler (A) must be installed in hole (B).

When cutterbar on a rigid platform is in its rearward position, idler (A) must be installed in hole C.

On flex platforms, the idler must always be installed in hole (B).




900CP,SE,O -19-04DEC92

LEFT-HAND STABILIZER SOCKET (FLEX PLATFORMS ONLY)


Use the following procedure to adjust a new socket for the left-hand stabilizer.

1. Start engine, raise platform all the way and shut off engine.
2. Lower safety stop.
3. Remove lock-out washer. Save hardware. Reinstall washer by inserting a 3/8 x 2 in. cap screw from the top (A). Place 1-1/4 in. O.D. washer and nut on cap screw and tighten.



TM1581,HX100,V -19-03OCT94

4. Insert a small pry bar in plug access hole (A) and rotate socket (B) to the correct position (C) shown. Socket is correctly positioned when the grease plug is over the FRONT half of the hole (A).



100
05
32


H30668
-UN-05APR89

TM1581, HX100, W -19-03OCT94

NOTE: Step 5 requires two service technicians.

5. Use 1 in. socket on an extension 508 to 660 mm (20 to 26 in.) long to tighten nut (A) to 135 N·m (100 lb-ft.) torque. Keep socket (B) from rotating while tightening by inserting the small pry bar in the plug access hole.

6. Remove lock-out washer and reinstall with the original hardware provided.



H30669
-UN-05APR89

1401, 10005, B4 -19-12SEP91


CLEANING DIRT FROM UNDER FLEXIBLE SEALS

At the end of each season, or more often as necessary, clean out the dirt from between flexible seals (A) and skid shoes (B) in area (C). Bolts (D) may have to be taken out to remove packed dirt.

CAUTION: Lower feeder house safety stop when working under platform. Turn off engine and remove key.

Hit the skid shoes with a hammer to “jar” dirt free.

A build-up of dirt in this area can restrict the movement of flex seals (A) and cause the skid shoes and cutterbar assembly to become heavier than normal, causing pushing of dirt.




H42426
-UN-14DEC90

H42426


900CP, SE, P -19-24JAN91

PICKUP REEL



- | | | | |
|--------------------------------------|--------------------------|----------------------|------------------------------|
| 1—Bracket (6 used) | 5—Finger | 10—Bolt | 15—Arm |
| 2—Bolt, 5/16 x 5/8 in.
(6 used) | 6—Finger (12 used) | 11—U-Bolt | 16—Cap Screw, 5/16 x 1/2 in. |
| 3—Bolt, 5/16 x 2-1/2 in.
(6 used) | 7—Retainer | 12—Lock Nut, 1/4 in. | 17—Plate |
| 4—Screw, No. 8 x
3/4 in. | 8—Bracket, Center | 13—Cap | 18—Shield |
| | 9—Bracket, L.H. (6 used) | 14—Base | |

Legend for Pickup Reel



- | | | | |
|--|---------------------------------------|--------------------------------|--|
| 1—Nut, 1/2 in. (Flex) | 6—Bolt (6 used) (Rigid) | 12—U-Bolt (6 used) | 17—Plate |
| 2—Lock Washer, 1/2 in. (Flex) | 7—Spacer (6 used) (Rigid) | 13—Lock Nut, 1/4 in. (12 used) | 18—Ring |
| 3—Washer, 17/32 X 1-1/4 x 0.060 in. (Flex) | 8—Bracket (6 used) (Rigid) | 14—Cap (6 used) | 19—Cap Screw, 5/16 x 1/2 in. (12 used) |
| 4—Spacer (6 used) (Flex) | 9—Finger (6 used) (Rigid) | 15—Base (6 used) | 20—Cap Screw, 5/16 x 3/4 in. (6 used) |
| 5—Cap Screw, 1/2 x 2 in. (Flex) | 10—Retainer (6 used) (Rigid) | 16—Arm (6 used) | |
| | 11—Lock Nut, 1/2 in. (6 used) (Rigid) | | |

Legend for Pickup Reel (640501—)

TM1581,HX100,Y -19-03OCT94

GENERAL INFORMATION

The reel gathers the crop, holds it until it is cut by the cutterbar, and then moves it into the platform auger.

The pickup reel has steel fingers attached to the slats. These fingers reach down into the crop and lift it so the cutterbar can get under it.

1401,10005,B6 -19-12SEP91

REEL REMOVAL AND DISASSEMBLY



1. Position the first bat to be removed in its uppermost position.

CAUTION: Leave reel drive chain in place to prevent reel from accidentally turning.

2. Refer to exploded views and remove lock nuts (12 or 13), U-bolt (11 or 12), bearing cups (13 or 14) and bearing bases (14 or 15) from reel arms (15 or 16).

Lift bat off reel arms. To balance reel, remove the next bat opposite the first one removed.

3. Remove cap screws (16 or 20) and remove reel arms (15 or 16) from spider plate (17).

4. Inspect all parts of the reel for damage or excessive wear. Replace parts as necessary.


TM1581,HX100,Z -19-03OCT94

ASSEMBLY

Refer to exploded view when assembling reel parts.

1401,10005,C3 -19-12SEP91

REEL DRIVE (900 SERIES)



- | | | | |
|-------------------------------|------------------------------------|-------------------------------|--|
| 1—Shield | 8—Bushing | 14—Support | 21—Snap Ring |
| 2—Cap Screw, 5/16 x 1/2 in. | 9—Grease Fitting | 15—Cap Screw, 1/2 x 1 in. | 22—Cotter Pin, 1/8 x 1-1/4 in. |
| 3—Cap Screw, 5/16 x 1-3/4 in. | 10—Mounting | 16—Trunnion | 23—Pin |
| 4—Plate | 11—Cap Screw, 3/8 x 1-3/4 in. | 17—Cap Screw, 1/2 x 7-1/2 in. | 24—Drive Gear |
| 5—Spacer | 12—Ball Bearing | 18—Bushing | 25—Set Screw, 3/8 x 1 in. (2 used) |
| 6—Drive Gear | 13—Washer, 1-15/32 x 2 x 0.105 in. | 19—Lock Nut, 1/2 in. | 26—Self-Tapping Screw, 5/16 x 1/2 in. (3 used) |
| 7—Cap Screw, 3/8 x 3/4 in. | | 20—Plastic Slide | |

R.H. Mountings and Gears

Align gears with a slight amount of backlash. Refer to TM1401, Section 70 for repair of hydraulic motor. The


drive for a pickup reel is illustrated, but service for either pickup or slat reel is the same.

TM1581, HX100, AA-19-03OCT94

100
05
36

I-46701 -JUN-21SEP94

200 and 900 Series Cutting Platforms/Reel Drive (900 Series)



- 1—Shaft Key
- 2—Bolt, 3/8 x 1 in.
- 3—Shaft, R.H.
- 4—Cap Screw, 3/8 x 3/4 in.
(6 used)
- 5—Shaft, Center

- 6—Shaft, L.H.
- 7—Washer
- 8—Cap Screw, 3/8 x 3/4 in.
(3 used)
- 9—Ball Bearing (3 used)
- 10—Bushing (2 used)

- 11—Support
- 12—Support, L.H.
- 13—Support, L.H.
- 14—Self-Locking Screw
- 15—Pad


- 16—Pin
- 17—Cotter Pin,
1/8 x 1-1/4 in.
- 18—Snap Ring
- 19—Locking Collar

L.H. Mountings (—640500)

H44862 -JUN-03AUG92

HX,1401,1005,BB-19-16DEC92

100
05
37




- | | | | |
|--|---|-----------------------------------|---------------------------------------|
| 1—Shield | 8—Bushings (2 used) | 16—Pin | 23—Pin |
| 2—Cap Screw,
5/16 x 1/2 in.
(2 used) | 9—Lubrication Fitting | 17—Cap Screw, M10 x 220 | 24—Spur Gear |
| 3—Cap Screw,
5/16 x 1-3/4 in. | 10—Support | 18—Bushing | 25—Set Screw,
3/8 x 1 in. (2 used) |
| 4—Plate | 11—Cap Screw,
3/8 x 1-3/4 in. (3 used) | 19—Lock Nut | 26—Screw, 5/16 x 1/2 in.
(3 used) |
| 5—Spacer | 12—Ball Bearing | 20—Pad | 27—Washer (2 used) |
| 6—Pinion | 13—Washer | 21—Snap Ring | 28—Drive Shaft |
| 7—Cap Screw,
3/8 x 3/4 in.
(4 used) | 14—Support, R.H. | 22—Cotter Pin,
1/8 x 1-1/4 in. | |
| | 15—Self-Locking Screw | | |

R.H. Mountings and Gears

HX,1401,1005,BC-19-03OCT94

I-44863 -UN-03AUG92



- | | | | |
|--|--|-----------------------------------|--------------------|
| 1—Shaft | 7—Lubrication Filling,
1/8 in. Straight | 11—Deflector | 16—Lock Nut |
| 2—Bolt, 3/8 x 1 in. | 8—Support | 12—Pad | 17—Pin |
| 3—Washer | 9—Support | 13—Cotter Pin,
1/8 x 1-1/4 in. | 18—Washer (2 used) |
| 4—Cap Screw,
3/8 x 1-3/4 in. (3 used) | 10—Self-Locking Screw,
1/2 x 1 in. | 14—Pin | 19—Bushing |
| 5—Ball Bearings (3 used) | | 15—Snap Ring | 20—Cap Screw |
| 6—Bushings (2 used) | | | 21—Support |

L.H. Mountings (645301—)

H44864 -JUN-03AUG92


HX,1401,1005,BD-19-03OCT94

STUBBLE LIGHT BULB REPLACEMENT

Remove nut securing housing (A).

Unscrew housing from base.

Push AD2062R (1156) bulb in and turn to remove.



H42849

H42849 -JUN-29NOV90

TM1581,HX100,CN-19-18AUG94


HEADER WARNING LIGHT BULB REPLACEMENT

Remove nuts (A).

Remove shield (B).

Unscrew housing (C) from bulb base.


Push AD2062R (1156) bulb in and turn to remove.



TM1581,HX100,CO-19-18AUG94

H42850 -UN-29NOV90

INSTALLING NEW REPAIR FLOOR SHEET ON 200 AND 900 SERIES PLATFORMS



H46634 -UN-02AUG94

IMPORTANT: Do not cut out bottom sheet on platform. This center floor repair sheet is made to be welded on top of existing sheets.

NOTE: Repair sheet was designed for use in center section of platform but can be used in any location on floor of platform. Additional holes may have to be drilled when used in other locations.

1. New repair sheet must lay flat on floor of platform. Smooth out any material that will hold sheet up and remove all hardware.

2. Lay sheet on platform floor in center of feeder house opening then align holes in sheet to holes in floor and reinstall hardware.


3. Weld around as shown with X's.

4. Plug weld all the remaining holes that do not have hardware in them.

5. Smooth any rough spots in weld so crop flows smoothly across floor.

1581,10005,ZI -19-28SEP94

INSTALLING FRAME METRIC HARDWARE



NOTE: Metric hardware **MUST** be used in the following application on 1993 and later platform frames. 1993 platforms (650001—) already include metric hardware. When **NEW** frames are substituted for platforms prior to 1993 (—650000) the hardware listed below **MUST** be used (included in AH141977).

(A)—19M7867 - M8 x 25 hex flange head cap screw used at center of platform to bolt stripper supports to tapped holes in floor (4 to 8 used depending on stripper position).

(B)—19M7139 - M8 x 20 hex head cap screw used at center of platform to plug unused tapped holes (0 to 4 used depending on stripper position).

(C)—37M7087 - M10 x 25 self tapping screw used to attach sensing box support to right-hand tilt channel (1 used flex only).

(D)—37M7087 - M10 x 25 self tapping screw used to attach long divider supports to lower tube cap (2 used on right-hand end; 3 used on left-hand end, flex only). Used to attach right-hand shield bracket to lower tube cap (2 used on right-hand end, rigid only).

HX1581,10005,EA-19-03OCT94

100
05
42

Group 10 40 Series Corn Heads

TORQUE VALUES

	Torque N·m (Lb·Ft.)
Countersunk head cap screws by gathering chain sprockets	110 N·m (80)
Gatherer chain guide cap screws	115 N·m (85)
Trash knife cap screws	115 N·m (85)
Stalk roll to shaft F grade cap screws	150 N·m (110)

HX1581,10010,A -19-03OCT94

SPECIAL TOOLS

The following JDC400 series tools are required to properly service the corn head gear case. They are not offered as a complete set, but must be ordered individually. In addition, some of the various drivers in D01045AA Driver Set are also required for use with the JDC400 series tools.

HX,1401,10010,A-19-03OCT94

Number: *JDC400-1 Seal Installer
Use: To install gatherer shaft seals.

H45090 -UN-08SEP92



HX,1401,10010CC-19-03OCT94

Number: *JDC400-2 Plug Installer
Use: To install expansion plugs.

H45091 -UN-08SEP92



HX,1401,10010CD-19-03OCT94

40 Series Corn Heads/Special Tools

Number: *JDC400-3 Spacer
Use: To install gatherer drive shaft bushings.

H45092 -UN-08SEP92



HX,1401,10010CE-19-03OCT94

Number: *JDC400-4 Spacer
Use: To install input shaft needle bearing.


H45093 -UN-08SEP92



HX,1401,10010CF-19-03OCT94

Number: *JDC400-5 Seal Installer
Use: To install barrel seals.

H45094 -UN-08SEP92



HX,1401,10010CG-19-03OCT94

Number: *JDC400-6 Seal Driver
Use: To install input shaft seal

H45095 -UN-08SEP92



*Order from:
Service Tools, Box 314, Owatonna, MN 55060

HX,1401,10010CH-19-03OCT94

100
10
2

40 Series Corn Heads/Special Tools

Number: *JDC400-7 Handle
Use: Used with various drivers and spacers.

H45096 -UN-08SEP92



HX,1401,10010CI-19-03OCT94

100
10
3

Number: *JDC400-8 Spacer
Use: To install barrel bearings.

H45097 -UN-08SEP92



HX,1401,10010CJ-19-03OCT94

Number: *JDC400-9 Deck Plate Spacing Tool
Use: To set correct spacing of deck plates.

H45098 -UN-08SEP92



HX,1401,10010CK-19-03OCT94

Number: *JDC400-10 Stalk Roll Timing Tool
Use: To set correct timing of stalk rolls.

H45099 -UN-08SEP92



HX,1401,10010CL-19-03OCT94

40 Series Corn Heads/Making Special Tools

Number: *D01045AA Master Bushing and Seal Driver Set

Use: Some of the drivers in this set are required for use with the JDC400 series tools.

Number: *D01046AA Tool Organizer Board

Use: Keeps D01045AA set components in proper order and safe from loss. Tools not included.

Number: *JDG450 Mechanical Puller or JDG610 hydraulic puller

Use: To pull stalk rolls (not shown).

*Order from:

Service Tools, Box 314, Owatonna MN 55060




HX1581,10010,EA-19-03OCT94

MAKING SPECIAL TOOLS

In addition to the JDC400 series tools, the following tools can be made in the dealer shop for servicing the corn head gear case.


- A—Gear Case Support
- B—Locating Dowel Studs
- C—Timing Tool



HX,1401,10010,C-19-03OCT94

The gear case support bracket is used for mounting the gear case in a vise. Make it from 6.4 mm (1/4 in.) steel plate.

- A—203 mm (8 in.)
- B—152 mm (6 in.)
- C—Two Holes,
13 mm (17/32 in.) dia.
- D—25 mm (1 in.)
- E—25 mm (1 in.)
- F—51 mm (2 in.)



H30651


100
10
5

-UN-10OCT88
H30651

HX,1401,10010,D-19-16DEC92

Barrel assembly locating dowel studs are used to assist in mounting the barrel assembly on the gear case. Make two studs by cutting off the heads of two 19H2530 3/8 x 3 in. cap screws.

- A—76 mm (3 in.)
- B—9.6 mm (3/8 in.)




H30652

-UN-10OCT88
H30652

HX,1401,10010,E-19-16DEC92

If the JDC400-10 tool is not available, a stalk roll timing tool can be made.

- A—37 mm (1-7/16 in.)
 - B—32 mm (1-9/32 in.)
 - C—102 mm (4 in.)
 - D—25 mm (1 in.)
 - E—25 mm (1 in.)
 - F—51 mm (2 in.)
 - G—Weld
 - H—152 mm (6 in.)
 - I—37 mm (1-7/8 in.)
 - J—24 mm (15/16 in.)
 - K—3 mm (1/8 in.)
 - L—13 mm (17/32 in.)
- Diameter Holes. Time as shown.




H30653


-UN-10OCT88
H30653

HX,1401,10010,F-19-03OCT94

Wood Gauge
 A-Front
 B-Rear



Metal Gauge
 A-Weld
 B-Do Not Weld



If the JDC400-9 gauge is not available, a gauge for deck plate spacing can be made from wood or metal.

TM1581,HX100,AD-19-03OCT94

GENERAL INFORMATION

As the combine moves through the field, the gatherer points are positioned between the rows of corn. The stalk rolls pull the corn stalks down so the ear will be snapped on the deck plates. Trash knives prevent weeds and trash from wrapping around the stalk rolls. The gatherer chains catch the ears and move them up to the auger. The auger then moves the ears to the front of the feeder house where two rubber paddles feed the ears into the feeder house.


1401,10010,A -19-12SEP91

100
10
6

40 Series Corn Heads/General Information

100
10
7

AUGER REMOVAL



NOTE: The corn head auger can be removed without removing the center shields.

CAUTION: Outer gatherer sheet (A) and point weigh approximately 45 kg. (100 pounds).

To raise outer gatherer sheet:

1. Remove nut (B), lock washer (C) and square washer (D) from bolt (E).

2. Remove lock nut (F) from bolt (G).

CAUTION: Support strap must be locked into position shown when outer gatherer sheet is raised.

3. Raise gatherer sheet (A) and lock support straps (I) into position.

CAUTION: When corn head is raised and cylinder safety stop is in safety position, the outer gatherer sheet and point assembly will be free to become unhooked after safety strap is removed and can fall forward.

To remove:


4. With outer gatherer sheet (A) raised, remove hardware lock nut, carriage bolt and lock washer attaching support strap (I) to gatherer sheet (A).

CAUTION: Outer gatherer sheet with gatherer point is heavy and awkward to handle.

5. Lift outer gatherer sheet (A) and point assembly off row unit at hinge points.

6. Remove row unit drive shaft shield (A).

7. Turn auger by hand and disconnect auger drive chain (B). Wedge auger securely by placing a wood block under auger, aligning at each end.




H43763 -UN-26AUG91

TM1581,HX100,AF-19-03OCT94

40 Series Corn Heads/Auger Removal

100
10
10




H43765

-UN-26AUG91
H43765

8. Remove nut (A) and washer (B). Disconnect and remove chain on sprocket (F).
9. Remove cap screws (G), housings (D), and bearing (E) on left-hand end of auger.
10. Use a safe hoist and remove by lifting right-hand end of auger up and out of corn head first. Complete removal by swinging auger out and over center shields.

Inspect all parts for damage or excessive wear and replace as required.

- A—Nut, 3/4 In.
- B—Washer, Lock, 3/4 In.
- C—Washer, 25/32 x 1-5/8 x 0.180 In.
- D—Housing (4 Used)
- E—Bearing (2 Used)
- F—Sprocket
- G—Bolt, 3/8 x 3/4 In.
- H—Paddle (2 Used)
- I—Strap
- J—Strap
- K—Bolt, 3/8 x 1-1/4 In.
- L—Auger



H43764

-UN-26AUG91
H43764

1401,HX,1010,C -19-16DEC92


ASSEMBLY AND INSTALLATION

1. Reinstall in reverse order.

IMPORTANT: Be certain to place hub side of sprocket against the auger to insure sprocket alignment.

2. Install row unit drive shaft shield (A).

3. Install right-hand outer gatherer sheet and point.




TM1581,HX100,AG-19-03OCT94

4. Both sides of the corn head main frame and auger bearing carriers (A) are slotted for adjusting the auger. The auger can be adjusted up and down and fore and aft for proper clearance with bottom of feed bed.

5. Keep the auger adjusted down and to the rear as far as possible in normal dry conditions. In damp, sticky or heavy trash conditions, adjust the auger up and forward to move material away from the row unit.

6. In normal conditions, keep a minimum of 6 mm (1/4 in.) clearance between auger and auger stripper.



1581,10010,ZD -19-03OCT94

ROW UNIT FRAME, GATHERER CHAINS, TRASH KNIVES AND DECK PLATES

Removal:

NOTE: If one of the outer row unit frames is to be removed, it will be necessary to remove the outer gatherer sheet. See "Auger Removal".

1. To raise center shield (A) forward as shown, first start engine and raise the corn head as high as possible.
2. Lower hydraulic cylinder safety stop (B) and shut off engine.



CAUTION: When corn head is raised and cylinder safety stop is in safety position, the center shield extension and point assembly will be free to become unhooked.

3. Release the center shield latches from their attaching points and raise center shield.

CAUTION: Center shield with extension and point is heavy and awkward to handle.

4. With center shield raised, lift assembly off row unit at hinge point (C).
5. Repeat above steps in reverse order to install center shield, shield extension and gatherer point assembly.

NOTE: When installing, center shield latches require a force of 11.3 kg (25 pounds) to snap latch closed.




TM1581,HX100,AH-19-03OCT94

CAUTION: Never service any part of the gatherer chain mechanism or idler sprocket until nut (A) is tight against the leg of the idler support strap.

6. Relieve gatherer chain tension by turning nut (A) until it is against the leg of the idler support strap (B).
7. Loosen bolt (C) until tension is off gatherer chain.
8. Remove bolts (D). This will allow the idler sprocket (E) to move back so the gatherer chain (F) can be removed.

NOTE: If idler sprocket will not slide back, remove entire idler assembly and clean idler support strap and the slot in the idler support bracket.




H30674 -UN-05DEC91

100
10
13

1401,10010,H -19-12SEP91


9. Remove idler sprocket (A), idler support (B), idler support strap (C), idler stop (D), spring (E), flat washer (F) and machine bolt (G).
10. Remove two cap screws (H), lock washers (I) and flat washers (J), attaching chain guide (K) to row unit frame (L).
11. Remove deck plate (M).



H43766 -UN-26AUG91

TM1581,HX100,CR-19-18AUG94

12. Remove snap ring (A) and remove drive sprocket (B).
13. Remove countersunk head cap screws (C) and upper latches (D).



H30675 -UN-05DEC91


1401,10010,J -19-12SEP91

14. Remove attaching cap screws (E) and remove trash knives.

CAUTION: Approximate weight of row unit frame is 23 kg (50 pounds); use two people to remove it from the corn head.

15. Remove four row unit attaching cap screws (F) and lift row unit frame off stalk rolls and gear case.

NOTE: Refer to "Gear Case Removal" for information concerning removal, service and installation.



1401,10010,K -19-12SEP91



INSPECTION AND REPAIR

Inspect all parts removed from the row unit frame for damage and excessive wear. Replace parts as necessary.

1401,10010,L -19-12SEP91

ASSEMBLY AND INSTALLATION

1. Install gear case if it has been removed for service. Refer to Gearcase Removal in this Section.
2. Install stalk rolls on gear case. Refer to Gearcase Removal in this section.
3. Install row unit frame with four countersunk head cap screws (C). After all cap screws are installed, tighten to 11 N·m (11 kg) (80 lb-ft) torque.
4. Install upper latches (D).
5. Install drive sprockets (B) on hex. shafts and secure with snap rings (A).
6. Install deck plates (E) and chain guides (F). Do not tighten cap screws at this time.
7. Install machine bolt (G), flat washer (H), spring (I), idler stop (J), idler support strap (K), idler support (L) and idler sprocket (M).



100
10
15

-UN-26AUG91

H43767

-UN-05DEC91

H30675

TM1581,HX100,AJ-19-03OCT94


ADJUSTING DECK PLATES AND GATHERER CHAIN GUIDES

Adjust the deck plates (A) as follows:

1. Raise the center shields.
2. Loosen four bolts (C) on both deck plates.
3. Position deck plates so the center space between the edge of the deck plates is located over the center space between the gatherer chains.
4. Adjust gatherer guides (D) in until they are just touching the gatherer chains.
5. Torque bolts (C) on guides and deck plates to 95 N·m (70 lb-ft).

NOTE: Deck plates must be spaced 1.6 mm (1/16 in.) wider apart at the rear than at the front.

IMPORTANT: The center of space (E) between deck plates must be located over the center of space (E) between stalk rolls.




100
10
16

TM1581, HX100, AK-19-03OCT94

A gauge for deck plate spacing can be made from wood or metal.

A—Front
B—Rear




Wood Gauge

1401,10010,0 -19-12SEP91

40 Series Corn Heads/Adjusting Trash Knives

A—Weld
B—Do Not Weld




Metal Gauge

1401,10010,P -19-12SEP91

100
10
17
-JUN-20NOV89
H36199

ADJUSTING TRASH KNIVES

Loosen knife attaching bolts (C) and adjust each trash knife (A) to a maximum of 1.6 mm (1/16 in.) of the highest flute on the stalk roll (B). Torque bolts to 95 N·m (70 lb-ft).



TM1581,HX100,AL-19-03OCT94


-JUN-20NOV89
H36872

STALK ROLLS

To remove:


⚠ CAUTION: Lower hydraulic cylinder safety stop before working under corn head.

1. Remove trash knives (A) from underside of row unit frame.
2. Remove stalk roll (C) from shafts by driving out double spring pins (D) and removing F grade cap screws (E). Clean out slots in stalk rolls to permit installing puller.



TM1581, HX100, AM-19-03OCT94

3. Use JDG450 puller or JDG610 hydraulic puller to pull stalk roll off gear case shaft.



1581, 10010, ZS -19-03OCT94

INSPECTION

Inspect stalk rolls for wear or damage. Hard-faced stalk rolls are available as service parts.

IMPORTANT: Be certain to replace stalk rolls in pairs. Do not install hard-faced stalk roll with a soft one.

1401,10010,T -19-12SEP91

100
10
19

INSTALLATION


1. Clean stalk roll shaft and outside of barrel. Coat shaft with grease before sliding on new roll.

NOTE: The spirals on the FRONT rotate to move material to the rear of the stalk roll. The flutes turn down and toward the opposite stalk roll.

2. Secure stalk roll (C) to shaft with double spring pins (D) and two F grade cap screws (E). Tighten cap screws to 150 N·m (15 kg) (110 lb-ft) torque.

IMPORTANT: If stalk roll cap screws are replaced, use only 19H2735 1/2 x 2 in. F grade cap screws.

3. Refer to "Adjusting Trash Knives" and adjust the trash knives (A).



H30680
-UN-05DEC91

1401,10010,U -19-12SEP91

ROW UNIT GEAR CASE


General Information:

On the 40 Series Corn Heads, each row unit is driven by its own gear-type drive. The drive is a fully enclosed case located under each row unit.

A row unit input shaft (A) is driven from the feeder house. This shaft drives the slip clutch (B), which in turn drives the input gear located in the gear case.

This input gear drives an idler spur gear which drives the main countershaft (C). The main countershaft has two sets of bevel gears. The inner set, which consists of two bevel gears welded to the driving spur gear, drives the stalk roll shafts (D). The outer set of bevel gears drive the gatherer shafts (E).

Each gear case is protected by a slip clutch (B) located on the input shaft at the upper end of the gear case.



TM1581,HX100,AN-19-03OCT94

DIAGNOSING MALFUNCTIONS

- Stalk Rolls Clashing

- Stalk roll shafts not properly timed.
 - Stalk rolls striking trash knives.

- Gearcase Noisy

- Lack of lubricant.
 - Gears not meshing properly.
 - Excessive backlash.
 - Binding of gears.

- Gearcase or Barrel Assembly Excessively Hot

- Seal failure causing loss of grease.
 - Lack of lubricant.
 - Binding of gears.
 - Defective bearings or bushings.
 - Improperly installed bearing caps.
 - Dirt packed in stalk roll and on barrel.

- Barrel Assembly Leaking Grease

- Defective seal under stalk roll.
 - Defective bearing.

1401,10010,W -19-12SEP91


100
10
21

REMOVAL

1. Remove gatherer chains and sprockets. (See Removing Gathering Chains in this Section.)
2. Remove upper sprockets and latches. (See Removing Gathering Chains in this Section.)
3. Remove both trash knives (A) from under side of row unit.
4. Remove four cap screws and four countersunk screws (B) and remove row unit frame.
5. Remove stalk rolls. (See Stalk Roll Removal in this Section.)
6. Pull out row unit hex drive shaft (F). To do this, remove the protective shield and row unit drive chain at the outer end of the corn head. Remove three bolts securing bearing carrier to the corn head frame and pull out drive shaft.

NOTE: The drive shaft is split and only one shaft need be removed to remove gearcase. Be certain to remove the correct shaft for the gearcase to be serviced.

7. Remove gearcase (G) by removing two cap screws and two eyebolts (H) which secure the gearcase to the corn head frame.




H30682 -JUN-05DEC91

1130682

HX,1401,10010,J-19-16DEC92

DISASSEMBLY


1. Clean outside of gearcase thoroughly. Attach support bracket (A) (See Special Tools) to gearcase with two 1/2 x 1 in. cap screws.



HX,1401,10010,K-19-16DEC92


2. Set gearcase with support in vise (A) and remove slip clutch.

3. Remove barrel assembly with stalk roll shafts and gasket (B) from gearcase and set assembly to one side. If only the barrel assembly or stalk roll shafts are to be serviced, refer to "Servicing Barrel Assembly and Stalk Roll Shafts".




4. Remove gatherer drive shaft assemblies (C). Mark shafts so they can be reinstalled correctly to maintain proper gear wear.

5. Remove end caps (D) from each end of gearcase. Drive out from the inside of gearcase and pry out with a screwdriver. Be careful not to damage sealing surface of cap.



1401,10010,Z -19-12SEP91

6. Remove snap ring (A) from either end of hex. countershaft. Remove countershaft and both bevel (C) gears. Roll stalk roll drive gear cluster (D) out front of gearcase.




1401,10010,A1 -19-12SEP91

7. Drive in one plug with JDC400-7 handle (A) until the opposite one is loose. Drive shaft back until the remaining plug is loose.


8. Be careful not to damage tolerance ring on shaft. Do not drive ring through idler gear bearings. Drive out idler shaft (B).

9. Remove idler gear out front of gearcase.



HX,1401,10010,L-19-03OCT94

10. Remove input shaft cap (A) with bearings, seal, and gasket (B). Remove thrust washer (C) and input gear and shaft (D).



1401,10010,A3 -19-12SEP91

INSPECTION

Wash all parts thoroughly in a clean, safe solvent. Clean all grease out of gearcase.

Inspect all parts for wear or damage, especially bushings, bearings and seals.

If bushings or bearings need replacement, use the instructions on the following pages.

1401,10010,A4 -19-12SEP91

REPLACING BEARINGS AND BUSHINGS


NOTE: The part number is stamped into each special tool.

1401,10010,F7 -19-12SEP91

GATHERER DRIVE SHAFT BUSHING AND SEAL

1. Assemble special tools (A to D) for driving out gatherer drive shaft bushing and seal.

- A—JDC400-7 Handle
- B—27502, 1-3/16 in. Disk
- C—27499, 1 in. Disk
- D—10020 Screw



H30689 -UN-15JUN89

HX,1401,10010,M-19-03OCT94

2. Use tool (A) as shown and drive through gatherer cap opening in gear case against bushing (B). Drive out both bushings and seal.




H30690 -UN-15JUN89

HX,1401,10010,N-19-16DEC92

3. Assemble tools (A to E) for installing gatherer drive shaft bearing.

- A—JDC400-7 Handle
- B—27506, 1-7/16 in. Disk
- C—27499, 1 in. Disk
- D—10020 Screw
- E—JDC400-3 Spacer




H30691 -UN-15JUN89

HX,1401,10010,O-19-03OCT94

4. Use tools (A) as shown to install bushing. Drive bushing (B) from bottom to obtain proper location of bushing in case.

NOTE: Do not install seal at this time.



100
10
27

-UN-15JUN89
H30692

HX,1401,10010,P-19-16DEC92

REPLACING COUNTERSHAFT BUSHINGS

1. Assemble plates (A and B) on screw (C) and insert through opening in front of gear case. Insert handle (D) through opening in end of gearcase and assemble tool inside gearcase.

- A—27507, 1-1/2 in. Disk
- B—27512, 1-13/16 in. Disk
- C—10020 Screw
- D—JDC400-7 Handle




-UN-15JUN89
H30693

HX,1401,10010,Q-19-03OCT94

40 Series Corn Heads/Replacing Countershaft Bushings


100
10
28

2. Drive out bushing (A), then disassemble tool (B) for removal. If remaining bushing is to be removed, follow the above procedure from the opposite end of the gearcase.




3. Assemble tools (A to D) for installing countershaft bushing.

- A—JDC400-7 Handle
- B—27520, 2 in. Disk
- C—27507, 1-1/2 in. Disk
- D—10020 Screw




4. Use tools (A) to install new bushing (B).



REPLACING INPUT SHAFT (IN GEARCASE AND INPUT SHAFT CAP) NEEDLE BEARINGS AND SEALS

1. Assemble tool as illustrated.

- A—JDS400-7 Handle
- B—27520, 2-5/16 in. Disk
- C—27515, 2 in. Disk
- D—10020 Screw




HX,1401,10010,T-19-03OCT94

H30697 -JUN-15JUN89

100
10
29

2. Drive tool (A) against inner end of bearing to remove both seal and bearing.




H30698

H30698 -JUN-05DEC91

1401,10010,B5 -19-12SEP91

3. Assemble tools (A to E) for installing input shaft needle bearing.

- A—JDC400-7 Handle
- B—JDC400-4 Spacer
- C—27515, 2 in. Disk
- D—27525, 2-5/8 in. Disk
- E—10020 Screw



H30699


H30699 -JUN-05DEC91

HX,1401,10010,U-19-03OCT94

4. Use tools (B) drive bearing (A) from outside of gearcase (or outside of input cap). Install rounded edge of needle bearing in bore and drive against flat edge of bearing.

NOTE: Flat edge of bearing has manufacturer's name and part number stamped into it. Do NOT drive against rounded edge of bearing.

5. Do not install seals until after gears are all installed so proper backlash can be determined.




H30700 -UN-05DEC91

HX,1401,10010,V-19-16DEC92

REPLACING GATHERER CAP BUSHINGS

1. Use a screwdriver or slide hammer puller to remove bushing (A) from gatherer cap (B).




H30701 -UN-05DEC91

HX,1401,10010,W-19-16DEC92

2. Assemble special tool to install bushing.


- A—JDC400-7 Handle
- B—27515, 2 in. Disk
- C—27499, 1 in. Disk
- D—10020 Screw



H30702 -UN-05DEC91

HX,1401,10010,X-19-03OCT94

3. Install bushing (A) with special tool (B). Be certain shoulder of bushings (A) is tight against edge of bore in cap.




100
10
31
-UN-05DEC91
H30703

HX,1401,10010,Y-19-16DEC92

REPLACING IDLER GEAR NEEDLE BEARINGS

1. Assemble special tool.


- A—JDC400-7 Handle
- B—27502, 1-3/16 in. Disk
- C—27499, 1 in. Disk
- D—10020 Screw



-UN-15JUN89
H30689

HX,1401,10010,Z-19-03OCT94

2. Remove needle bearings (A) from idler gear (B).




-UN-05DEC91
H30704

HX,1401,10010AC-19-16DEC92

40 Series Corn Heads/Replacing Idler Gear Needle Bearings

3. Assemble special tool to install NEW needle bearings.

- A—JDC400-7 Handle
- B—27506, 1-7/16 in. Disk
- C—27499, 1 in. Disk
- D—10020 Screw
- E—JDC400-3 Spacer



H30691 -UN-15JUN89


HX,1401,10010AA-19-03OCT94

4. Drive against the flat end (end with vendor number) of the bearing and install one from each end. Do NOT install bearing by driving one bearing in against the other.

HX,1401,10010AB-19-16DEC92

100
10
32

ASSEMBLY



- | | | | |
|---------------------------------|-------------------------------|----------------------------|----------------------------------|
| 1—Stack Roll Drive Gear Cluster | 10—Oil Seal (2 Used) | 19—Needle Bearing | 29—Gatherer Drive Shaft (2 Used) |
| 2—Bushing (2 Used) | 11—Needle Bearing | 20—Expansion Ring (2 Used) | 30—Oil Slinger Spring (2 Used) |
| 3—Bevel Pinion Gear (2 Used) | 12—Input Cap W/Bearing | 21—Tolerance Ring | 31—Gearcase |
| 4—Snap Ring (2 Used) | 13—Cap Screw, 3/8 x 1-1/8 In. | 22—Idler Shaft | 32—Cap Screw, 1/2 x 1-1/4 In. |
| 5—Countershaft | 14—Lock Washer, 3/8 In. | 23—Needle Bearing (2 Used) | 33—Lock Washer, 1/2 In. |
| 6—Grease Cap (2 Used) | 15—Gasket | 24—Idler Gear Assembly | 34—Drive Sprocket (2 Used) |
| 7—Bushing (2 Used) | 16—Thrust Washer (2 Used) | 25—Cap Screw, 3/8 x 1 In. | 35—Snap Ring (2 Used) |
| 8—Grease Seal (2 Used) | 17—Input Gear | 26—Bushing (2 Used) | |
| 9—Pipe Plug, 3/4 In. | 18—Grease Fitting, 1/8 In. | 27—Gatherer Cap W/Bearing | |
| | | 28—Gasket | |

H30705


H30705 -UN+26AUG91

100
10
33

1. Use John Deere Corn Head Lube and lubricate all bushings and bearings prior to assembly of gearcase. Also pack seals with this grease prior to installation.

IMPORTANT: This special high-pressure lubricant is available in a 0.4 kg (14-1/2 oz.) tube (AN102562), or a 16 kg (35 lb.) pail (AH80490).

2. Coat only one side of each thrust washer (A) with corn head grease and place greased side of each washer against each side of input shaft gear (B). The grease is used to hold the thrust washers against the gear for ease of installation. The lugs on the washers fit between the gear teeth.



H30706 -UN-05DEC91

3. Install input shaft with thrust washers in gearcase.


IMPORTANT: Turn input shaft to be certain lugs on both thrust washers fit between teeth on input gear.

1401,10010,C6 -19-12SEP91

4. Install input cap (A) and gaskets (B) and secure with hardware previously removed.

NOTE: Input cap can be installed only one way.

5. Visually check that thrust washer lugs are in gear teeth. Check end play of input shaft; end play should be 0.13 to 0.38 mm (0.005 to 0.15 in.). End play must not exceed 0.38 mm (0.15 in.) Bump ends of shaft with rubber hammer to check. Input shaft must rotate freely. Add or remove gaskets as necessary to achieve proper end play.



H30707 -UN-05DEC91


NOTE: Always use at least one, but no more than six, gaskets.

6. Install seal (C) with seal drives (D).

TM1581,HX100,AO-19-03OCT94

7. Assemble idler gear (A) and shaft (B) in gearcase. Install new tolerance ring (C) on shaft prior to assembly. To facilitate assembly, insert gear through opening in front of gearcase; then insert shaft.


NOTE: Start end of idler shaft (without tolerance ring) into bore first.



TM1581,HX100,AP-19-03OCT94


8. Assemble tools (A, B and C) to install expansion plugs (D), above.

- A—JDC400-7 Handle
- B—JDC400-2 Plug Installer
- C—10020 Screw



TM1581,HX100,AQ-19-03OCT94

9. Center idler shaft in bores and install both expansion plugs. Use tools illustrated to install plugs.




TM1581,HX100,AR-19-03OCT94

10. Coat gatherer bevel gears with corn head grease on flange surface only. Place bevel gears in gearcase. Install snap ring on one end of countershaft and insert countershaft through only the first bevel gear in the case.

11. Insert stalk roll drive gear assembly through opening in front of gearcase. Pass countershaft through stock roll gear assembly and bevel gears. Insert other snap ring on end of countershaft.

- A—Stalk Roller Drive
- B—Gear Assembly
- C—Snap Ring




H30711 -UN-05DEC91

TM1581,HX100,AS-19-03OCT94

12. Leave NEW shafts dry, or clean OLD shafts. Assemble gatherer drive shafts in gatherer caps. Be certain shafts bottom in caps. Tap on shafts and turn to be certain they are free. Recheck end play.

IMPORTANT: With gatherer drive shafts turning toward each other (as viewed from barrel assembly opening), oil slinger springs must throw grease away from gears and toward bronze bushings for efficient lubrication. Shafts should be reinstalled on same side of case to maintain proper gear wear. The spring for the right-hand shaft has a left-hand spiral and spring for left-hand shaft has a right-hand spiral. For repairs, right-hand spiral springs are colored RED and the left-hand spiral springs are colored BLUE.



H30712 -UN-05DEC91


- A—L.H. Gatherer Drive Shaft with Gear
- B—R.H. Gatherer Drive
- C—R.H. Spiral Oil Slinger Spring
- D—L.H. Spiral Oil Slinger Spring

TM1581,HX100,AT-19-03OCT94

13. Install both shafts (A), caps (B) and gaskets (C) dry (without grease) and tighten cap screws securely. Check gatherer drive shafts for proper backlash, 0.20 to 0.36 mm (0.008 to 0.014 in.).

14. Add or remove gaskets as necessary to achieve proper backlash. Tap end of shaft to make certain it is bottomed in cap.

NOTE: Gaskets are available in two thicknesses, 0.18 to 0.25 mm (0.007 and 0.010 in.).



100
10
37

H30713 -UN-05DEC91


TM1581,HX100,AU-19-03OCT94

15. After obtaining proper backlash, remove gatherer caps and shafts and coat gatherer cap bushing and shaft with John Deere Corn—Head Lube.

16. To be certain everything turns fully, turn input shaft by hand when all parts are assembled.

17. Coat shoulders of gatherer caps and gaskets with Permatex (A) and install in gearcase. Coat threads of cap screws with Permatex and install and tighten to 45 N·m (35 lb-ft).

18. Pack gatherer shaft and input shaft seals with corn head grease and install on shafts (B). Be careful NOT to cut lips of seal on groove of shaft. Cover grooves with tape.




H30714 -UN-05DEC91

TM1581,HX100,AV-19-03OCT94

19. Coat edges of end caps (A) with Permatex (B) and tap end caps into gearcase. Be certain caps are securely seated in gearcase.

20. This completes the disassembly and assembly of the gearcase. If work is not required on the barrel assembly and stalk roll shaft, see "Attaching Barrel Assembly to Gearcase" for assembly of these parts to the gearcase.

21. If work is required on the barrel assembly and stalk roll shafts, proceed on the following pages.



H30715 -UN-05DEC91

TM1581,HX100,AW-19-03OCT94

SERVICING BARREL ASSEMBLY AND STALK ROLL SHAFTS


Disassembly

NOTE: If only the barrel assembly and/or stalk roll shafts are to be serviced, remove barrel assembly with shafts from gearcase. Set gearcase assembly to one side and cover opening to keep dirt out of gearcase.

The slip clutch does NOT need to be removed.

1. Hold barrel assembly (A) and tap stalk roll shafts (B) on a solid surface to separate shafts from barrel assembly.
2. Clean all grease off stalk roll shafts and gears and out of barrel assembly.
3. Remove seal from end of barrel and discard.

NOTE: Use NEW SEALS after installing barrel assembly on gearcase.




H30716 -UN-05DEC91

HX,1401,10010AK-19-16DEC92

INSPECTION AND REPAIR

- 1—Grease Seal
- 2—Needle Bearing
- 3—Barrel
- 4—Gasket
- 5—Bearing
- 6—Stalk Roll Shaft




H30717

1401,10010,D8 -19-12SEP91

-UN-26AUG91
H30717

100
10
39

1. Examine stalk roll shaft (A), gear (B) and bearing (C) for wear. If it is necessary to remove bearing, use a split puller (D) as illustrating and press bearing off shaft. Install new bearing with a press. Be sure to seat inner face of bearing against gear hub.




H30718

1401,10010,D9 -19-12SEP91

-UN-05DEC91
H30718

2. Measure the stalk roll shaft at surfaces specified. If measurements are below the given dimensions or shaft has signs of wear, replace the shaft.

- A—31.47 mm (1.239 in.)
- B—81.30 mm (3.20 in.)
- C—76 mm (2.99 in.)
- D—189.4 mm (7.46 in.)
- E—31.72 mm (1.249 in.)




-UN-01MAY94
H46413

TM1581,HX100,CS-19-18AUG94

100
10
40

3. Assemble tool for removing bearing and seal in barrel assembly.


- A—JDC400-7 Handle
- B—27502, 1-3/16 in. Disk
- C—27507, 1-1/2 in. Disk
- D—10020 Screw



-UN-05DEC91
H30719

HX1581,10010,AA-19-03OCT94

4. Use tool (D) and drive out needle bearing (A) and seal (B) in barrel assembly (C).




-UN-05DEC91
H30720

TM1581,HX100,CU-19-18AUG94

40 Series Corn Heads/Attaching Barrel Assembly to Gearcase

5. Assemble tool for installing bearing in assembly.

- A—JDC400-7 Handle
- B—27515, 2 in. Disk
- C—JDC400-8 Spacer
- D—27502, 1-3/16 in. Disk
- E—10020 Screw




HX1581,10010,AB-19-03OCT94

6. Use tool (B) to install needle bearing in barrel assembly. Be certain to drive against flat end of needle bearing only.

NOTE: Do NOT install seals until after barrel assembly (A) with stalk roll shafts has been attached to gearcase. Coat needle bearings with Corn-Head grease.

7. Install stalk roll shafts in barrel assembly and strike on ends of gear with a lead hammer to seat shaft bearing shafts on barrel assembly. Rotate shafts. They must turn freely.




TM1581,HX100,CW-19-18AUG94

ATTACHING BARREL ASSEMBLY TO GEARCASE

1. With gearcase assembly (A) mounted in a vise, insert the two barrel assembly locating dowel studs (B) in upper corner holes as illustrated. (See "Special Tools".)

2. Assemble new gasket (C) over locating dowel studs and set barrel assembly (D) with shafts on studs.




HX,1401,10010AP-19-16DEC92

40 Series Corn Heads/Attaching Barrel Assembly to Gearcase

3. Install stalk roll shaft timing tool (A) (see Special Tools) on end of shafts. Use 1/2 x 1-3/4 in bolts (B) or 1/2 in. rods to secure timing tool to shafts. It is not necessary to put nuts on the bolts.

4. Push against stalk roll shafts and barrel assembly. If inner surface of barrel assembly will not fit tight against surface of gearcase (C), stalk roll shafts are not properly timed and must be timed.



-UN-05DEC91

H30724

1401,10010,E6 -19-12SEP91


5. Grasp stalk roll shafts and pull barrel assembly away from gearcase about 25 mm (1 in.), remove one bolt from timing tool (A) and rotate one stalk roll shaft 180 degrees. Reinstall bolt and check to be certain barrel assembly is flush (B) against gearcase.

NOTE: If the fit is still not tight, repeat above procedure, rotating other stalk roll shaft.

6. When barrel assembly fits tight against gearcase, secure assembly with four bolts and check stalk roll backlash by holding one shaft and rotating the other. Backlash should be 0.20 to 0.36 mm (0.008 to 0.014 in.). Add or remove gaskets as necessary to obtain proper backlash.

NOTE: Gaskets are available in two thicknesses, 0.18 to 0.25 mm (0.007 to 0.010 in.). Rotate shafts to check for tight spots.

7. When proper backlash has been obtained, remove barrel assembly and pack around gears and in barrel with John Deere Corn-Head Lube™, or equivalent. Use four ounces of grease to each barrel, total 56 ounces for the gearcase. After filling gearcase, pump grease through grease fitting while turning by hand.




-UN-05DEC91

H30725

1581,10010,ZE -19-03OCT94


40 Series Corn Heads/Attaching Barrel Assembly to Gearcase

8. Install barrel assembly and secure with hardware previously removed (A). Coat the two special dowel bolts (B) with Permatex and install in lower corners of barrel assembly. Tighten all bolts.



1401,10010,E8 -19-12SEP91

9. Using tool (C), install seals (A) on ends of barrel assembly (B) over stalk roll shaft. Use tape over all spring pin holes to avoid cutting seal. Also, be certain seal spring does not rotate out of seal during installation.



HX,1401,10010AR-19-16DEC92

INSTALLATION

1. Remove special mounting bracket from gearcase and install gearcase on corn head.
2. Reverse removal procedure to install gearcase, stalk rolls, row-unit frame, gatherer chains, gatherer shields and associated parts.
3. Adjust gatherer chains, trash knives and deck plates as outlined.
4. Tighten trash knife bolts and stalk rolls clamping bolts to specified torques.
5. After complete assembly and installation of the corn head gearcase and component parts, with corn head attached to combine, start engine and engage corn head drive.
6. Operate corn head with gatherer points on the ground at low idle speed for four minutes.
7. Increase combine engine to fast idle and run corn head for six minutes.



CAUTION: Shut off combine engine.

8. Check for hot bearings and lubricate. Correct as necessary.

HX,1401,10010AS-19-16DEC92


ROW UNIT SLIP CLUTCH

General Information

The slip clutches protect the corn head drives. Each row unit drive and the auger drive have a slip clutch.

TM1581,HX100,AZ-19-03OCT94

40 Series Corn Heads/Assembly



- | | | | |
|---|-----------------|-------------------------------------|--|
| 1—Coupler | 4—Bushing | 10—Spring Retainer | 14—Cap Screw,
3/8 x 3-3/4 in.
(2 used) |
| 2—Cap Screw,
1/2 x 5-3/4 in.
(4 used) | 5—Retainer | 11—Spacer (4 used) | 15—Internal Tooth Lock
Washer, 1/2 in. (4 used) |
| 3—Jam Nut, 1/2 in.
(8 used) | 6—Thrust Washer | 12—Nut, 3/8 in. (2 used) | |
| | 7—Hub | 13—Lock Washer, 3/8 in.
(2 used) | |
| | 8—Jaw | | |
| | 9—Spring | | |

HX,1401,10010AT-19-16DEC92

REPAIR

Remove two 3/8 x 3-3/4 in. cap screws (14) to remove slip clutch. Refer to the above illustration for disassembly.

Inspect hub (7) and jaw (8) for wear. Inspect spring (9) for breakage. Inspect all other parts and replace parts as necessary.

HX,1401,10010AU-19-16DEC92

ASSEMBLY

Use the exploded view (See "Row Unit Slip Clutch") as a guide when assembling shift clutch.

1. Coat entire thrust washer (6) with multipurpose grease prior to assembly. Do not grease facing of hub (7) and jaw (8).

2. Reassemble slip clutch.


HX,1401,10010AV-19-16DEC92

40 Series Corn Heads/Assembly

3. Tighten four cap screws in slip clutch to obtain a 71 mm (2-13/16 in.) dimension (A).

NOTE: The auger slip clutch is non-adjustable.


4. Do NOT tighten the nuts on the four cap screws to the point where the clutch will NOT slip. Jam the two nuts on each cap screw together and then tighten to 75 N·m (7.5 kg) (55 lb-ft) torque.



HX,1401,10010AW-19-16DEC92

H33378 -UN-25OCT89

- | | |
|----------------------------------|-----------------------------------|
| 1—Snap Ring | 9—Locking Collar |
| 2—Shield | 10—Lock Washer, 1/2 in. (4 used) |
| 3—Rivet, 5/16 x 1/2 in. (2 used) | 11—Bolt, 1/2 x 1-1/4 in. (4 used) |
| 4—Nut | 12—Support |
| 5—Shield | 13—Self-Tapping Screw (3 used) |
| 6—Support | |
| 7—Housing (2 used) | |
| 8—Bearing | |




HX,1401,10010AX-19-03OCT94

H44873 -UN-06AUG92

100
10
46

MAIN DRIVE SHAFT AND COUPLER

443, 444, 546, 642, 643, 644, 645,
 842, 843, 844 AND 1243 (SN —635100)
 543 (SN —380600) (62081—635100)
 642 AND 842 (SN —332700)




- | | | | |
|--------------------------------------|---|-----------------------------------|-----------------------------------|
| 1—Nut, 3/4 in. | 6—Bearing | 11—Shaft | 14—Link Chain (2 used) |
| 2—Cotter Pin,
5 x 50 mm | 7—Housing | 12A—Cap Screw, 1/2 x 2-1/2
in. | 15—Sprocket, 14 Tooth
(2 used) |
| 3—Washer,
25/32 x 1-5/8 x 1/4 in. | 8—Holder | 12B—Snap Ring | 16—Ball (6 used) |
| 4—Sprocket, 24 Tooth | 9—Bolt, 3/8 x 1 in. | 13A—Coupling | 17—Coupler (2 used) |
| 5—O-Ring (2 used) | 10—Lock Washer, 3/4 in.
(S.N. —416850) | 13B—Sprocket, 14 Tooth | 18—Snap Ring |

TM1581,HX100,BA-19-03OCT94

100
10
47

H44865 -JUN-06AUG92

MAIN DRIVE SHAFT AND COUPLER
443, 444, 546, 643, 644, 645, 843, 844 AND
1243 (SN 635001—)




- | | | | |
|----------------------|---------------------|------------------------|-----------------------|
| 1—Lock Nut, 3/4 in. | 8—Shaft | 15—Bearing | 20—Snap Ring |
| 2—Sprocket, 28 Tooth | 9—Shield | 16—Angle | 21—Chain |
| 3—Housing | 10—Bracket (2 used) | 17—Bracket | 22—Sprocket, 14 Tooth |
| 4—Bearing | 11—Housing (4 used) | 18—Bolt, 3/8 x 3/4 in. | 23—Ball (3 used) |
| 5—Retainer | 12—Shield | 19—Sprocket, 14 Tooth | 24—Coupler |
| 6—Seal | 13—Snap Ring | | 25—Snap Ring |
| 7—Bolt, 3/8 x 1 in. | 14—Shield | | |

H44866 -JUN-06/AUG92

HX,1401,10010AZ-19-03OCT94

**MAIN DRIVE SHAFT AND COUPLER
343**

- 1—Self-Locking
Screw (4 used)
- 2—Flange Nut (7 used)
- 3—Bracket
- 4—Cap Screw, 1/2 x 1 in.
- 5—Washer, 17/32 x 15/16 x
0.060 in.
- 6—Housing
- 7—Bearing
- 8—Bolt, 3/8 x 3/4 (3 used)
- 9—Shield
- 10—Nut (2 used)
- 11—Rivet, 5/16 x 1/2 in.
(2 used)
- 12—Shield
- 13—Snap Ring




HX,1401,10010BA-19-28JAN93

H44872 -UN-06AUG92

100
10
49

**MAIN DRIVE SHAFT AND COUPLER
344**



- | | | | |
|---|--|--|--|
| <ul style="list-style-type: none"> 1—Screw, 3/8 x 3-3/4
(3 used) 2—Cotter Pin, 5 x 50 mm 3—Nut, 3/4 in. 4—Washer, 25/32 x 1-5/8 x
1/4 in. 5—Sprocket, 24 Tooth | <ul style="list-style-type: none"> 6—O-Ring 7—Housing (4 used) 8—Bearing (2 used) 9—Bushing 10—Washer, 3/4 in.
(S.N. —416850) | <ul style="list-style-type: none"> 11—Spring Pin, 3/16 x 1-3/4
in. 12—Spring Pin, 5/16 x 1-3/4
in. 13—Shaft 14—Chain | <ul style="list-style-type: none"> 15—Sprocket, 14 Tooth 16—Ball 17—Quick Coupler 18—Snap Ring 19—Shield, L.H. 20—Screw (2 used) |
|---|--|--|--|

HX,1401,10010BB-19-16DEC92


H44867 -UN-06AUG92

MAIN DRIVE SHAFT AND COUPLER

444 (R.H. AND L.H.) (—466450)

444 (R.H.) (466451—600000)

444 (R.H. AND L.H.) (600001—640500)



H44868 -JUN-06AUG92

- 1—Nut
- 2—Washer, 25/32 x 1-5/8 x 1/4 in. (S.N. —630300)
- 3—Sprocket, 24 Tooth (S.N. —620350)
Sprocket, 28 Tooth (S.N. 620351—)
- 4—O-Ring (S.N. —630300)


- 5—Bearing (2 used)
- 6—Housing (4 used)
- 7—Decal, "Danger"
- 8A—Guard
- 8B—Shield
- 9—Self-Locking Screw
- 10—Self-Locking Screw
- 11A—Bracket (S.N. —383768)

- 11B—Bracket
- 12—Spacer, 3/8 x 2 in. (3 used) (S.N. —383768)
- 13—Lock Washer, 3/4 in. (S.N. —416850)
- 14—Shaft

- 15—Bolt, 3/8 x 3-1/4 in.
- 16—Cotter Pin, 5 x 50 mm (S.N. 516351—630300)
- 17—Seal (S.N. 46650—)
- 18—Retainer (S.N. 46650—)

HX,1401,10010BC-19-16DEC92

MAIN DRIVE SHAFT AND COUPLER
643 (—640500)




- | | | | |
|---------------------------------------|-------------------------------------|---|----------------------------|
| 1—Shield | 8—Holder (S.N. —630300) | 12—Washer, 25/32 x 1-5/8 x 1-1/4 in. (S.N. —630300) | 16—Support |
| 2—Bolt, 5/16 x 3/4 in. | 9—Bolt, 3/8 x 1 in. (3 used) | 13—Cotter Pin (S.N. 516351—630300) | 17—Screw |
| 3—Housing (4 used) | 10—O-Ring (S.N. —630300) | 14—Nut, 3/4 in. | 18—Decal, "Danger" |
| 4—Bearing (2 used) | 11—Sprocket, 24 Tooth (S.N. 620504) | 15—Self-Locking Screw (2 used) | 19—Shield |
| 5—Bolt, 3/8 x 3/4 in. (3 used) | Sprocket, 28 Tooth (S.N. 620505—) | | 20—Seal (S.N. 46650—) |
| 6—Shaft | | | 21—Retainer (S.N. 46650—) |
| 7—Lock Washer, 3/4 in. (S.N. —416850) | | | |

H44869 -JUN-06AUG92

HX,1401,10010BD-19-16DEC92

STUBBLE LIGHT BULB REPLACEMENT

- Remove nut securing housing (A).
- Unscrew housing from base.
- Push AD2062R (1156) bulb in and turn to remove.



H42849

H42849 -JUN-29NOV90

TM1581,HX100,CX-19-18AUG94


HEADER WARNING LIGHT BULB REPLACEMENT

Remove nuts (A).

Remove shield (B).

Unscrew housing (C) from bulb base.

Push AD2062R (1156) bulb in and turn to remove.



100
10
52

Group 15
90 Series Corn Heads

TORQUE VALUES

	Torque N·m (Lb-Ft.)
Countersunk head cap screws by gathering chain sprockets	110 N·m (80 lb-ft.)
Gatherer chain guide cap screws	95 N·m (70 lb-ft.)
Trash knife cap screws	95 N·m (70 lb-ft.)
Idler support block cap screws	95 N·m (70 lb-ft.)
Fluted stalk roll class 10.9 cap screws	140 N·m (100 lb-ft.)
Knife stalk roll:	
Casting to shaft	40 N·m (30 lb-ft.)
Front knife cap screws	80 N·m (60 lb-ft.)
Rear knife cap screws	40 N·m (30 lb-ft.)
Eargate cap screws	20 N·m (15 lb-ft.)
Deckcover wear plate	20 N·m (15 lb-ft.)
Cover locking angle	20 N·m (15 lb-ft.)

1581,10015,ZT -19-03OCT94

SPECIAL TOOLS

The following JDC400 series tools are required to properly service the corn head gear case. They are not offered as a complete set, but must be ordered individually. In addition, some of the various drivers in D01045AA Driver Set are also required for use with the JDC400 series tools.

HX,1401,10010,A-19-03OCT94

Number: *JDC400-1 Seal Installer
Use: To install gatherer shaft seals.

H45090 -UN-08SEP92




HX,1401,10010CC-19-03OCT94

90 Series Corn Heads/Special Tools

Number: *JDC400-2 Plug Installer
Use: To install expansion plugs.

H45091 -UN-08SEP92



HX,1401,10010CD-19-03OCT94

Number: *JDC400-3 Spacer
Use: To install gatherer drive shaft bushings.

H45092 -UN-08SEP92



HX,1401,10010CE-19-03OCT94

Number: *JDC400-4 Spacer
Use: To install input shaft needle bearing.


H45093 -UN-08SEP92



HX,1401,10010CF-19-03OCT94

Number: *JDC400-5 Seal Installer
Use: To install barrel seals.

H45094 -UN-08SEP92



HX,1401,10010CG-19-03OCT94

100
15
2

90 Series Corn Heads/Special Tools

Number: *JDC400-6 Seal Driver
Use: To install input shaft seal

H45095 -UN-08SEP92



*Order from:
Service Tools, Box 314, Owatonna, MN 55060

HX,1401,10010CH-19-03OCT94

Number: *JDC400-7 Handle
Use: Used with various drivers and spacers.

H45096 -UN-08SEP92



HX,1401,10010CI-19-03OCT94

Number: *JDC400-8 Spacer
Use: To install barrel bearings.

H45097 -UN-08SEP92



HX,1401,10010CJ-19-03OCT94

Number: *JDC400-10 Stalk Roll Timing Tool
Use: To set correct timing of stalk rolls.

H45099 -UN-08SEP92



HX,1401,10010CL-19-03OCT94

90 Series Corn Heads/Making Special Tools

Number: *D01045AA Master Bushing and Seal Driver Set

Use: Some of the drivers in this set are required for use with JDC400 series tools.

Number: *D01046AA Tool Organizer Board

Use: Keeps D01045AA set components in proper order and safe from loss. Tools not included.

Number: *JDG450 Mechanical Puller or JDG610 hydraulic puller

Use: To pull stalk rolls (not shown).

*Order from:

Service Tools, Box 314, Owatonna MN 55060




H36476 -UN-16JUN89

HX1581,10015,FA-19-03OCT94

MAKING SPECIAL TOOLS

In addition to the JDC400 series tools, the following tools can be made in the dealer shop for servicing the corn head gear case.

- A—Gear Case Support
- B—Locating Dowel Studs
- C—Timing Tool




H30650 -UN-15JUN89

HX,1401,10010,C-19-03OCT94

The gear case support bracket is used for mounting the gear case in a vise. Make it from 6.4 mm (1/4 in.) steel plate.

- A—203 mm (8 in.)
- B—152 mm (6 in.)
- C—Two Holes,
13 mm (17/32 in.) dia.
- D—25 mm (1 in.)
- E—25 mm (1 in.)
- F—51 mm (2 in.)



H30651


100
15
5

-UN-10OCT88
H30651

HX,1401,10010,D-19-16DEC92

Barrel assembly locating dowel studs are used to assist in mounting the barrel assembly on the gear case. Make two studs by cutting off the heads of two 19H2530 3/8 x 3 in. cap screws.

- A—76 mm (3 in.)
- B—9.6 mm (3/8 in.)




H30652

-UN-10OCT88
H30652

HX,1401,10010,E-19-16DEC92

If the JDC400-10 tool is not available, a stalk roll timing tool can be made.

- A—37 mm (1-7/16 in.)
 - B—32 mm (1-9/32 in.)
 - C—102 mm (4 in.)
 - D—25 mm (1 in.)
 - E—25 mm (1 in.)
 - F—51 mm (2 in.)
 - G—Weld
 - H—152 mm (6 in.)
 - I—37 mm (1-7/8 in.)
 - J—24 mm (15/16 in.)
 - K—3 mm (1/8 in.)
 - L—13 mm (17/32 in.)
- Diameter Holes. Time as shown.



H30653

-UN-10OCT88
H30653

HX,1401,10010,F-19-03OCT94

Wood Gauge

A-Front



B-Rear

Metal Gauge

A-Weld

B-Do Not Weld

If the JDC400-9 gauge is not available, a gauge for deck plate spacing can be made from wood or metal.



HX1581,10015,CA-19-03OCT94


GENERAL INFORMATION

As the combine moves through the field, the gatherer points are positioned between the rows of corn. The stalk rolls pull the corn stalks down so the ear will be snapped on the deck plates. Trash knives prevent weeds and trash from wrapping around the stalk rolls. The gatherer chains catch the ears and move them up to the auger. The auger then moves the ears to the front of the feeder house where the rubber paddles feed the ears into the feeder house.

TM1581,10015,C -19-03OCT94

REMOVE AUGER

1. Loosen cap screws (A) and rotate header warning light (B) rearward.



TM1581,10015,D -19-03OCT94

2. Remove spring locking pin (A) securing rear of end fenders to support.




HX1581,10015,G -19-03OCT94

3. Raise point and remove quick-lock pin (A).


CAUTION: Outer point and shield is heavy and awkward to handle.

4. Raise point and shield and slide shield off of hinge pins.

5. Lift end fender and point assembly off of row unit.



-UN-22JUL93
H45834




-UN-10FEB94
H46184

TM1581,10015,F -19-03OCT94

To remove:


6. Remove row unit drive shaft shield (A).

7. Turn auger by hand and disconnect auger drive chain (B). Wedge auger securely by placing a wood block under auger, aligning at each end.



-UN-26AUG91
H43763

TM1581,10015,G -19-03OCT94



H43765

-UN-26AUG91
H43765


8. Remove nut (A) and washer (B). Disconnect and remove chain on sprocket (F).

9. Remove cap screws (G), housings (D) and bearing (E) on left-hand end of auger.

10. Use a safe hoist and remove by lifting right-hand end of auger up and out of corn head first. Complete removal by swinging auger out and over center shields.

Inspect all parts for damage or excessive wear and replace as required.

- A—Nut, M20 (8 used)
- B—Washer, Lock, 3/4 in. (8 used)
- C—Washer, 25/32 x 1-5/8 x 0.180 in. (8 used)
- D—Housing (4 used)
- E—Bearing (2 used)
- F—Sprocket
- G—Bolt, M10 x 20 (8 used)
- H—Strap
- I—Paddle
- J—Strap
- K—Bolt, M10 x 20 (3 used)
- L—Auger



H43764

-UN-26AUG91
H43764


TM1581.10015.H -19-03OCT94

ASSEMBLY AND INSTALLATION

1. Reinstall in reverse order.

IMPORTANT: Be certain to place hub side of sprocket against the auger to insure sprocket alignment.

2. Install row unit drive shaft shield (A).
3. Install right-hand outer gatherer sheet and point.




TM1581,10015,1 -19-03OCT94

H41465 -UN-20NOV89

4. Both sides of the corn head main frame and auger bearing carriers (A) are slotted for adjusting the auger. The auger can be adjusted up and down and fore and aft for proper clearance with bottom of feed bed.

5. Keep the auger adjusted down and to the rear as far as possible in normal dry conditions. In damp, sticky or heavy trash conditions, adjust the auger up and forward to move material away from the row unit.

6. In normal conditions, keep a minimum of 6 mm (1/4 in.) clearance between auger and auger stripper.



1581,10015,ZH -19-03OCT94

H42846 -UN-29NOV90



100
15
10

ROW UNIT FRAME, GATHERER CHAINS, TRASH KNIVES AND DECK PLATES

CAUTION: Never run corn head with center shields raised or removed. Always shut off engine before leaving machine.


1. Loosen cap screw (A) on the rear of the gatherer shield and raise stop (B) to the vertical position.

NOTE: Do not torque bolt (A) over 20 N·m (15 lb-ft).



HX1581,10015,H -19-03OCT94

2. Raise the point and remove quick-lock pins (A).




TM1581,10015,K -19-03OCT94

3. Lift the point and gatherer shield.
4. Slide the gatherer shield to the right until the shield is free of support pins (A).


! CAUTION: The center shield and point assembly is heavy and awkward to handle.

5. Lift off point and gatherer shield assembly.



TM1581,10015.L -19-03OCT94

6. Loosen cap screws (A) and rotate header warning light (B) rearward.




TM1581,10015.M -19-03OCT94

7. Lift the point and gatherer shield.

8. Slide the gatherer shield to the right until the shield is free of support pins (A).


CAUTION: The center shield and point assembly is heavy and awkward to handle.

9. Lift off point and gatherer shield assembly.



TM1581,10015,N -19-03OCT94

10. Loosen cap screws (A) and rotate header warning light (B) rearward.



TM1581,10015,O -19-03OCT94

11. Remove spring locking pin (A) securing outer gatherer shield to support.



TM1581,HX100,DC-19-18AUG94



100
15
14

12. Raise point and remove quick-lock pin (A).

⚠ CAUTION: Outer point and shield is heavy and awkward to handle.

13. Raise point and shield and slide shield off of hinge pins.

14. Lift outer gatherer shield and point assembly off of row unit.



TM1581,10015,Q -19-03OCT94



CAUTION: Never service any part of the gatherer chain mechanism or idler sprocket until nut (G) is tight against the leg of the idler support strap.

15. Loosen nut (D).
16. Relieve gatherer chain tension by turning nuts (G) until it is against the leg of the idler support strap.
17. Loosen bolt (F) until tension is off gatherer chain and tube (E).
18. Remove bolts (C). This will allow the idler sprocket to move back so the gatherer chain (B) can be removed.

NOTE: If idler sprocket will not slide back, remove entire idler assembly and clean idler support strap and the slot in the idler support bracket.

19. Remove chain (B) from sprocket (A).

- A—Sprocket
- B—Chain
- C—Bolts
- D—Nut
- E—Tube
- F—Bolt




TM1581.10015.R -19-03OCT94

20. Remove idler sprocket (A), idler support (B), idler support strap (C), idler stop (D), spring (E), flat washer (F) and machine bolt (G).

21. Remove two cap screws (H) and flat washers (I), attaching chain guide (J) to row unit frame (K).

22. Remove deck plate (L).




TM1581,10015,S -19-03OCT94

H46402 -UN-11MAY94

23. Remove snap ring (A) and remove drive sprocket (B).

24. Remove countersunk head cap screws (C) and deflectors (D).



TM1581,10015,T -19-03OCT94


H30675 -UN-05DEC91

25. Remove attaching cap screws (A) and remove trash knives.

CAUTION: Approximate weight of row unit frame is 23 kg (50 pounds); use two people to remove it from the corn head.

26. Remove four row unit attaching cap screws (B) and lift row unit frame off stalk rolls and gearcase.

NOTE: Refer to "Gear Case Removal" for information concerning removal, service and installation.



H46408 -UN-01MAY94

TM1581,10015,U -19-03OCT94

INSPECTION AND REPAIR

Inspect all parts removed from the row unit frame for damage and excessive wear. Replace parts as necessary.

1401,10010,L -19-12SEP91

ASSEMBLY AND INSTALLATION


1. Install gear case if it has been removed for service. Refer to Gearcase Removal in this Section.

2. Install stalk rolls on gear case. Refer to Gearcase Removal in this Section.

3. Install row unit frame with four countersunk head cap screws (C). After all cap screws are installed, tighten to 110 N·m (80 lb-ft) torque.

4. Install deflectors (D).

5. Install drive sprockets (B) on hex shafts and secure with snap rings (A).




H30675 -UN-05DEC91

HX1581,10015,J -19-03OCT94

6. Install deck plates (L) and chain guides (J) with flat washers (I) and cap screws (H). Do not tighten cap screws at this time. See Adjusting Deck Plates.

7. Install machine bolt (G), flat washer (F), spring (E), idler stop (D), idler support strap (C), idler support (B) and idler sprocket (A).



100
15
19

H466402 -UN-11MAY94

HX1581,10015,K -19-03OCT94

ADJUSTING DECK PLATES AND GATHERER CHAIN GUIDES

The deck plates (A) snap ears from the stalks as the stalks are pulled down by the stalk rolls (B).


The corn head is shipped from the factory with the deck plates spaced 30 mm (1-3/16-in.) apart at the front and 32 mm (1-1/4-in.) apart at the rear to cover most conditions. The deck plates can be adjusted for different varieties of corn and varying field conditions.

To minimize the amount of trash and stalk intake, the deck plates must be open as far as possible without causing shelling.

1. Raise the center shields.
2. Loosen four bolts (C) on both deck plates.
3. Position deck plates so the center space between the edge of the deck plates is located over the center space between the stalk rolls (B).
4. Adjust gatherer chain guides (D) in until they are just touching the gatherer chains.
5. Torque bolts (C) on guides and deck plates to 95 N-m (70 lb-ft).

NOTE: Deck plates must be spaced 1.5 to 2 mm (1/16- to 5/64-in.) wider apart at the rear than at the front.

IMPORTANT: The center of space (E) between deck plates must be located over the center of space (E) between stalk rolls.




- A—Deck Plates
- B—Stalk Rolls
- C—Bolts
- D—Gatherer Chain Guide
- E—Center Line

TM1581,10015,W -19-03OCT94

A gauge for deck plate spacing can be made from wood or metal.

- A—Front
- B—Rear



Wood Gauge

CRNHD,90OCH,AD -19-14SEP93

ROW UNITS


The row unit houses the trash knives, gathering chains, deck plates, and stalk rolls. Ears of corn are snapped from the stalk and conveyed to the auger by the row unit. Row unit speed and combine travel speed are directly related.

CRNHD,900CH,AA -19-14SEP93

100
15
21

ADJUSTING TRASH KNIVES

1. Trash knives (A) prevent weeds and trash from wrapping around stalk rolls (B).
2. Knives must be set as close as possible to the rolls without striking the flutes.
3. Loosen knife attaching bolts (C) and adjust each trash knife to a maximum of 1.5 mm (1/16-in.) of the highest flute on the stalk roll. Torque bolts to 95 N·m (70 lb-ft).




TM1581,10015,X -19-03OCT94

STALK ROLLS

To remove:

⚠ CAUTION: Lower hydraulic cylinder safety stop before working under corn head.


1. Remove trash knives (A) from underside of row unit frame.
2. Remove stalk roll (B) from shafts by driving out double spring pins (C) and removing class 10.9 cap screws (D). Clean out slots in stalk rolls to permit installing puller.



H46409
-UN-01MAY94

TM1581,10015,Y -19-03OCT94

3. Use JDG450 puller (3) or JDG610 hydraulic puller to pull stalk roll off gear case shaft.



H25654
-UN-05DEC91

TM1581,10015,Z -19-03OCT94

INSPECTION

Inspect stalk rolls for wear or damage. Stalk rolls are available as service parts.

TM1581,10015,AA-19-03OCT94

INSTALLATION


1. Clean stalk roll shaft and outside of barrel. Coat shaft with grease before sliding on new roll.

NOTE: The spirals on the FRONT rotate to move material to the rear of the stalk roll. The flutes turn down and toward the opposite stalk roll.

2. Secure stalk roll (B) to shaft with double spring pins (C) and two class 10.9 cap screws (D). Tighten cap screws to 150 N·m (110 ft-lbs.).

IMPORTANT: If stalk roll cap screws are replaced, use only 19M7361 M12 x 50 class 10.9 cap screws.

3. Refer to "Adjusting Trash Knives" and adjust the trash knives (A).



H46409 -UN-01MAY94

TM1581,HX100,DF-19-18AUG94


KNIFE STALK ROLLS

CAUTION: Keep hands and feet away from stalk rolls.

Knife Stalk Rolls (Optional) The stalk roll knives (C) are attached to the stalk roll casting with M8 x 55 cap screws and M10 x 16 cap screws (D). Torque M8 cap screws to 40 N·m (30 lb-ft). Torque M10 cap screws to 80 N·m (60 lb-ft).

The stalk roll castings (E) are attached to the shaft with M10 x 30 six lobe head screws and a double spring pin. Torque M10 screws to 40 N·m (30 lb-ft).

IMPORTANT: Check after first eight to twelve hours of operation when corn head is new or when stalk rolls are replaced.



Knife Stalk Rolls (Optional)

100
15
24


H45859
-UN-14SEP93

TM1581,HX100,DG-19-18AUG94

ADJUSTABLE DECK PLATES REMOVE ADJUSTABLE DECK PLATES

1. Remove two M12 x 65 cap screws (A) from left-hand idler support (B).
2. Remove gatherer chain from left-hand side of row unit.
3. Remove idler support (B) and chain tensioner assembly from row unit.
4. Remove two M12 x 50 cap screws (C) with washers from chain guide (D).
5. Remove chain guide.
6. Remove cover plate (E).
7. Remove deck plate (F).
8. Remove slide (G).
9. Clean and inspect parts. Replace as necessary.

- A—Cap Screws, M12 x 65
(2 used)
- B—Idler Support
- C—Cap Screws, M12 x 50
(2 used)
- D—Chain Guide
- E—Cover Plate
- F—Deck Plate
- G—Slide



HX1581,10015,AA-19-03OCT94


100
15
25

H46694 -UN-18SEP94

INSTALL ADJUSTABLE DECK PLATES

1. Be sure ALL parts are clean and free of dirt and trash.
2. Place slide (G) on left-hand row unit leg. Align holes.
3. Install deck plate on row unit on top of slide (G). Pins of plate must engage ears of pivot arm.
4. Install spacer plate (E) with tabs down through slots in deck plate (F) to slide (G).
5. Install chain guide (D) with two M12 x 50 cap screws and washers (C).
6. Install gatherer chain and tightener.
7. Install idler support (B) and chain tensioner assembly to row unit with two M12 x 65 cap screws (A).
8. Torque bolts (C) and (A) to 95 N·m (70 lb-ft).

- A—Cap Screw, M12 x 65
(2 used)
- B—Idler Support
- C—Cap Screw, M12 x 50
(2 used)
- D—Chain Guide
- E—Cover Plate
- F—Deck Plate
- G—Slide



HX1581,10015,AB-19-03OCT94

H46694 -UN-18SEP94


100
15
26

ADJUSTABLE DECK PLATES, TIE BAR, PIVOT ARMS AND CYLINDER

REMOVE TIE BAR

1. Remove nut (A), washers (B) and spacer (C) from bolt (D).
2. Remove bolt (D) from clamp (E) on each row unit.
3. Spread each clamp (E) to slide clamp (E) on tie bar (F).


A—Nut
 B—Washers (2 used)
 C—Spacer
 D—Bolt
 E—Clamp
 F—Tie Bar



HX1581,10015,AC-19-03OCT94

4. Remove cotter pins (A) and drilled pins (B) from tie bar coupler (C).
5. Separate left-hand tie bar (D) and right-hand tie bar (E) from coupler (C).
6. Remove left-hand tie bar (D) and right-hand tie bar (E).

A—Cotter Pin
 B—Drilled Pin
 C—Coupler
 D—Left-Hand Tie Bar
 E—Right-Hand Tie Bar



HX1581,10015,AD-19-03OCT94

INSTALL TIE BAR

1. Install left-hand tie bar (A) and right-hand tie bar (B) through supports (C).

NOTE: Install clamps (D) loose on tie bars.

2. Connect tie bars (A) and (B); one on each row unit.


3. Install drilled pins (F) and cotter pins (G).

4. Retract deck plate hydraulic cylinder.

5. Install bolt (H) with washer (I), spacer (J), washer (I) and nut (K) through tie bar clamp (D) and pivot arm (L). Do NOT tighten at this time.

6. Close deck plates until 3 mm clearance is obtained between pivot arm (L) and row unit frame (M).

7. Tighten nut (K) until clamp (D) is closed tight.



- A—Tie Bar, Left-Hand
- B—Tie Bar, Right-Hand
- C—Support
- D—Clamps
- E—Coupler
- F—Pins, Drilled
- G—Pins, Cotter
- H—Bolt
- I—Washer
- J—Spacer
- K—Nut
- L—Pivot Arm
- M—Frame, Row Unit

HX1581,10015,AE-19-03OCT94

H46697 -UN-18SEP94


REMOVE PIVOT ARMS

1. Remove nut (A), washers (B), spacer (C) and bolt (D) from pivot arm (E) and tie bar clamp (F).

2. Remove M12 x 25 cap screws (G) from pivot arm support (H).

3. Remove pivot arm (E).

- A—Nut
- B—Washer
- C—Spacer
- D—Bolt
- E—Pivot Arm
- F—Clamp
- G—Cap Screw, M12 x 25
- H—Pivot Arm Support




HX1581,10015,AF-19-03OCT94

H46698 -UN-18SEP94

INSTALL PIVOT ARMS

1. Install pivot arms (E) on pivot supports (H).
2. Install four M12 x 25 cap screws (G) through pivot arm supports (H) onto row unit. Torque to 95 N·m (70 lb-ft).
3. Install washer (B) and spacer (C) on bolt (D). Place through large slot on pivot arm (E).
4. Install washer (B) on bolt and insert bolt through bar clamp (F).
5. Install nut (A) on bolt (D). Do NOT tighten at this time.
6. Adjust deck plate CLOSED and cylinder RETRACTED so that there is 3 mm clearance between pivot arm and row unit frame.
7. Tighten bolt (D) and nut (A) until clamp (F) is closed and tie bar is crimped by clamp (F).




- | | |
|-------------------|-----------------------|
| A—Nut | F—Clamp |
| B—Washer (2 used) | G—Cap Screw, M12 x 25 |
| C—Spacer | H—Pivot Arm Support |
| D—Bolt | |
| E—Pivot Arm | |

HX1581,10015,AG-19-03OCT94

REMOVE CYLINDER

1. Remove outer nut (A).
2. Remove hoses (B).
3. Remove nut (C) from cable and remove cable.
4. Remove bolt (D).
5. Remove cylinder (E) and coupler (F).




- | |
|------------|
| A—Nut, M20 |
| B—Hoses |
| C—Nut, M5 |
| D—Bolt |
| E—Cylinder |
| F—Coupler |

HX1581,10015,AH-19-03OCT94

INSTALL CYLINDER

1. Install cylinder rod (A) with jam nut through coupler (B).
2. Install M20 x 45 cap screw (C) through coupler (B).
3. With cylinder RETRACTED, adjust pivot arms to 3 mm clearance between pivot arm and row unit frame. Tighten nuts (D) on cylinder rod against coupler (B).
4. Install cable and secure with nut (E).
5. Install hoses (F) to fittings (G).



- A—Cylinder Rod
- B—Coupler
- C—Cap Screw, M20 x 45
- D—Nuts
- E—Nut
- F—Hoses
- G—Fittings

HX1581.10015.AI-19-03OCT94

H46704 -UN-22SEP94

GEARCASE


General Information:

On the 90 Series Corn Heads, each row unit is driven by its own gear-type drive. The drive is a fully enclosed case located under each row unit.

A row unit input shaft (A) is driven from the feeder house. This shaft drives the slip clutch (B), which in turn drives the input gear located in the gearcase.

This input gear drives an idler spur gear which drives the main countershaft (C). The main countershaft has two sets of bevel gears. The inner set, which consists of two bevel gears welded to the driving spur gear, drives the stalk roll shafts (D). The outer set of bevel gears drive the gatherer shafts (E).

Each gearcase is protected by a slip clutch (B) located on the input shaft at the upper end of the gearcase.



HX1581.10015.GA-19-03OCT94

H30681 -UN-05DEC91

DIAGNOSING MALFUNCTIONS

- Stalk Rolls Clashing

- Stalk roll shafts not properly timed.
 - Stalk rolls striking trash knives.

- Gearcase Noisy

- Lack of grease.
 - Gears not meshing properly.
 - Excessive backlash.
 - Binding of gears.

- Gearcase or Barrel Assembly Excessively Hot

- Seal failure causing loss of grease.
 - Lack of grease.
 - Binding of gears.
 - Defective bearings or bushings.
 - Improperly installed bearing caps.
 - Dirt packed in stalk roll and on barrel.

- Barrel Assembly Leaking Grease

- Defective seal under stalk roll.
 - Defective bearing.

TM1581,10015,AD-19-03OCT94

100
15
31

REMOVAL

1. Remove gatherer chains and sprockets. (See Removing Gathering Chains in this Section.)
2. Remove upper sprockets and latches. (See Removing Gathering Chains in this Section.)
3. Remove both trash knives (A) from under side of row unit.
4. Remove row unit frame. (See Row Unit Frame in this Section.)
5. Remove stalk rolls. (See Stalk Roll Removal in this Section.)
6. Pull out row unit hex drive shaft (A). To do this, remove the protective shield and row unit drive chain at the outer end of the corn head. Remove three bolts securing bearing carrier to the corn head frame and pull out drive shaft.

NOTE: There are two drive shafts. One for the right-hand half and one for the left-hand half. Be certain to remove the correct shaft for the gearcase to be serviced.

7. Remove gearcase (B) by removing two cap screws and two eyebolts (C) which secure the gearcase to the corn head frame.




H46410 -JUN-01MAY94

TM1581,10015,AE-19-03OCT94

DISASSEMBLY


1. Clean outside of gearcase thoroughly. Attach support bracket (A) (See Special Tools) to gearcase with two 1/2 x 1 in. cap screws.



HX,1401,10010,K-19-16DEC92


2. Set gearcase with support in vise (A) and remove slip clutch.

3. Remove barrel assembly with stalk roll shafts and gasket (B) from gearcase and set assembly to one side. If only the barrel assembly or stalk roll shafts are to be serviced, refer to "Servicing Barrel Assembly and Stalk Roll Shafts".




4. Remove gatherer drive shaft assemblies (C). Mark shafts so they can be reinstalled correctly to maintain proper gear wear.

5. Remove end caps (D) from each end of gearcase. Drive out from the inside of gearcase and pry out with a screwdriver. Be careful not to damage sealing surface of cap.



1401,10010,Z -19-12SEP91

6. Remove snap ring (A) from either end of hex. countershaft. Remove countershaft and both bevel (C) gears. Roll stalk roll drive gear cluster (D) out front of gearcase.




1401,10010,A1 -19-12SEP91

7. Drive in one plug with JDC400-7 handle (A) until the opposite one is loose. Drive shaft back until the remaining plug is loose.


8. Be careful not to damage tolerance ring on shaft. Do not drive ring through idler gear bearings. Drive out idler shaft (B).

9. Remove idler gear out front of gearcase.



HX,1401,10010,L-19-03OCT94

10. Remove input shaft cap (A) with bearings, seal, and gasket (B). Remove thrust washer (C) and input gear and shaft (D).



1401,10010,A3 -19-12SEP91

INSPECTION

Wash all parts thoroughly in a clean, safe solvent. Clean all grease out of gearcase.

Inspect all parts for wear or damage, especially bushings, bearings and seals.

If bushings or bearings need replacement, use the instructions on the following pages.

1401,10010,A4 -19-12SEP91

REPLACING BEARINGS AND BUSHINGS


NOTE: The part number is stamped into each special tool.

1401,10010,F7 -19-12SEP91

GATHERER DRIVE SHAFT BUSHING AND SEAL

1. Assemble special tools (A to D) for driving out gatherer drive shaft bushing and seal.

- A—JDC400-7 Handle
- B—27502, 30.2 mm (1-3/16 in.) Disk
- C—27499, 25.4 mm (1 in.) Disk
- D—10020 Screw



TM1581,10015,AH-19-03OCT94

H30689 -UN-15JUN89

2. Use tool (A) as shown and drive through gatherer cap opening in gear case against bushing (B). Drive out both bushings and seal.




HX,1401,10010,N-19-16DEC92

H30690 -UN-15JUN89

3. Assemble tools (A to E) for installing gatherer drive shaft bearing.

- A—JDC400-7 Handle
- B—27506, 36.5 mm (1-7/16 in.) Disk
- C—27499, 25.4 mm (1 in.) Disk
- D—10020 Screw
- E—JDC400-3 Spacer




TM1581,10015,AI-19-03OCT94

H30691 -UN-15JUN89

4. Use tools (B) as shown to install bushing. Drive bushing (A) from bottom to obtain proper location of bushing in case.

NOTE: Do not install seal at this time.



100
15
37

-UN-15JUN89
H30692

TM1581,10015,AJ-19-03OCT94

REPLACING COUNTERSHAFT BUSHINGS

1. Assemble plates (A and B) on screw (C) and insert through opening in front of gear case. Insert handle (D) through opening in end of gearcase and assemble tool inside gearcase.

- A—27507, 38.1 mm (1-1/2 in.) Disk
- B—27512, 46.0 mm (1-13/16 in.) Disk
- C—10020 Screw
- D—JDC400-7 Handle




-UN-15JUN89
H30693

TM1581,10015,AK-19-03OCT94

90 Series Corn Heads/Replacing Countershaft Bushings

2. Drive out bushing (A), then disassemble tool (B) for removal. If remaining bushing is to be removed, follow the above procedure from the opposite end of the gearcase.




1401,10010,B1 -19-12SEP91

H30694
-UN-05DEC91

3. Assemble tools (A to D) for installing countershaft bushing.


- A—JDC400-7 Handle
- B—27520, 50.8 mm (2 in.) Disk
- C—27507, 38.1 mm (1-1/2 in.) Disk
- D—10020 Screw



TM1581,10015,AC-19-03OCT94

H30695
-UN-15JUN89

4. Use tools (A) to install new bushing (B).




HX,1401,10010,S-19-28JAN93

H30696
-UN-05DEC91

REPLACING INPUT SHAFT (IN GEARCASE AND INPUT SHAFT CAP) NEEDLE BEARINGS AND SEALS


1. Assemble tool as illustrated.

- A—JDS400-7 Handle
- B—27520, 33.4 mm (2-5/16 in.) Disk
- C—27515, 50.8 mm (2 in.) Disk
- D—10020 Screw



TM1581,10015,AM-19-03OCT94


2. Drive tool (A) against inner end of bearing to remove both seal and bearing.



1401,10010,B5 -19-12SEP91

3. Assemble tools (A to E) for installing input shaft needle bearing.

- A—JDC400-7 Handle
- B—JDC400-4 Spacer
- C—27525, 66.7 mm (2-5/8 in.) Disk
- D—27525, 66.7 (2-5/8 in.) Disk
- E—10020 Screw




TM1581,10015,AN-19-03OCT94

4. Use tools (B) drive bearing (A) from outside of gearcase (or outside of input cap). Install rounded edge of needle bearing in bore and drive against flat edge of bearing.

NOTE: Flat edge of bearing has manufacturer's name and part number stamped into it. Do NOT drive against rounded edge of bearing.

5. Do not install seals until after gears are all installed so proper backlash can be determined.




H30700 -UN-05DEC91

HX,1401,10010,V-19-16DEC92

REPLACING GATHERER CAP BUSHINGS

1. Use a screwdriver or slide hammer puller to remove bushing (A) from gatherer cap (B).




H30701 -UN-05DEC91

HX,1401,10010,W-19-16DEC92

2. Assemble special tool to install bushing.


- A—JDC400-7 Handle
- B—27515, 50.8 mm (2 in.) Disk
- C—27499, 25.4 mm (1 in.) Disk
- D—10020 Screw



H30702 -UN-05DEC91

TM1581,10015,AO-19-03OCT94

3. Install bushing (A) with special tool (B). Be certain shoulder of bushings (A) is tight against edge of bore in cap.



H30703


H30703 -UN-05DEC91

HX,1401,10010,Y-19-16DEC92

REPLACING IDLER GEAR NEEDLE BEARINGS

1. Assemble special tool.


- A—JDC400-7 Handle
- B—27502, 30.2 mm (1-3/16 in.) Disk
- C—27499, 25.4 mm (1 in.) Disk
- D—10020 Screw



H30689 -UN-15JUN89

TM1581,10015,AP-19-03OCT94

2. Remove needle bearings (A) from idler gear (B).



H30704


H30704 -UN-05DEC91

HX,1401,10010AC-19-16DEC92

90 Series Corn Heads/Replacing Idler Gear Needle Bearings

3. Assemble special tool to install NEW needle bearings.

- A—JDC400-7 Handle
- B—27506, 36.5 mm (1-7/16 in.) Disk
- C—27499, 25.4 mm (1 in.) Disk
- D—10020 Screw
- E—JDC400-3 Spacer



H30691
-UN-15JUN89


TM1581,10015,AQ-19-03OCT94

4. Drive against the flat end (end with vendor number) of the bearing and install one from each end. Do NOT install bearing by driving one bearing in against the other.

HX,1401,10010AB-19-16DEC92

100
15
42

ASSEMBLY



H30705

- | | | | |
|---------------------------------|-------------------------------|------------------------------------|----------------------------------|
| 1—Stack Roll Drive Gear Cluster | 10—Oil Seal (2 Used) | 20—Expansion Ring (2 Used) | 29—Gatherer Drive Shaft (2 Used) |
| 2—Bushing (2 Used) | 11—Needle Bearing | 21—Tolerance Ring | 30—Oil Slinger Spring (2 Used) |
| 3—Bevel Pinion Gear (2 Used) | 12—Input Cap W/Bearing | 22—Idler Shaft | 31—Gearcase |
| 4—Snap Ring (2 Used) | 13—Cap Screw, 3/8 x 1-1/8 In. | 23—Needle Bearing (2 Used) | 32—Cap Screw, 1/2 x 1-1/4 In. |
| 5—Countershaft | 14—Lock Washer, 3/8 In. | 24—Idler Gear Assembly | 33—Lock Washer, 1/2 In. |
| 6—Grease Cap (2 Used) | 15—Gasket | 25—Cap Screw, 3/8 x 1 In. | 34—Drive Sprocket (2 Used) |
| 7—Bushing (2 Used) | 16—Thrust Washer (2 Used) | 26—Bushing (2 Used) | 35—Snap Ring (2 Used) |
| 8—Grease Seal (2 Used) | 17—Input Gear | 27—Gatherer Cap W/Bearing (2 used) | |
| 9—Pipe Plug, 3/4 In. | 18—Grease Fitting, 1/8 In. | 28—Gasket (2 used) | |
| | 19—Needle Bearing | | |


100
 15
 43
 -UN-26AUG91
 H30705

TM1581,10015,AR-19-03OCT94

1. Use John Deere Corn Head Grease and lubricate all bushings and bearings prior to assembly of gearcase. Also pack seals with this grease prior to installation.

IMPORTANT: This special high-pressure grease is available in a 0.4 kg (14-1/2 oz.) tube (AN102562), or a 16 kg (35 lb.) pail (AH80490).

2. Coat only one side of each thrust washer (A) with corn head grease and place greased side of each washer against each side of input shaft gear (B). The grease is used to hold the thrust washers against the gear for ease of installation. The lugs on the washers fit between the gear teeth.



-UN-05DEC91

H30706

3. Install input shaft with thrust washers in gearcase.

IMPORTANT: Turn input shaft to be certain lugs on both thrust washers fit between teeth on input gear.

TM1581,10015,AS-19-03OCT94


4. Install input cap (A) and gaskets (B) and secure with hardware previously removed.

NOTE: Input cap can be installed only one way.

5. Visually check that thrust washer lugs are in gear teeth. Check end play of input shaft; end play should be 0.13 to 0.38 mm (0.005 to 0.15 in.). End play must not exceed 0.38 mm (0.15 in.) Bump ends of shaft with rubber hammer to check. Input shaft must rotate freely. Add or remove gaskets as necessary to achieve proper end play.

NOTE: Always use at least one, but no more than six, gaskets.

6. Install seal (C) with seal driver (D).




-UN-05DEC91

H30707

TM1581,10015,AT-19-03OCT94

7. Assemble idler gear (A) and shaft (B) in gearcase. Install new tolerance ring (C) on shaft prior to assembly. To facilitate assembly, insert gear through opening in front of gearcase; then insert shaft.

NOTE: Start end of idler shaft (without tolerance ring) into bore first.




100
15
45
-UN-05DEC91
H30708

TM1581,10015,AU-19-03OCT94

8. Assemble tools (A, B and C) to install expansion plugs (D), above.


- A—JDC400-7 Handle
- B—JDC400-2 Plug Installer
- C—10020 Screw



-UN-05DEC91
H30709

TM1581,10015,AV-19-03OCT94

9. Center idler shaft in bores and install both expansion plugs. Use tools illustrated to install plugs.




-UN-05DEC91
H30710

TM1581,10015,AW-19-03OCT94

10. Coat gatherer bevel gears with corn head grease on flange surface only. Place bevel gears in gearcase. Install snap ring on one end of countershaft and insert countershaft through only the first bevel gear in the case.

11. Insert stalk roll drive gear assembly through opening in front of gearcase. Pass countershaft through stock roll gear assembly and bevel gears. Insert other snap ring on end of countershaft.

- A—Stalk Roller Drive
- B—Gear Assembly
- C—Snap Ring




H30711 -UN-05DEC91

TM1581,10015,AX-19-03OCT94

12. Leave NEW shafts dry, or clean OLD shafts. Assemble gatherer drive shafts in gatherer caps. Be certain shafts bottom in caps. Tap on shafts and turn to be certain they are free. Recheck end play.

IMPORTANT: With gatherer drive shafts turning toward each other (as viewed from barrel assembly opening), oil slinger springs must throw grease away from gears and toward bronze bushings for efficient lubrication. Shafts should be reinstalled on same side of case to maintain proper gear wear. The spring for the right-hand shaft has a left-hand spiral and spring for left-hand shaft has a right-hand spiral. For repairs, right-hand spiral springs are colored RED and the left-hand spiral springs are colored BLUE.



H30712 -UN-05DEC91


- A—L.H. Gatherer Drive Shaft with Gear
- B—R.H. Gatherer Drive
- C—R.H. Spiral Oil Slinger Spring
- D—L.H. Spiral Oil Slinger Spring

TM1581,10015,AY-19-03OCT94

13. Install both shafts (A), caps (B) and gaskets (C) dry (without grease) and tighten cap screws securely. Check gatherer drive shafts for proper backlash, 0.20 to 0.36 mm (0.008 to 0.014 in.).

14. Add or remove gaskets as necessary to achieve proper backlash. Tap end of shaft to make certain it is bottomed in cap.

NOTE: Gaskets are available in two thicknesses, 0.18 and 0.25 mm (0.007 and 0.010 in.).




TM1581,10015,AZ-19-03OCT94

15. After obtaining proper backlash, remove gatherer caps and shafts and coat gatherer cap bushing and shaft with John Deere Corn Head Grease.

16. To be certain everything turns fully, turn input shaft by hand when all parts are assembled.

17. Coat shoulders of gatherer caps and gaskets with Permatex (A) and install in gearcase. Coat threads of cap screws with Permatex and install and tighten to 45 N·m (35 lb-ft).

18. Pack gatherer shaft and input shaft seals with corn head grease and install on shafts (B). Be careful NOT to cut lips of seal on groove of shaft. Cover grooves with tape.




TM1581,10015,BA-19-03OCT94

100
15
48

19. Coat edges of end caps (A) with Permatex (B) and tap end caps into gearcase. Be certain caps are securely seated in gearcase.

20. This completes the disassembly and assembly of the gearcase. If work is not required on the barrel assembly and stalk roll shaft, see "Attaching Barrel Assembly to Gearcase" for assembly of these parts to the gearcase.

21. If work is required on the barrel assembly and stalk roll shafts, proceed on the following pages.



H30715 -UN-05DEC91

TM1581,10015,BB-19-03OCT94

SERVICING BARREL ASSEMBLY AND STALK ROLL SHAFTS


Disassembly

NOTE: If only the barrel assembly and/or stalk roll shafts are to be serviced, remove barrel assembly with shafts from gearcase. Set gearcase assembly to one side and cover opening to keep dirt out of gearcase.

The slip clutch does NOT need to be removed.

1. Hold barrel assembly (A) and tap stalk roll shafts (B) on a solid surface to separate shafts from barrel assembly.
2. Clean all grease off stalk roll shafts and gears and out of barrel assembly.
3. Remove seal from end of barrel and discard.

NOTE: Install NEW SEALS AFTER installing barrel assembly on gearcase.




H30716 -UN-05DEC91

TM1581,10015,BC-19-03OCT94

INSPECTION AND REPAIR

- 1—Grease Seal
- 2—Needle Bearing
- 3—Barrel
- 4—Gasket
- 5—Bearing
- 6—Stalk Roll Shaft




H30717

1401,10010,D8 -19-12SEP91

-UN-26AUG91
H30717

100
15
49

1. Examine stalk roll shaft (A), gear (B) and bearing (C) for wear. If it is necessary to remove bearing, use a split puller (D) as illustrated and press bearing off shaft. Install new bearing with a press. Be sure to seat inner face of bearing against gear hub.




H30718

1401,10010,D9 -19-12SEP91

-UN-05DEC91
H30718

2. Measure the stalk roll shaft at surfaces specified. If measurements are below the given dimensions or shaft has signs of wear, replace the shaft.

- A—31.47 mm (1.239 in.)
- B—81.30 mm (3.20 in.)
- C—76 mm (2.99 in.)
- D—189.4 mm (7.46 in.)
- E—31.72 mm (1.249 in.)




TM1581,HX100,DI-19-18AUG94

-UN-01MAY94
H46413

3. Assemble tool for removing bearing and seal in barrel assembly.


- A—JDC400-7 Handle
- B—27502, 30.2 mm (1-3/16 in.) Disk
- C—27507, 38.1 mm (1-1/2 in.) Disk
- D—10020 Screw



-UN-05DEC91

TM1581,10015,BE-19-03OCT94

4. Use tool (D) and drive out needle bearing (A) and seal (B) in barrel assembly (C).




-UN-05DEC91

TM1581,10015,BF-19-03OCT94

5. Assemble tool for installing bearing in barrel assembly.

- A—JDC400-7 Handle
- B—27515, 50.8 mm (2 in.) Disk
- C—JDC400-8 Spacer
- D—27502, 30.2 mm (1-3/16 in.) Disk
- E—10020 Screw



-UN-05DEC91


TM1581,10015,BG-19-03OCT94

90 Series Corn Heads/Attaching Barrel Assembly to Gearcase

6. Use tool (B) to install needle bearing in barrel assembly. Be certain to drive against flat end of needle bearing only.

NOTE: Do not install seals until after barrel assembly (A) with stalk roll shafts has been attached to gearcase. Coat needle bearings with Corn-Head grease.

7. Install stalk roll shafts in barrel assembly and strike on ends of gear with a lead hammer to seat shaft bearing shafts on barrel assembly. Rotate shafts. They must turn freely.




-UN-05DEC91
H30722

TM1581,10015,BH-19-03OCT94

ATTACHING BARREL ASSEMBLY TO GEARCASE

1. With gearcase assembly (A) mounted in a vise, insert the two barrel assembly locating dowel studs (B) in upper corner holes as illustrated. (See "Special Tools".)

2. Assemble new gasket (C) over locating dowel studs and set barrel assembly (D) with shafts on studs.




-UN-05DEC91
H30723

HX,1401,10010AP-19-16DEC92

90 Series Corn Heads/Attaching Barrel Assembly to Gearcase

3. Install stalk roll shaft timing tool (A) (see Special Tools) on end of shafts. Use 1/2 x 1-3/4 in bolts (B) or 1/2 in. rods to secure timing tool to shafts. It is not necessary to put nuts on the bolts.

4. Push against stalk roll shafts and barrel assembly. If inner surface of barrel assembly will not fit tight against surface of gearcase (C), stalk roll shafts are not properly timed and must be timed.



1401,10010,E6 -19-12SEP91


5. Grasp stalk roll shafts and pull barrel assembly away from gearcase about 25 mm (1 in.), remove one bolt from timing tool (A) and rotate one stalk roll shaft 180 degrees. Reinstall bolt and check to be certain barrel assembly is flush (B) against gearcase.

NOTE: If the fit is still not tight, repeat above procedure, rotating other stalk roll shaft.

6. When barrel assembly fits tight against gearcase, secure assembly with four bolts and check stalk roll backlash by holding one shaft and rotating the other. Backlash should be 0.20 to 0.36 mm (0.008 to 0.014 in.). Add or remove gaskets as necessary to obtain proper backlash.

NOTE: Gaskets are available in two thicknesses, 0.18 and 0.25 mm (0.007 and 0.010 in.). Rotate shafts to check for tight spots.


7. When proper backlash has been obtained, remove barrel assembly and pack around gears and in barrel with John Deere Corn Head grease, or equivalent. Use four ounces of grease to each barrel, total 56 ounces for the gearcase. After filling gearcase, pump grease through grease fitting while turning by hand.



TM1581,10015,BI-19-03OCT94


90 Series Corn Heads/Attaching Barrel Assembly to Gearcase

8. Install barrel assembly and secure with hardware previously removed (A). Coat the two special dowel bolts (B) with Permatex and install in lower corners of barrel assembly. Tighten all bolts.



1401,10010,E8 -19-12SEP91

9. Using tool (C), install seals (A) on ends of barrel assembly (B) over stalk roll shaft. Use tape over all spring pin holes to avoid cutting seal. Also, be certain seal spring does not rotate out of seal during installation.



HX,1401,10010AR-19-16DEC92

100
15
54

INSTALLATION

1. Remove special mounting bracket from gearcase and install gearcase on corn head.
2. Reverse removal procedure to install gearcase, stalk rolls, row-unit frame, gatherer chains, gatherer shields and associated parts.
3. Adjust gatherer chains, trash knives and deck plates as outlined.
4. Tighten trash knife bolts and stalk rolls clamping bolts to specified torques.
5. After complete assembly and installation of the corn head gearcase and component parts, with corn head attached to combine, start engine and engage corn head drive.
6. Operate corn head with gatherer points on the ground at low idle speed for four minutes.
7. Increase combine engine to fast idle and run corn head for six minutes.



CAUTION: Shut off combine engine.

8. Check for hot bearings and lubricate. Correct as necessary.

HX,1401,10010AS-19-16DEC92


ROW UNIT SLIP CLUTCH

General information

The slip clutches protect the corn head drives. Each row unit drive and the auger drive have a slip clutch.

TM1581,10015,BJ-19-03OCT94

90 Series Corn Heads/Row Unit Slip Clutch



- | | | | |
|------------------------------------|--------------------|--|---|
| 1—Coupler | 5—Retainer | 11—Spacer (4 used) | 14—Cap Screw, M10 x 100
(2 used) |
| 2—Cap Screw,
M12 x 150 (4 used) | 6—Thrust Washer | 12—Nut, M10 (2 used) | 15—Internal Tooth Lock
Washer, 12.7 mm (1/2 in.)
(4 used) |
| 3—Jam Nut, M12
(8 used) | 7—Hub | 13—Lock Washer 9.5 mm
(3/8 in.)
(2 used) | |
| 4—Bushing | 8—Jaw | | |
| | 9—Spring | | |
| | 10—Spring Retainer | | |

TM1581,10015,BK-19-03OCT94

REPAIR

Remove drive chain cover, chain row unit drive sprocket and triangle bearing flange. (May not be necessary when at end of shaft.)

Remove two M10 x 100 cap screws (14) to remove slip clutch. Refer to the above illustration for disassembly.

Inspect hub (7) and jaw (8) for wear. Inspect spring (9) for breakage. Inspect all other parts and replace parts as necessary.

TM1581,HX100,DJ-19-18AUG94

ASSEMBLY

Use the exploded view (See "Row Unit Slip Clutch") as a guide when assembling shift clutch.

1. Coat entire thrust washer (6) with multipurpose grease prior to assembly. Do not grease facing of hub (7) and jaw (8).

2. Reassemble slip clutch.

HX,1401,10010AV-19-16DEC92

TM1581 (03OCT94)


100-15-56

060597
PN=177

3. Tighten four cap screws in slip clutch to obtain a 67 mm (2-5/8 in.) dimension (A).

NOTE: The auger slip clutch is non-adjustable.

4. Do NOT tighten the nuts on the four cap screws to the point where the clutch will NOT slip. Jam the two nuts on each cap screw together and then tighten to 75 N·m (55 ft·lb) torque.




TM1581,10015, BM-19-03OCT94

H33378 -UN-25OCT89

100
15
57

MAIN DRIVE SHAFT AND COUPLER

493, 494, 594, 693, 694, 893,
894, 1293 (655201—)



H44866 -UN-06AUG92


- 1—Lock Nut, M20
- 2—Sprocket, 28 Tooth
- 3—Housing
- 4—Bearing
- 5—Retainer
- 6—Seal
- 7—Bolt, M10 x 25

- 8—Shaft
- 9—Shield
- 10—Bracket (2 used)
- 11—Housing (4 used)
- 12—Shield
- 13—Snap Ring
- 14—Shield

- 15—Bearing
- 16—Angle
- 17—Bracket
- 18—Bolt, M10 x 20 (2 used)
- 19—Sprocket, 14 Tooth

- 20—Snap Ring
- 21—Chain
- 22—Sprocket, 14 Tooth
- 23—Ball (3 used)
- 24—Coupler
- 25—Snap Ring

**MAIN DRIVE SHAFTS AND SHIELDS—
494 SIDEHILL**



100
15
58

-JUN-01MAY94
H46411

TM1581,10015,BO-19-03OCT94


90 Series Corn Heads/Main Drive Shaft and Shields

1—Decal	8—Sprocket	16—Shield	24—Yoke
2—Shield	9—Bolt, M10 x 80 (3 used)	17—Snap Ring (2 used)	25—Bolt, M12 x 70 (4 used)
3—Pin	Nut, M10 (3 used)	18—Bearing (2 used)	Lock Nut, M12 (4 used)
4—Hinge	10—Flange (4 used)	19—Lube Fitting	26—Decal
5—Bolt, M10 x 20 (3 used)	11—Bearing (2 used)	20—Yoke Tube	27—Shield
Nut, M10 (3 used)	12—Bracket	21—Lube Fitting (2 used)	28—Yoke Shaft
6—Lock Nut, M20	13—Retainer	22—Snap Ring (2 used)	29—Yoke
7—Washer, 21 x 42 x 5 mm	14—Seal	23—Cross and Bearings (2 used)	30—Drive Shaft Assembly
	15—Shaft		

TM1581,10015,BP-19-03OCT94

100
15
59

**MAIN DRIVE SHAFT AND SHIELDS—
693, 694, 893 AND 894 SIDEHILL**



H46412 -UN-01MAY94

TM1581,10015,BQ-19-03OCT94

TM1581 (03OCT94)

100-15-60


060597
PN=181

90 Series Corn Heads/Main Drive Shaft and Shields

- | | | | |
|----------------------------|--------------------------|----------------------|---------------------------|
| 1—Bracket | 5—Bolt, M8 x 20 (4 used) | 10—Shield | 15—Lock Nut |
| 2—Bolt, M10 x 20 (13 used) | 6—Bracket (2 used) | 11—Dowel Pin | 16—Shield |
| Flange Nut, M10 (13 used) | 7—Flange (4 used) | 12—Shaft (2 used) | 17—Seal |
| 3—Bolt, M8 x 20 (2 used) | 8—Bearing (2 used) | 13—Chain | 18—Retainer |
| Flange Nut, M8 (2 used) | 9—Decal | 14—Sprocket (2 used) | 19—Washer, 21 x 42 x 5 mm |
| 4—Hinge | | | |

TM1581,10015,BR-19-03OCT94

693, 694, 893, AND 894
C-V DRIVESHAFT SIDEHILL



-UN-22MAR93
H45749

- | | | | |
|-------------------------------|-------------------------|------------|----------------------------|
| 1—Yoke | 5—Yoke (2 used) | 10—Decal | 14—Yoke Tube |
| 2—Lube Fitting | 6—Lube Fitting (3 used) | 11—Shield | 15—Yoke |
| 3—Snap Ring | 7—Yoke Shaft (2 used) | 12—Shield | 16—Bolt, M12 x 70 (4 used) |
| 4—Cross and Bearings (4 used) | 8—Snap Ring (2 used) | 13—Bearing | Lock Nut, M12 (4 used) |
| | 9—Shield Retainer | | |


TM1581,HX100,DK-19-18AUG94

STUBBLE LIGHT BULB REPLACEMENT

Remove nut securing housing (A).

Unscrew housing from base.

Push AD2062R (1156) bulb in and turn to remove.



H42849

TM1581,HX100,DL-19-18AUG94

H42849 -UN-29NOV90


HEADER WARNING LIGHT BULB REPLACEMENT

Remove nuts (A).

Remove shield (B).

Unscrew housing (C) from bulb base.

Push AD2062R (1156) bulb in and turn to remove.



H42850

TM1581,HX100,DM-19-18AUG94

H42850 -UN-29NOV90

100
15
62

Group 20

50 and 50A Series Row-Crop Heads

TORQUE VALUES

	Torque N·m (Lb·Ft.)
Auger finger crank cap screws	70 N·m (50)
Auger fingers in plastic bearings	16 N·m (12)
Slip clutch nuts	45 N·m (35)
Gatherer chain idler nut	Initial 110 N·m (80 lb-ft.) then 205 N·m (150 lb-ft.)

1581,10020,ZV -19-03OCT94

50 AND 50A SERIES ROW-CROP HEAD— SPECIAL TOOLS

Number: *JDC3 Fluted Driver

Use: To remove and install the special six-point 5/16 in. screws in the auger finger guides.

NOTE: To use JDC3 driver with a 1/4 in. socket, a common 1/4 to 3/8 in. adapter is required for use with a 3/8 in. ratchet.


Number: *D01170AA Press

Use: To remove and install rivets when replacing rotary knife sections.

Order from:
Service Tools, Box 314, Owatonna MN 55060

H45100

-UN-08SEP92



H45301 -UN-13OCT92

HX1581,10020,FA-19-03OCT94

AUGER



-UN-10JAN91

H42441

GENERAL INFORMATION

As the combine moves through the field, the row crop gatherer points are positioned between the rows. These gatherer points lift and guide the crop into the gathering belts.

The gathering belts extend forward of the rotary knife to grip each stalk before it is cut. Each row unit has


its own rotary knife, equipped with six high-carbon cutting sections.

After the rotary knives have cut the stalks, the gathering belts then convey the stalks to the sump-type auger. A trough, located under the gathering belts, reduces crop loss due to shatter.

HX1581,10020,A -19-03OCT94

CROSS AUGER REMOVAL

1. Place a chain under center of auger and attach chain to hoist or lift fork.
2. Remove shield, loosen tightener (A) and disconnect and remove chain (B).
3. Remove nuts (C) and turn nut (D) off eyebolt to lower auger down on chain.
4. Remove nut (D) on eyebolt, loosen nut (E), and remove nuts (F). Remove auger adjusting bracket.




-UN-03AUG92

H44852

TM1581,HX100,DN-19-18AUG94

50 and 50A Series Row-Crop Heads/Auger


5. Remove seven bolts and remove front auger drive chain shield (A).



100
20
3
-UN-10SEP92
H45104


HX,1401,10015,D-19-16DEC92

6. Remove four bolts and remove rear auger drive chain shield (A).



-UN-10SEP92
H45105


HX,1401,10015,E-19-16DEC92



7. Slide auger all the way to the left (A).

8. Use hoist to lift right-hand end of auger up and out and remove auger from header (B).

NOTE: Due to various row spacings, it may be necessary to remove two round head bolts and lift the right-hand outer gatherer shield off to provide additional clearance for auger removal.



HX,1401,10015,F-19-16DEC92

INSPECTION AND REPAIR


Inspect all parts of the auger for damage or excessive wear. Replace parts as necessary. Refer to "Replacing Auger Hub".

See "Auger Shafts, Cranks and Fingers" for additional information concerning the row-crop head auger.

1401,10015,E -19-12SEP91

REPLACING AUGER HUB


Replacement auger hub must be accurately centered in the auger tube or excessive auger run out may result.



1. Measure and record dimension (A).
2. Drill out spot welds (B).
3. Grind out welds (C).

NOTE: Early auger had spot welds at (D) instead of welds at (C).

4. Place new hub in auger tube.
5. Center hub in tube according to dimension (A).
6. Use holes drilled in step 1 as a guide to weld NEW hub in tube.
7. Weld outer hub head to tube at (C).



HX,1401,10015,G-19-16DEC92

INSTALLING AUGER

Center auger between end sheets before following the steps described under "Removing Auger" in the reverse order to installing the auger.

TM1581,10020,B -19-03OCT94

REPLACING AUGER FINGERS

1. Use JDC3 driver to remove two finger guide screws and remove guide.

NOTE: Order JDC3 from your John Deere dealer. Use drive with 1/4 to 3/8 in. adapter.

2. Remove access hole covers in auger.

3. Remove broken parts and install new parts. Pull out on finger when installing nut on cap screw, to keep cap screw from turning. Torque cap screw to 16 N·m (12 lb-ft). Install guide.

H30649 -UN-23FEB89



H30649




H31987 -UN-13OCT88

TM1581,10020,C -19-03OCT94

100
20
6

AUGER



1—Guide Cap
2—Screw, 5/16 x 0.560 in.
3—Hub

4—Auger
5—Cap Screw,
1/4 x 5/8 in.

6—Nut, 6 mm
7—Cover


8—Hub (SN —635100)

H45107 -UN-10SEP92

TM1581,10020,D -19-03OCT94

AUGER SHAFTS, CRANKS AND FINGERS

453, 453A, 454, 454A, 653, 653A,
654, 654A, 655, 655A, 853 AND 853A



H38636

- | | | | |
|---|----------------------------------|------------------------------|----------------------|
| 1—Screw, 5/16 x 0.560 in. | 6—Spring Pin | 11—Shaft Key, 3/16 x 3/4 in. | 16—Ball Bearing |
| 2—Guide Cap | 7A—Bearing (—426350) | 12—Crank | 17—Lock Nut, 3/8 in. |
| 3—Guide | 7B—Bearing (426351—) | 13—Set Screw, 1/4 x 1/4 in. | 18—Pin |
| 4A—Finger (—426350) | 8—Screw, 5/16 x 1-3/4 in. | 14—Locking Collar | 19—Shaft |
| 4B—Finger (426351—) | 9—Shaft | 15—Bearing Flange | |
| 5—Washer, 11/32 x 3/4 x
0.075 in. (426351—535210)
(426351—535210) | 10—Cap Screw, 3/8 x 2-1/4
in. | | |

1. The auger does not have to be removed to repair shafts, cranks and fingers.

2. Use JDC3 fluted driver for removal of finger guide screws (1) (see "Special Tools").

3. When assembling parts in the auger, tighten parts to the following specification:


Cap screws (10) in cranks (12) - 70 N·m (50 lb-ft)

Auger fingers in plastic bearings - 16 N·m (12 lb-ft)

1581,10020,ZJ -19-03OCT94

**AUGER SHAFTS, CRANKS AND FINGERS
854, 854A AND 1253A**

100
20
8




- | | | | |
|---------------------------------|--|------------------------------------|---------------------------------------|
| 1—Lock Nut, 3/8 in.
(3 used) | 7—Set Screw, 1/4 x 1/4 in.
(2 used) | 12—Finger (18 used) | 18—Pin |
| 2—Bearing | 8—Locking Collar (2 used) | 13—Bearing | 19—Cap Screw, 3/8 x 2-1/4
(4 used) |
| 3—Housing (2 used) | 9—Screw, 5/16 x 0.560 in.
(36 used) | 14—Screw, 5/16 x 1-3/4 in. | 20—Crank |
| 4—Shaft | 10—Cap (18 used) | 15—Spring Pin, 1/4 x 1-7/8 in. | 21—Shaft |
| 5—Shaft Key (4 used) | 11—Guide (18 used) | 16—Bearing (2 used) | |
| 6—Housing (4 used) | | 17—Flange Nut, 3/8 in.
(6 used) | |

-UN-06AUG92

H44874

1581,10020,ZK -19-03OCT94

AUGER BRACKETS



- 1—Eyebolt
- 2—Bushing
- 3—Bolt, 3/8 x 1-1/4 in.
- 4—Nut 1/2 in.
- 5—Nut, 3/4 in.
- 6—Lock Washer, 3/4 in.
- 7—Washer, 25/32 x 1-5/8 x 0.180 in.

- 8—Bearing Flange
- 9—Bearing
- 10—Bracket
- 11—Washer, 1-13/32 x 2 x 0.060 in.
- 12—Sprocket (60 teeth)

- 13—Bolt, 3/8 x 3/4 in.
- 14—Bolt, 3/8 x 1 in.
- 15—Washer, 13/32 X 13/16 X 0.065 in. (—576110)
- 16—Bolt, 1/2 x 1-1/4 in.

- 17—Cap Screw, 3/8 x 2-1/4 in.
- 18—Support
- 19—Washer
- 20—Bracket

ROW UNIT DRIVES


All drives on the row-crop head are protected by either two or three slip clutches.

454 and 454A Row-Crop Heads are equipped with two slip clutches. The auger slip clutch (A) is located on the drive shaft on the right-hand side of the header. The row-unit clutch is located on the right-hand end of the row unit drive shaft.


653, 653A, 654, 654A, 655, 655A, 853, and 853A Row-Crop Heads are equipped with three slip clutches. The auger slip clutch (A) is located on the main drive shaft on the right-hand side of the header. The row-unit clutches (B) are located on the right-hand end and left-hand end of each row unit drive shaft, outside the respective end sheets.

When replacing slip clutch springs or jaws, the four bolts used to compress the spring must be tight. Tighten nuts in the auger clutch to 45 N·m (35 lb-ft) torque and the row unit clutch to 108.5 N·m (80 lb-ft).

A 24H1571 1-25/32 x 2-7/8 x 0.120 in. washer can be added between the spring and the clutch carrier to increase torque capacity of clutch. Add as required to a maximum of two washers.



(Auger Drive Slip Clutch)



(Row Unit Drive Slip Clutch)


1581,10020,ZL -19-03OCT94

50 and 50A Series Row-Crop Heads/Row Unit Drives

100
20
11

ROW UNIT DRIVES

**453, 453A, 454, 454A, 653, 653A,
654, 654A, 655, 655A, 853, AND 853A**



100
20
12

H44875 -UN-06AUG92

50 and 50A Series Row-Crop Heads/Row Unit Drives

1—Shaft, Outer	13—Jaw	26—Bearing	36B—Shield
2—Cap Screw, 3/8 x 1 (4 used)	14—Spring	27—Bolt, 3/8 x 3/4 in.	37—Snap Ring
3—Washer, 13/32 x 13/16 x 0.065 in.	15—Housing	28—Sprocket, 13 Tooth	38—Shield
4—Housing (2 used)	16—Chain	29—Nut, 3/4 in.	39—Bearing
5—Bearing	17—Cap Screw, 3/8 x 1-1/4 (2 used)	30—Washer, 25/32 x 1-3/4 x 0.194 in.	40—Sprocket
6—Cap Screw, 1/2 x 2-1/2 in. (4 used)	18—Strap (2 used)	31—Shaft	41—Bolt, 3/8 x 3/4 in.
7—Bushing	19—Strap	32A—Shield (S.N. —630252)	42—Bracket
8—Sprocket, 30 Tooth Drive	20—Bushing (3 used)	32B—Shield	43—Washer, 13/32 x 13/16 x 0.065 in. (2 used)
9—Washer, 1.840 x 3.560 x 0.134 in.	21—Sprocket, 15 Tooth (2 used)	33A—Snap Ring (S.N. —630252)	44A—Support (S.N. —344700)
10—Hub	22—Spacer, 0.516 x 0.623 x 0.551 in.	33B—Bearing	44B—Angle (S.N. 344701—)
11—Washer, 25/32 x 1-3/4 x 0.194 in. (2 used)	23—Washer, 17/32 x 1-1/4 x 0.180 in. (2 used)	34—Bolt, 3/8 x 3/4 in. (2 used)	45—Screw, 5/16 x 3/4 in.
12—Nut, 3/4 in. (2 used)	24—Bolt, 1/2 x 2-3/4 in.	35—Support	46—Washer, 25/32 x 2-7/8 x 0.120 in.
	25—Housing (2 used)	36A—Shield	


Right-Hand Illustrated

TM1581,10020,1 -19-03OCT94

100
20
13

ROW UNIT DRIVES
854, 854A AND 1253A

100
20
14



H44876 -UN-06AUG92

50 and 50A Series Row-Crop Heads/Row Unit Drives

- | | | | |
|--|--------------------------------------|--|------------------------------------|
| 1—Snap Ring | 9B—Shield | 11B—Shield (2 used) | 19—Angle |
| 2—Shaft | 10A—Snap Ring (S.N.
—635100) | 12—Shield | 20—Support |
| 3—Washer, 25/32 x 1-3/4 x
0.194 in. | 10B—Bearing | 13—Snap Ring | 21—Screw, M8 X 20 |
| 4—Nut, Slotted, M20 | 11A—Shield, (S.N.
—620463) (854A) | 14—Shield | 22—Bolt, 3/8 x 3/4 in. (4
used) |
| 5—Cotter Pin, 5 x 40 mm | (S.N. 620464—635100) | 15—Bearing | 23A—Support |
| 6—Housing (4 used) | (854A) | 16—Sprocket, 14 Tooth | 23B—Bracket |
| 7—Bearing (2 used) | (S.N. —620511) | 17—Washer, 13/32 x 13/16 x
0.065 in. (3 used) | 24—Housing (2 used) |
| 8—Bolt, 3/8 x 3/4 in. | (1253A) | 18—Bracket | |
| 9A—Shield (S.N.
—635100) | (S.N. 620511—635100) | | |
| | (1253A) | | |


Right-Hand Illustrated

TM1581,10020,J -19-03OCT94

100
20
15

**ROW UNIT DRIVES
854, 854A, AND 1253A**

100
20
16



- | | | | |
|--|--|--|--|
| 1—Shaft | 10—Washer, 1.84 x 3.560 x
0.134 in. | 20—Cap Screw, M10 x 30
(2 used) | 26—Sprocket, 15 Tooth |
| 2—Cotter Pin, 5 x 40 mm | 11—Hub | 21—Strap (1253A) | 27—Bushing |
| 3—Cap Screw, 3/8 x 1 in.
(4 used) | 12—Washer, 25/32 x 1 5/8 x
0.180 in. (2 used) | 22—Washer, 17/32 x 1-1/4 x
0.180 in. (2 used) | 28—Bolt, 1/2 x 2 3/4 in. |
| 4—Washer, 13/32 x 13/16 x
0.056 in. (8 used) | 13—Nut, Slotted, M20 | 23—Bolt, 1/2 x 1-1/4 in.
(2 used) | 29—Shield |
| 5—Housing (2 used) | 14—Jaw | 24—Bushing | 30—Self-Locking Screw
M20 x 45 (4 used) |
| 6—Bearing | 15—Spring | 25—Sprocket, 13 Tooth
(854A) | 31—Washer, 25/32 x 2-7/8 x
0.120 in. |
| 7—Cap Screw, 1/2 x 2-1/2 in.
(4 used) | 16—Housing | 26—Sprocket, 17 Tooth
(1253H) | 32—Washer, 17/32 x 1-1/8 x
0.060 in. |
| 8—Bushing | 17—Chain | | |
| 9—Sprocket, 30 Tooth (854A)
Sprocket, 38 Tooth
(1253A) | 18—Strap (854A) | | |
| | 19—Strap (854A) | | |


Right-Hand Illustrated

-JUN-06AUG92
H44877

50 and 50A Series Row-Crop Heads/Row Unit Drives

100
20
17

ROW UNIT DRIVES
653, 653A, 654, 654A, 655, AND 655A



TM1581, HX100, DU-19-18AUG94

50 and 50A Series Row-Crop Heads/Row Unit Drives


- | | | | |
|--|--|---|---|
| 1—Housing | 12—Washer, 13/32 x 13/16
x 0.065 in. (8 used) | 23—Screw, 5/16 x 3/4 in. | 34—Sprocket, 13 Tooth |
| 2—Spring | 13—Cap Screw, 3/8 x 1 (4
used) | 24A—Support | 35—Washer, 25/32 x 1-5/8 x
0.180 in. |
| 3—Jaw | 14—Shaft | 24B—Angle | 36—Nut, 3/4 in. |
| 4—Nut, 3/4 in. | 15—Strap | 25—Bolt, 3/8 x 3/4 (4 used) | 37—Bushing |
| 5—Washer, 25/32 x 1-5/8
x 0.180 in. | 16—Sprocket, 15 Tooth | 26—Bracket | 38—Strap |
| 6—Hub | 17—Bushing | 27—Washer, 13/32 x 13/16
x 0.065 in. | 39—Washer, 17/32 x 1-1/4 x
0.180 in. |
| 7—Washer, 1.84 x 3.356 x
0.134 in. | 18—Washer, 17/32 x 1-1/4
x 0.180 in. | 28—Snap Ring | 40—Cap Screw, 3/8 x 1 in.
(2 used) |
| 8—Sprocket, 30 Tooth | 19—Bolt, 1/2 x 2-3/4 in. | 29—Sprocket, 14 Tooth | 41—Chain |
| 9—Cap Screw, 1/2 x 2-1/2 in.
(4 used) | 20—Shaft | 30—Bearing | 42—Washer, 25/32 x 2-7/8 x
0.120 in. |
| 10—Housing (2 used) | 21—Housing (2 used) | 31—Shield | |
| 11—Bearing | 22—Bearing | 32—Snap Ring | |
| | | 33—Shield | |

Left-Hand Illustrated

TM1581,10020.L -19-03OCT94

100
20
19

**ROW UNIT DRIVES
854, 854A AND 1253A**



- | | | | |
|--|--|--|---|
| 1—Housing | 9—Cap Screw, 1/2 x 2-1/2 in.
(4 used) | 16—Washer, 17/32 x 1-1/4 x
0.180 in. (2 used) | 22—Bushing |
| 2—Spring | 10—Housing (2 used) | 17—Spacer | 23—Strap |
| 3—Jaw | 11—Bearing | 18—Sprocket, 15 Tooth | 24—Washer, 17/32 x 1-1/8 x
0.068 in. |
| 4—Nut | 12—Washer, 13/32 x 13/16 x
0.065 in. (8 used) | 19—Sprocket, 13 Tooth
(854A) | 25—Flange Nut |
| 5—Washer, 25/32 x 1-5/8
x 0.180 in. | 13—Cap Screw, 3/8 x 1 in.
(4 used) | Sprocket, 17 Tooth
(1253A) | 26—Bolt, 1/2 x 1-1/4 in. (2
used) |
| 6—Hub | 14—Shaft | 20—Strap | 27—Strap |
| 7—Washer | 15—Bolt, 1/2 x 2-3/4 in. | 21—Chain | 28—Washer, 25/32 x 2-7/8 x
0.120 in. |
| 8—Sprocket, 30 Tooth (854A)
Sprocket, 39 Tooth
(1253A) | | | |

Left-Hand Illustrated

1581,10020,ZN -19-03OCT94

100
20
20


H44879 -UN-06AUG92

50 and 50A Series Row-Crop Heads/Row Unit Drives

100
20
21

ROW UNIT DRIVES
854, 854A AND 1253A

100
20
22



50 and 50A Series Row-Crop Heads/Hydraulic Cylinder Safety Stop

- | | | | |
|-------------------------------------|---------------------------------|---|-----------------------|
| 1—Cotter Pin, 5 x 40 in. | 6—Housing | 13—Washer, 13/32 x 13/16 x 0.065 in. (5 used) | 20—Ball (3 used) |
| 2—Nut, Slotted, M20 | 7—Bolt, 3/8 x 3/4 in. (8 used) | 14—Shield, Inner | 21—Sprocket, 14 Tooth |
| 3—Washer, 25/32 x 1-3/4 x 0.194 in. | 8—Shaft | 15—Snap Ring | 22—Screw, M8 x 20 |
| 4—Sprocket, 13 Tooth (854A) | 9—Snap Ring | 16—Shield | 23—Support |
| Sprocket, 17 Tooth (1253A) | 10—Tube | 17—Bearing | 24—Angle |
| 5—Bearing (2 used) | 11A—Support | 18—Snap Ring | 25—Bracket |
| | 11B—Bracket | 19—Quick Coupler | 26—Housing |
| | 12—Bolt, 3/8 x 3/4 in. (4 used) | | |

Left-Hand Illustrated

TM1581,10020,M -19-03OCT94


100
20
23

HYDRAULIC CYLINDER SAFETY STOP

CAUTION: When working under the row-crop head, always place the hydraulic cylinder safety stop in safety position to prevent header from lowering.


1. Start engine, raise feeder house and fully extend hydraulic cylinder to place safety stop in safety position.
2. (20 Series Combines) Disconnect support chain (A) from safety stop (B) and lower safety stop onto the cylinder rod.
3. (Maximizer Combines) Hold handle (A) and release safety stop by removing pin (B) and lifting stop up and in and lowering it down onto the cylinder rod.

After completing work on the row crop head, place safety stop in storage position.



20 Series Combines

H35404
-UN-28NOV89



Maximizer Combines

H41444
-UN-28NOV89

1581,10020,ZO -19-03OCT94

REMOVING GATHERER SHEETS

1. Raise row-crop head and lower hydraulic cylinder safety stop.
2. Pull spring locking pin (A) and lower point to ground. Store pin in same chain link.



TM1581,10020,N -19-03OCT94

H41476 -UN-05DEC89

3. Open gatherer sheets.




HX,1401,10015AG-19-16DEC92

H41477 -UN-05DEC89

4. Remove two cotter pins (B) and lift off sheet (A). Do not mix sheets. They have been adjusted for each row unit.

5. Remove round head bolts (C) and remove bracket (D).

A—Gatherer Sheet
B—Cotter Pins
C—Round Head Bolts
D—Bracket




HX,1401,10015AH-19-16DEC92

H41528 -UN-18DEC89

REMOVING AND REPAIRING GATHERING BELTS

1. After lowering gatherer point, swing up sheet (A), remove two cotter pins (B) and lift off sheet. Do not mix sheets. They have been adjusted for each row unit.
2. Remove two round head bolts (C) and remove bracket (D).



1581,10020,WA -19-03OCT94

H41528 -UN-18DEC89

50 and 50A Series Row-Crop Heads/Removing and Repairing Gathering Belts

3. Loosen jam nut (A) and back off bolt (B) to loosen belt.
4. Remove nut and washer on idler (C).
5. Remove two cap screws (D) and remove chain guide (E).

NOTE: Remove only the right-hand chain guide to remove either belt. "Right-hand" and "left-hand" sides are determined by facing in the direction the row-crop head will travel when in use.

6. Lift off gathering belt with idler. Set idler aside.




HX,1401,10015AJ-19-16DEC92

100
20
25
-UN-20DEC89
H41529

NOTE: A gatherer chain can be repaired by replacing the 2-ply rubber fabric. One of the fabric plies is thicker than the other. Install the **THICKER** ply (A) so it contacts the crop.

7. Install gathering belt, idler, and chain guide.

NOTE: A new gatherer belt and chain from service parts will be stiff and chain rollers will not turn freely. This condition is normal for new parts. Chain will wear and loosen during operation.




H41530

HX,1401,10015AK-19-03OCT94

-UN-18DEC89
H41530

8. Position belt on sprockets so the lug attachment link (A) of the chain is centered between the attachment links (B) of the mating chain within 9.6 mm (3/8 in.).




H41531

1581,10020,ZP -19-03OCT94

-UN-18DEC89
H41531

9. Connecting link on chain must be attached with the trailing edge away from the direction of travel.



100
20
26

-UN-10SEP02
H45109


HX,1401,10015AM-19-16DEC92

10. Tighten bolt (A) until a 88 N (20 lb) force applied midway between the drive and idler sprockets will deflect the belt 13 to 25 mm (1/2 to 1 in.).


11. Tighten jam nut (B).

12. Attach bracket (C) with round head bolts (D).

13. Attach gatherer sheet (E) with cotter pins (F).




-UN-18DEC89
H41532



-UN-20DEC89
H41533

1581,10020,ZQ -19-03OCT94

GATHERER CHAIN DRIVE—EXPLODED VIEW



H45302 -UN-13OCT92

- 1—Shaft
- 2—Gear (18 Teeth)
- 3—Snap Ring
- 4—Ball Bearing

- 5—Snap Ring
- 6—Left-Hand Sprocket (11 Teeth and 12 Teeth)


- 7—Right-Hand Sprocket (11 Teeth)
- 8—Washer, 25/32 x 1-3/8 x 0.180 in.

- 9—Slotted Nut, 3/4 in.
- 10—Cotter Pin, 3.2 x 5.0 mm

TM1581,10020,O -19-03OCT94

100
20
27

RIGHT-HAND AND LEFT-HAND GATHERER CHAIN DRIVE IDLER



H45111
-UN-10SEP92

1—Washer, 21/32 x 1-3/8 x 0.134 in.
2—Bolt, 3/8 x 4 in.
3—Support

4—Cap Screw, 1/2 x 3-1/4 in.
5—Right-Hand Strap
6—Bolt, 5/8 x 3 in.


7—Cap Screw, 3/8 x 3-3/4 in.
8—Nut, 1/2 in.
9—Sprocket (11 Teeth)

10—Left-Hand Strap
11—Nut, 1/2 in.
12—Cap Screw, 1/2 x 2-1/2 in.

HX,1401,10015AP-19-16DEC92

REMOVING ROTARY KNIFE

1. Remove gatherer sheets. See "Removing Gatherer Sheets" in this Group.
2. Loosen chain tightener (A).




H45112
-UN-10SEP92

TM1581,10020_P -19-03OCT94

⚠ CAUTION: Rotary knife with shaft will drop when slotted nut is removed.


3. Remove cotter pin (A), slotted nut (B) and flat washer (C).



H45113
-UN-10SEP92

HX,1401,10015AR-19-16DEC92

4. Remove rotary knife (A).



HX,1401,10015AS-19-16DEC92

H45114 -UN-10SEP92

100
20
29

REPLACING ROTARY KNIFE SECTIONS


1. Use *D01170AA Press to remove and install rivets when replacing knife sections. Instructions are included with the press.

IMPORTANT: Replace knife sections with special high carbon steel sections having hard surface treatment on the beveled edges.

2. For good knife section and stationary knife contact, remove all burrs from attaching rivets with a file or electric sander.

CAUTION: Wear suitable eye protection when using sander to remove burrs.

*Order from:
Service Tools, Box 314, Owatonna MN 55060



H41525 -UN-14DEC89

HX,1401,10015AT-19-03OCT94


ADJUSTING ROTARY KNIFE SECTIONS

1. For a good cut and to keep wear of stationary knife blade (A) and rotary knife (B) sections to a minimum, the highest rotary knife section must contact the stationary knife evenly.

2. Check cutting surfaces of each rotary knife section. Clearance between highest knife section and stationary knife must not be more than 0.20 mm (0.008 in.) (C). Maximum clearance on other five sections is 76 mm (0.030 in.).

3. If clearance is too much, slotted nut on rotary knife must be tightened or shim stationary knife with H100293 as required to bring clearance to 0.20 mm (0.008 in.). See your John Deere dealer for purchase of H100293.

IMPORTANT: When knife sections are replaced, there must not be more than 0.20 mm (0.008 in.) clearance at the highest section. Riveting process can cause knife sections to deflect. Rotary knife is correctly set when highest knife section is warm (not hot) to the touch after operation.



H41526

-UN-14DEC89


H41526

HX,1401,10015AU-19-03OCT94

REMOVING STATIONARY KNIFE

Raise row-crop head to maximum height and lower safety stop.

1. Remove nuts from plow bolts (A) attaching bearing housing to row unit frame.



H41524


-UN-12DEC89

H41524

TM1581,10020,Q -19-03OCT94

2. Remove rotary knife (A). (See "Rotary Knives".)
3. Remove socket head plow bolt (B) and remove stationary knife (C).

NOTE: When stationary knife becomes worn, it can be reversed to double its life. Do NOT turn stationary knife over or cutting edge will not match rotary knife.




H42465 -UN-12JAN91

100
20
31

HX,1401,10015AW-19-16DEC92

INSTALLING ROTARY KNIFE


1. Turn slotted nut (D) until the rotary knife can be rotated by hand. A slight drag or shearing action must be felt as the rotary knife passes across the stationary knife. See "Adjusting Rotary Knife" in this Group.
2. Replace cotter pin (C).
3. Replace rotary knife chain (B).
4. Tighten adjusting bolt (E) until an 8 N (20 lb) force applied midway between the sprockets at point (B) will deflect chain 5-8 mm (3/16—5/16 in.).
5. Tighten nuts (A) to 115 N·m (85 lb-ft).



H45115 -UN-10SEP92

HX,1401,10015AX-19-16DEC92

**KNIFE DRIVE AND BEARINGS—
453, 453A, 454, 454A, 653, 653A,
654, 654A, 655, 655A, 853 AND 853A**



100
20
32

H44885
-UN-06AUG92

1581,10020,XA -19-03OCT94

TM1581 (03OCT94)

100-20-32

060597
PN=215

50 and 50A Series Row-Crop Heads/Knife Drive and Bearings


- | | | | |
|--|----------------------------------|----------------------------------|---------------------------------------|
| 1—Cotter Pin,
3 x 50 mm | 8—Housing | 16—Shield | 23—Washer, 13/32 x 7/8
x 0.120 in. |
| 2—Nut, Slotted, 3/4 in. | 9—Spring | 17—Spring Pin,
3/8 x 2 in. | 24—Plate |
| 3—Washer, 25/32 x
1-3/8 x 0.180 in. | 10—Bolt, 3/8 x 4 in.
(2 used) | 18—Section (6 used) | 25—Bolt, 1/2 x 4-1/2 in. |
| 4—Sprocket, 12 Tooth | 11—Spacer | 19—Plow Bolt and Nut | 26—Bolt, 1/2 x 2-1/2 in. |
| 5—Snap Ring (2 used) | 12—Knife, Stationary | 20—Knife | 27—Lubrication Fitting |
| 6—Bearing (2 used) | 13—Shim | 21—Bolt, 3/8 x 4-1/2 in. | 28—Bolt, 3/8 x 1-1/4 in. |
| 7—Spacer | 14—Screws, 1/2 x 1 in. | 22—Cap Screw, 3/8 x 1-1/4
in. | |
| | 15—Screw (2 used) | | |

1581,10020,ZR -19-03OCT94

100
20
33

KNIFE DRIVE

**453, 453A, 454, 454A, 653, 653A,
654, 654A, 655, 655A, 853 AND 853A**



100
20
34

H44884 -JUN-06AUG92

TM1581,HX100,DZ-19-18AUG94

50 and 50A Series Row-Crop Heads/Knife Drive


- | | | | |
|---|-----------------------------|----------------------------------|---|
| 1—Chain, 74 links | 4—Sprocket, 11 and 12 Teeth | 9—Rail | 13—Washer, 13/32 x
13/16 x 0.065 in. |
| 2—Washer, 33/64 x
7/8 x 0.048 (2 used) | 5—Bushing | 10—Bolt, 3/8 x 1 in. | 14—Cap Screw, 3/8 x 4-1/2
in. |
| 3—Sprocket, 15 Teeth (2
used) | 6—Strip | 11—Bolt, 1/2 x 2 in.
(2 used) | |
| | 7—Screw, 3/8 x 1 in. | 12—Bolt, 3/8 x 1-1/4 in. | |
| | 8—Tightener | | |

TM1581,10020,T -19-03OCT94

100
20
35

50 and 50A Series Row-Crop Heads/Knife Drive

100
20
36



HX,1401,10015BC-19-16DEC92

H44883 -UN-06AUG92

50 and 50A Series Row-Crop Heads/Stubble Light Bulb Replacement

- | | | | |
|---|--------------------------------------|--------------------------|---|
| 1—Chain, 74 Links | 11—Bolt, 3/8 x 1-1/4 in.
(2 used) | 20—Shim | 31—Sprocket, 15 Teeth |
| 2—Washer, 17/32 x 1-1/4
x 0.180 in. (2 used) | 12—Spring Pin, 3/8 x 2 in. | 21—Bolt, 3/8 x 4 in. | 32—Washer, 25/32 x 1-5/8 x
0.180 in. |
| 3—Spacer | 13—Section (6 used) | 22—Spacer | 33—Nut, Slotted, M20 |
| 4—Sprocket, 15 Tooth | 14—Rivet, 1/4 x 7/8 in.
(18 used) | 23—Spring | 34—Cotter Pin, 3 x 50 mm |
| 5—Sprocket, 11 and 15 Tooth | 15—Knife | 24—Bolt, 1/2 x 4-1/2 in. | 35—Bolt, 3/8 x 4-1/2 in. |
| 6—Strap | 16—Shield | 25—Bolt, 1/2 x 2-1/2 in. | 36—Cap Screw, 3/8 x 1-1/4
in. |
| 7—Screw, M10 x 25
(2 used) | 17—Screw, M10 x 25
(2 used) | 26—Lubrication Fitting | 37—Washer, 13/32 x 7/8
x 0.120 in. |
| 8—Rail | 18—Screw, 1/2 x 1 in. | 27—Housing | 38—Plate |
| 9—Bolt, 3/8 x 1 in. | 19—Knife, Stationary | 28—Snap Ring (2 used) | |
| 10—Bolt, 1/2 x 2-3/4 in.
(2 used) | | 29—Bearing (2 used) | |
| | | 30—Spacer | |

Rotating Knife and Drives

TM1581,10020,U -19-03OCT94

100
20
37


If the rotary knife drive must be disassembled, refer to the previous exploded views for relationship of parts.

HX,1401,10015BE-19-16DEC92

STUBBLE LIGHT BULB REPLACEMENT

Unscrew housing (A) from base.

Push AD2062R (1156) bulb in and turn to remove.



H42849

1581,10020,XC -19-03OCT94

-UN-29NOV90
H42849


HEADER WARNING LIGHT BULB REPLACEMENT

Remove nuts (A).

Remove shield (B).

Unscrew housing (C) from bulb base.

Push bulb in and turn to remove.



100
20
38

Section 10 GENERAL

10

Contents

Page

Group 05—Safety	10-05-1
Group 10—Identification	
Serial Number	10-10-1
Group 15—Specifications	10-15-1

Section 100 HEADER REPAIR

Contents

	Page		Page
Group 05—200 and 900 Series Cutting Platforms			
Torque Values	100-05-1	Installing Frame Metric Hardware	100-05-41
Special Tools	100-05-1	Group 10—40 Series Corn Heads	
General Information	100-05-2	Torque Values	100-10-1
Auger Removal	100-05-2	Special Tools	100-10-1
Inspection and Repair	100-05-5	Making Special Tools	100-10-4
Auger Shafts, Cranks and Fingers	100-05-6	General Information	100-10-6
Repair and Assembly	100-05-6	Auger Removal	100-10-8
Auger Drive	100-05-8	Assembly and Installation	100-10-11
Sidehill Auger Drives	100-05-9	Row Unit Frame	100-10-12
Auger Drive Slip Clutch	100-05-10	Inspection and Repair	100-10-14
Guards and Knives	100-05-10	Assembly and Installation	100-10-15
Hydraulic Cylinder Safety Stop	100-05-11	Adjusting Deck Plates and Gatherer Chain Guides	100-10-16
Reoval and Installation of Guards and Knives	100-05-12	Adjusting Trash Knives	100-10-17
Knife Drive Arm Clamp Adjustment	100-05-13	Stalk Rolls	100-10-18
Setting Knife Register	100-05-14	Inspection	100-10-19
Guard Alignment	100-05-14	Installation	100-10-19
Adjusting Hold Down Clips	100-05-15	Gear Case	100-10-20
Adjusting Wearing Plates	100-05-16	Diagnosing Malfunctions	100-10-21
Knife Section Service Kit	100-05-16	Removal	100-10-22
Replacing Knife Section	100-05-16	Disassembly	100-10-23
Adjusting Non-Clog Cutterbar Guards (Attachment)	100-05-17	Inspection	100-10-25
Auger Fingers	100-05-18	Replacing Bearings and Bushings	100-10-25
Cutterbar Drive Case	100-05-18	Gatherer Drive Shaft Bushing and Seal	100-10-26
Disassembly	100-05-20	Replacing Countershaft Bushings	100-10-27
Inspecting Drive Case Components	100-05-22	Replacing Input Shaft Needle Bearings and Seals	100-10-29
Install Drive Case Bearings	100-05-23	Replacing Gatherer Cap Bushings	100-10-30
Assemble Knife Drive Case	100-05-24	Replacing Idler Gear Needle Bearings	100-10-31
Installation	100-05-27	Assembly	100-10-33
Knife Drive Case	100-05-28	Servicing Barrel Assembly and Stalk Roll Shafts	100-10-38
Cutterbar Drive	100-05-30	Inspection and Repair	100-10-39
Replacing Cutterbar Drive Belt	100-05-31	Attaching Barrel Assembly to Gearcase	100-10-41
Adjusting Fixed Idler Position	100-05-31	Installation	100-10-44
L.H. Stabilizer Socket (Flex Platforms Only)	100-05-31	Row Unit Slip Clutch	100-10-44
Cleaning Dirt from Under Flexible Seals	100-05-32	Repair	100-10-45
Pickup Reel	100-05-33	Assembly	100-10-45
General Information	100-05-34	Main Drive Shaft and Coupler	100-10-47
Removal and Disassembly	100-05-35	Main Drive Shaft and Coupler	100-10-49
Assembly	100-05-35	Stubble Light Bulb Replacement	100-10-51
Reel Drive (900 Series)	100-05-36		
Stubble Light Bulb Replacement	100-05-39		
Installing New Repair Floor Sheet	100-05-40		

Continued on next page

Contents

100

	Page		Page
Header Warning Light Bulb Replacement	100-10-52	Header Warning Light Bulb Replacement	100-15-62
Group 15—90 Series Corn Heads		Group 20—50 and 50A Series Row-Crop Heads	
Torque Values	100-15-1	Torque Values	100-20-1
Special Tools	100-15-1	Auger	100-20-2
Making Special Tools	100-15-4	Inspection and Repair	100-20-4
General Information	100-15-6	Replacing Auger Hub	100-20-5
Remove Auger	100-15-7	Installing Auger	100-20-5
Assembly and Installation	100-15-10	Replacing Auger Fingers	100-20-6
Row Unit Frame, Gatherer Chains, Trash Knives and Deck Plates	100-15-11	Auger	100-20-6
Inspection and Repair	100-15-18	Auger Shafts, Cranks and Fingers	100-20-7
Assembly and Installation	100-15-18	Auger Brackets	100-20-9
Adjusting Deck Plates and Gatherer Chain Guides	100-15-20	Row Unit Drives	100-20-10
Row Units	100-15-21	Row Unit Drives	100-20-18
Adjusting Trash Knives	100-15-21	Hydraulic Cylinder Safety Stop	100-20-23
Stalk Rolls	100-15-22	Removing Gatherer Sheets	100-20-24
Inspection	100-15-23	Removing and Repairing Gathering Belts	100-20-24
Installation	100-15-23	Gatherer Chain Drive—Exploded View	100-20-27
Knife Stalk Rolls	100-15-24	Removing Rotary Knife	100-20-28
Adjustable Deck Plates	100-15-25	Replacing Rotary Knife Sections	100-20-29
Adjustable Deck Plates, Tie Bar, Pivot Arms and Cylinder	100-15-27	Adjusting Rotary Knife Sections	100-20-30
Remove Pivot Arms	100-15-28	Removing Stationary Knife	100-20-30
Remove Cylinder	100-15-29	Installing Rotary Knife	100-20-31
Gearcase	100-15-30	Knife Drive and Bearings	100-20-32
Diagnosing Malfunctions	100-15-31	Knife Drive	100-20-34
Removal	100-15-32	Stubble Light Bulb Replacement	100-20-37
Disassembly	100-15-33	Header Warning Light Bulb Replacement	100-20-38
Inspection	100-15-35		
Replacing Bearings and Bushings	100-15-35		
Gatherer Drive Shaft Bushing and Seal	100-15-36		
Replacing Countershaft Bushings	100-15-37		
Input Shaft, Needle Bearings and Seals	100-15-39		
Replacing Gatherer Cap Bushings	100-15-40		
Replacing Idler Gear Needle Bearings	100-15-41		
Assembly	100-15-43		
Servicing Barrel Assembly and Stalk Roll Shafts	100-15-48		
Inspection and Repair	100-15-49		
Attaching Barrel Assembly to Gearcase	100-15-52		
Installation	100-15-55		
Row Unit Slip Clutch	100-15-55		
Main Drive Shaft and Coupler	100-15-57		
Main Drive Shaft and Shields	100-15-58		

Contents

SECTION 10—GENERAL

- Group 05—Safety
- Group 10—Identification
- Group 15—Specifications

SECTION 100—HEADER REPAIR

- Group 05—200 and 900 Series Cutting Platforms
- Group 10—40 Series Corn Heads
- Group 15—90 Series Corn Heads
- Group 20—50 and 50A Series Row-Crop Heads

Index

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1581-19-03OCT94

COPYRIGHT© 1994
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual

Contents

10

100

INDX

Index

	Page		Page
A			
Adjusting Trash Knives	100-15-21	Cutterbar, setting knife register	100-05-14
Auger cranks,		Cutterbar, Wearing Plate Adjustment . . .	100-05-16
Platform	100-05-6	Cylinder Safety Stop	100-05-11
Auger drive slip clutch,		D	
Platform	100-05-10	Deck plates, adjust	
Auger drive,		40 Series Corn Head	100-10-16
Platform	100-05-8	90 Series Corn Head	100-15-20
Sidehill platform	100-05-9	Driveshaft,	
Auger fingers,		40 Series Corn Head	100-10-47
Platform	100-05-6	Driveshafts,	
Replace row crop	100-20-6	Row crop	100-20-12
Auger fingers, replace	100-05-18	F	
Auger install,		Fixed Idler Adjustment	100-05-31
Row crop	100-20-5	G	
Auger removal,		Gatherer chain guide, adjust	
Platform	100-05-2	90 Series Corn Head	100-15-20
Auger remove, row crop	100-20-2	Gatherer chain guides, adjust	
Auger remove, 40 Series Corn Head	100-10-8	40 Series Corn Head	100-10-16
Auger shaft crank,		Gatherer chain,	
Row crop	100-20-7	Row Crop	100-20-27
Auger shafts,		Gatherer sheets,	
Platform	100-05-6	Row Crop	100-20-24
Auger, install 40 Series Corn Head	100-10-11	H	
Auger, install, 90 Series Corn Head . . .	100-15-10	Header Warning Light Bulb Replacement	100-05-40, 100-15-62
Auger, remove, 90 Series Corn Head . . .	100-15-7	I	
B			
Bulb		Idler, Fixed, Adjustment	100-05-31
50A Series Row Crop Head, warning .	100-20-38	Inch torque values	10-15-14
C			
Cutterbar, Adjusting Drive Belt Tension .	100-05-31	K	
Cutterbar, drive belt, replace	100-05-31	Knife drive case, install	100-05-27
Cutterbar, driveshaft	100-05-30	Knife drive,	
Cutterbar, guards and knives	100-05-12	Row Crop	100-20-32
Cutterbar, hold down clip, adjust	100-05-15	Knife Stalk Rolls	100-15-24
Cutterbar, knife drive arm adjust	100-05-13		
Cutterbar, knife drive case, repair	100-05-18		
Cutterbar, knife guard adjustment	100-05-14		
Cutterbar, Knife Register	100-05-14		
Cutterbar, Knife Removal and Installation	100-05-14		
Cutterbar, Knife Section Replacement . .	100-05-14		
Cutterbar, non-clog guards, adjust	100-05-17		
Cutterbar, Removing Dirt Buildup	100-05-32		
Cutterbar, Replacing Drive Belt	100-05-31		
Cutterbar, sections replace	100-05-16		

Index

	Page		Page
M		W	
Metric torque values	10-15-15	Warning light bulb, replace	100-05-40
P		2	
Pickup reel	100-05-33	200 and 900 Series Cutting Platform	
R		Cutterbar drive	100-05-30
Reel drive, 900 Series	100-05-36	Cutterbar drive case, inspect	100-05-22
Reel, remove	100-05-35	Cutterbar drive case, install	100-05-23
Rotary knife	100-20-28	Cutterbar drive case, installation	100-05-27
Row Unit	100-15-21	Disassembly	100-05-35
Row unit gearcase,		Guard alignment	100-05-14
40 Series Corn Head	100-10-20	Knife drive case	100-05-28
Row unit slip clutch,		Pickup reel	100-05-33
40 Series Corn Head	100-10-44	Reel Drive	100-05-36
90 Series Corn Head	100-15-55	Removal	100-05-35
Row Unit, Adjusting Deck Plates	100-15-20	200 and 900 Series Cutting Platforms	
Row Unit, Adjusting Gatherer Chain		Auger finger	100-05-18
Guides	100-15-20	Cylinder stop, 9400, 9500, 9600	100-05-11
S		Guards	100-05-12
Serial Number	10-10-1	Knives	100-05-12
Specifications,		Non-clog cutterbar guards, adjust	100-05-17
40 Series Corn Heads	10-15-6	4	
90 Series Corn Heads	10-15-9	40 Series Corn Head	
900 Series Platforms	10-15-3	Stalk roll shaft barrel,	100-10-38, 100-15-48
918 Draper Platform	10-15-5	Stalk roll shaft barrel, assembly	100-10-41, 100-15-52
Stabilizer, flex platform	100-05-31	40 Series Corn Heads	
Stalk rolls,		Deck plates, assembly	100-10-15
40 Series Corn Head	100-10-18	Deck plates, inspection	100-10-15
Stationary knife	100-20-30	Deck plates, removal	100-10-12
Stubble Light Bulb Replacement	100-10-51, 100-15-62	Drive shaft seal, assemble	100-10-26
Stubble light bulb, replace	100-05-39	Gatherer cap bushings, replace	100-10-30, 100-15-40
Stubble light bulb, replace cornhead	100-10-51	Gatherer chains, assembly	100-10-15
T		Gatherer chains, inspection	100-10-15
Torque values		Gatherer chains, removal	100-10-12
Inch	10-15-14	Gatherer drive shaft, assemble	100-10-26
Metric	10-15-15	Gearcase countershaft bushing,	100-10-27
Trash knives, adjust		Gearcase input shaft, replace	100-10-29
40 Series Corn Head	100-10-17	Gearcase needle bearing, replace	100-10-29
90 Series Corn Head	100-15-21	Gearcase seals, replace	100-10-29
		Gearcase, disassembly	100-10-23, 100-15-33
		Gearcase, removal	100-10-22
		Idle gear needle bearing, replace	100-10-31

INDX
2

	Page
40 Series Corn Heads—Continued	
Main drive shaft	100-10-47
Main drive shaft coupler	100-10-47
Row unit frame, removal	100-10-12
Row unit, assembly	100-10-15
Row unit, installation	100-10-15
Slip clutch, assembly	100-10-45, 100-15-56
Slip clutch, repair	100-10-45
Stalk roll shaft barrel, install	100-10-44, 100-15-55
Trash knives, assembly	100-10-15
Trash knives, inspection	100-10-15
Trash knives, removal	100-10-12

5

50 Series Row Crop Head	
Rotary knife, install	100-20-31
50A Series Row Crop Head	
Auger fingers	100-20-7
Auger brackets	100-20-9
Auger cranks	100-20-7
Auger fingers, replace	100-20-6
Auger hub, replace	100-20-5
Auger shafts	100-20-7
Auger, installation	100-20-5
Auger, removal	100-20-2
Cylinder safety stop	100-20-23
Gatherer chain drive	100-20-27
Gatherer sheets, remove	100-20-24
Rotary knife sections, adjusting	100-20-30
Rotary knife sections, replace	100-20-29
Rotary knife, remove	100-20-28
Row unit driver	100-20-10
Stationary knife, remove	100-20-30
Warning light bulb, replace	100-20-38
50A Series Row Crop Heads	
Gathering belts, replace	100-20-24

