

John Deere 310L (SN.C000001-,D000001-) Backhoe Loader Operation & Test Technical Manual (TM14156X19)



Type: Service Manual

Language: English

Pages: 487

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere 310L (SN.C000001-,D000001-) Backhoe Loader Operation & Test Technical Manual (TM14156X19)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:


- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

[20] - Tighten nuts to specification while prying to avoid gear case movement.

Item	Measurement	Specification
Gear Case Mounting Nuts	Torque	130 N-m (96 lb-ft)

[21] -



LEGEND:

A	Knife Head
B	Bearing Shield
C	Clearance

Bearing

Reset vertical position and angle of knife head (A). Check clearance of bearing shield (B) and recheck all clearances (C). Repeat procedure until proper clearance is achieved.

[22] -



LEGEND:

A	Cap Screw
---	-----------


Knife Head Cap Screw

Tighten cap screw (A) to specification.

Item	Measurement	Specification
Knife Head Cap Screw	Torque	130 N-m (96 lb-ft)

[23] - Verify that the knife section is still properly positioned in the first guard slot after the knife head cap screw is fully tightened.

[24] -



LEGEND:

A	Idler Arm
B	Idler Arm Lock Out
C	Yoke
D	Knife Assembly

Idler Arm Lock Out



Thank you very much
for your reading.
Please click here
to get more information.