
John Deere 350D and 400D Articulated Dump Truck Service Repair Technical Manual (TM1941)



Type: Service Manual Language: English Pages: 652 Format: PDF Features: Bookmarked, searchable, printable Compatibility: Windows/Mac/Tablet/Mobile This service manual contains important information for the maintenance, troubleshooting and servicing of the John Deere 350D and 400D Articulated Dump Truck Service Repair Technical Manual (TM1941)


In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only.** If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

Disassemble and Assemble Retarder and P3 Planetary



Retarder and P3 Planetary

L			
			 -

EL GLIND	
1	Retarder Housing Gasket
2	Cap Screw (12 used)
3	Cap Screw (2 used)



Thank you very much for your reading. Please click here to get more information.