

# John Deere 458, 558, 458 Silage Special Round Balers Service Repair Technical Manual (TM1735)

Section 10 - GENERAL

## Group 15 - General Information

### Machine Description—458, 458 Silage Special and 558



558

The 458, 458 Silage Special, and 558 Round Balers consist of the following major assemblies:

- Drive Train
- Pickup
- Bale Forming Belts and Rolls
- Bale Wrapping System

**Covers:** 458,458s,558

**Type:** Service Manual

**Language:** English

**Pages:** 735

**Format:** PDF

**Features:** Bookmarked, searchable, printable

**Compatibility:** Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere 458, 558, 458 Silage Special Round Balers Service Repair Technical Manual (TM1735)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

**Contents:**


- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

## Disassemble and Assemble Converging Drum Spindle Assembly

[1] - Remove converging drum spindle assembly. (See [Remove and Install Converging Drum and Spindle Assembly](#) in Section 30, Group 00.)

[2] - All spindle assemblies:



a.

### Drum

Position spindle assembly (A) on converging drum (B) and install cap screw (C). Tighten cap screw.

### LEGEND:

A Spindle Assembly  
B Converging Drum  
C Cap Screw



b.

### Inner Spindle Assembly


Insert bar (A) in converging drum to prevent unit from turning and use breaker bar and socket (B) to loosen spindle nut.

c. Leave spindle assembly in converging drum for stability.

### LEGEND:

A Bar  
B Breaker Bar and Socket

[3] -



### LEGEND:

A Washer  
B Flange Nut  
C Pulley  
D Bushing

### Drum

### Middle spindle assembly:

a. Remove flange nut (B) and washer (A)



Thank you very much  
for your reading.  
Please click here  
to get more information.