



John Deere 4630 Self-Propelled Sprayer (PIN Prefix 1YH) Service Repair Technical Manual (TM106119)

4630 Self-Propelled
Sprayer Repair

REPAIR TECHNICAL MANUAL
Self-Propelled Sprayers models 4630
TM106119 18 AUG 15 (ENGLISH)

For complete service information also see:

GreenStar 3 2630 Display Technical Solutions Manual	TM112219
JDPS Master Tool Manual	TM111119
4630 Self-Propelled Sprayer Diagnostic	TM106219
GreenStar 2 Diagnosis and Tests Manual	TM1061
Alternators and Stators	CTM77
PowerTech E 4.5L & 6.8L Diesel Engines (Tier 2/Stage II, Tier 3/Stage IIIA, Tier 3/Stage IIA, Tier 3/Stage III, (U.S. EPA 2007))	CTM104
100 Series Hydraulic Cylinders	CTM103519

PDF  **DOWNLOAD** 

John Deere Agriculture
Printed by Belgreen

TM106119

Covers: 4630,1YH)

Type: Service Manual

Language: English

Pages: 755

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere 4630 Self-Propelled Sprayer (PIN Prefix 1YH) Service Repair Technical Manual (TM106119)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:


- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

Repair Procedure R-AG

Remove Contact From Connector Body

[1] -




Connector

LEGEND:

A Locked Position
B Unlocked Position

Using a pick or small screwdriver, push internal secondary lock upward until unlocked position (B) is achieved.

[2] -




LEGEND:

A JDG10205 Terminal Extraction Tool
B Housing
C Wire

Connector

From terminal end of connector, insert JDG10205 Terminal Extraction Tool
Extraction Tool
JDG10205



JDG10205

To remove terminals from connector body.
(A) into housing (B) of terminal to be repaired.



Thank you very much
for your reading.
Please click here
to get more information.