


John Deere 4720 Self-Propelled Sprayers Service Repair Technical Manual (TM2229)

Section 10 - GENERAL INFORMATION

Group 10: General Information

Dimensions



Left-Hand Side

LEGEND:

- A Cab Height—Springs Inflated, 2299 mm (90.5 in.)
- B Under Frame Clearance, 1588 mm (62.5 in.)
- C Bottom of Ladder, 572 mm (22.5 in.)
- D First Platform Step, 1588 mm (62.5 in.)
- E Second Platform Step, 2007 mm (79.0 in.)
- F Top Platform, 2299 mm (90.5 in.)
- G Tire Center-to-Rearmost Boom Point, 1676 mm (66.0 in.)
- H Highest Point on Boom in Transport—60 ft. Boom, 3467 mm (136.5 in.)
- H Highest Point on Boom in Lowest Cradle Position—80/90 ft. Boom, 3832 mm (150.9 in.)
- H Highest Point on Boom in Highest Cradle Position—80/90 ft. Boom, 4115 mm (162.0 in.)
- I Wheelbase, 4211 mm (165.8 in.)
- J Front of Machine-to-Rear of Rear Tire, 6073 mm (239.1 in.)
- K Front of Machine-to-Rearmost Boom Point, 6848 mm, (270.0 in.)



DOWNLOAD



Type: Service Manual

Language: English

Pages: 691

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere 4720 Self-Propelled Sprayers Service Repair Technical Manual (TM2229)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.


Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

Input Yoke Remove and Install

[1] -



LEGEND:

A	Cap Screw
B	Washer
C	O-Ring
D	Yoke
E	Oil Seal

Cap Screw, Washer and O-Ring



Removing Yoke and Oil Seal

Remove cap screw (A).

[2] - Remove washer (B).

[3] - Remove O-ring (C).

[4] - Remove yoke (D).

[5] - Remove oil seal (E).

[6] - Apply medium strength thread lock and sealer to outside diameter of oil seal and petroleum jelly to inside diameter of new oil seal (E). Install using a disk driver.

Number	Name	Use
<ul style="list-style-type: none"> • T43512 (us) • TY9473 (canadian) • 242 LOCTITE™ (loctite) 	Thread Lock and Sealer (Medium Strength)	Apply to outside diameter of transmission input shaft oil seal.

[7] -

→NOTE:

Optimal white paste reduces spline wear.

Apply OPTIMOLY PASTE WHITE T™ on input shaft spline before installing yoke.

Number	Name	Use
• AT164660 (us)	OPTIMOLY PASTE WHITE T™	Apply to splines of transmission input shaft.

[8] -

IMPORTANT:

The yoke may need to be moved up and down until the seal lip is pointing out over the full circumference. Seal lip of oil seal must not be rolled when yoke is installed.



Thank you very much
for your reading.
Please click here
to get more information.