


John Deere R4040i Demountable Self-Propelled Crop Sprayer Service Repair Technical Manual (TM407419)



R4040i Chemical
Application Vehicle and
Demountable Crop Sprayer
Repair



REPAIR TECHNICAL MANUAL
Self-Propelled Sprayers models R4040i
TM407419 12 NOV 14 (ENGLISH)


For complete service information also see:

R4040i Chemical Application Vehicle and Demountable Crop Sprayer Diagnostic	TM407519
JDLink (MTG) Technical Manual	TM114519
JDPS Master Tool Manual	TM111119
Alternators and Starting Motors	CTM77
CTM441 - Machine	CTM441
120 Series Hydraulic	
PowerTech 6068 ECM Diesel ECU	



DOWNLOAD

John Deere Agriculture
Printed by Belgreen



TM407419

Covers: R4040i

Type: Service Manual

Language: English

Pages: 777

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile

This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere R4040i Demountable Self-Propelled Crop Sprayer Service Repair Technical Manual (TM407419)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.


Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

Remove and Install Drive Shaft

[1] -




LEGEND:

- A Shield
- B Cap Screws (2 used)

Shield

Remove cap screws (B) and upper shield (A).

[2] -




LEGEND:

- A Shield
- B Cap Screw (6 used)
- C Cap Screw (4 used)

Upper Shield

Remove cap screws (B and C) and shield (A).


[3] -



LEGEND:

- A Bracket
- B Cap Screw (8 used)
- C Cap Screw
- D Cap Screw (2 used)
- E Cap Screw (2 used)
- F Drive Shaft

Shield





Thank you very much
for your reading.
Please click here
to get more information.