


John Deere Tractors 5055E, 5065E, 5075E, 5078E, 5085E, 5090E Diagnostic & Tests Service Manual (TM801619)



Covers: 5075E,5078E,5085E,5055E,5065E,5090E

Type: Service Manual

Language: English

Pages: 1032

Format: PDF

Features: Bookmarked, searchable, printable

Compatibility: Windows/Mac/Tablet/Mobile


This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere Tractors 5055E, 5065E, 5075E, 5078E, 5085E, 5090E Diagnostic & Tests Service Manual (TM801619)**

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

Contents:

- General Information
- Specifications
- Serial Number Location
- Engine Specifications
- Engine Diagnostics
- Engine Tests and Adjustments
- Engine Repair
- Power Train
- Transmission
- Axles
- Differential
- PTO
- Hydraulic System
- Electrical System
- Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- Ignition and Charging
- Steering
- Brakes
- Wheels
- Operator's Platform
- Body Panels
- Disassembly and Assembly
- Diagnostics, Tests and Adjustments
- Troubleshooting
- and much more...

Please note this manual is in **downloadable PDF format only**. If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.

**LEGEND:**

18	Cap Screw (4 used)
21	Cap Screw (7 used)
22	Cover
23	Panel
A7	Air Conditioner Controller (ACF)
X51	Air Conditioner 4-Pin Connector
X52	Air Conditioner 10-Pin Connector


Heater and Air Conditioner Panel

Remove cap screws (18) and set air conditioner controller (ACF) (A7) aside. [See Cab Harness \(W1\) Component Location.](#) (Group 9015-10.)

[13] - Install identification tags and disconnect air conditioner 4-pin connector (X51) and air conditioner 10-pin connector (X52). [See Heater and Air Conditioner Harness \(W41\) Component Location.](#) (Group 9015-10.)

[14] - Remove cap screws (21), cover (22), and panel (23).

[15] -

**LEGEND:**

24	Cap Screw (2 used)
A11	Machine Controller

Machine Controller

Remove cap screws (24) and set machine controller (A11) aside.

[16] -



Thank you very much
for your reading.
Please click here
to get more information.