

# Impeller Mower-Conditioners 1326 and 1327




JOHN DEERE

## TECHNICAL MANUAL Impeller Mower-Conditioners 1326 and 1327

TM3260 (01Jun86) English

**John Deere Arc-lès-Gray**  
**TM3260 (01Jun86)**

LITHO IN U.S.A.  
ENGLISH





**1326 – 1327 MOWER CONDITIONERS  
TECHNICAL MANUAL  
TM 3260 (JUNE-86)**

**CONTENTS OF THIS MANUAL IN SECTIONS AND GROUPS**

**10 – GENERAL**

05 – Introduction  
10 – Specifications

**50 – POWER TRAIN – REPAIR**

05 – Powerline  
10 – Slip clutch  
20 – Gear case

**100 – CUTTING COMPONENTS – REPAIR**

05 – Disks  
10 – Cutterbar

**110 – HYDRAULIC SYSTEM – REPAIR**

05 – Lift cylinders

© by Deere & Co.; European Office  
D-6800 Mannheim

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TABLEMAT-CCL101AE-200885





# Section 10 GENERAL

## CONTENTS OF THIS SECTION IN GROUPS

### 05 – INTRODUCTION

Service literature .....	10-05-1
Safety .....	10-05-2
General recommendations for disassembly and inspection .....	10-05-2

### 10 – SPECIFICATIONS

General specifications .....	10-10-1
General torques for hardware .....	10-10-1
Locking collars for shaft bearings .....	10-10-2
Lubrication .....	10-10-2

GENERAL-CCL11001AE-200885



## SERVICE LITERATURE

This technical manual is part of a twin concept of service.

### FOS Manuals – for reference

### Technical Manuals – for actual service

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of trouble shooting, general maintenance, and basic types of failures and their causes. FOS manuals are for training new people and for reference to experienced technicians.

Some features of this technical manual:


Table of contents at front of manual

Exploded views showing parts relationship

Photos showing service techniques

This technical manual was planned and written for you – an experienced technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



X2252N,X2253N-CCL11005AE-200885

## **SAFETY**

Operator's Manuals of the relevant machines contain SAFETY rules for operation and service. Practice them to avoid ACCIDENTS.

RECOMGENE-CCL11005AE-200885

## **GENERAL RECOMMENDATIONS FOR DISASSEMBLY AND INSPECTION**

A good working organization as well as clean tools and work bench are a must for proper repair and service.

Use adequate tools, check all parts for serviceability and replace them if necessary.

Refer to relevant FOS Manuals for diagnosing component problems.

Follow given specifications and refer to Operator's Manual for safety procedures.

Use exploded views to identify parts.

Before commencing reassembly, make sure all parts (including replacements) are available on your work bench.

RECOMGENE-CCL11005BE-200885

**GENERAL SPECIFICATIONS**

Refer to the operator's manual of the relevant machine.

SPECGENE-CCL11010AE-200885

**GENERAL TORQUES**

**METRIC MEASUREMENT**

Bolt Diameter (A)	Bolt Torque in Nm (ft-lb)	
	8.8	10.9
5 mm	7 ( 5 )	9 ( 6.5 )
6 mm	10 ( 8.5 )	15 ( 10 )
8 mm	30 ( 20 )	40 ( 30 )
10 mm	50 ( 35 )	80 ( 60 )
12 mm	100 ( 75 )	140 ( 100 )
14 mm	160 ( 120 )	210 ( 155 )
16 mm	240 ( 175 )	350 ( 260 )
20 mm	480 ( 355 )	650 ( 480 )
24 mm	820 ( 605 )	1150 ( 850 )
30 mm	1640 (1210 )	2250 (1660 )

*NOTE: Bolts having lock nuts should be torqued to approximately 65% of amounts shown in above chart.*

This chart gives the recommended torques for hardware. Refer to this chart when no specified torque is mentioned in assembly procedures.


SPECGENE-CCL11005BE-200885

## LOCKING COLLARS FOR SHAFT BEARINGS

Locking collars (A) on bearings (B) must be kept tight at all times.

On rotating shafts (C), locking collars (A) will have to be secured in the direction of shaft rotation.

On stationary shafts (D), locking collars (A) will have to be secured in the opposite direction of bearing (B) rotation.



CC 2636

A—Locking collar

C—Rotating shaft

B—Bearing

D—Stationary shaft

CC2636-CCL11010AE-200885

## LUBRICATION

Quality of lubricant to be used and lubrication periods depend upon operating conditions.

**IMPORTANT: Refer to lubrication section of the Operator's Manual for procedure, proper oil specifications and recommended grease.**

SPECGENE-CCL11020CE-200885

# Section 50

## POWER TRAIN – REPAIR

### CONTENTS OF THIS SECTION IN GROUPS

#### 05 – POWERLINE

POWR-Gard PTO disassembly .....	50-05-1
POWR-Gard PTO reassembly .....	50-05-5
BONDIOLI PTO disassembly .....	50-05-8
BONDIOLI PTO shield disassembly .....	50-05-8
BONDIOLI PTO shield reassembly .....	50-05-9
BONDIOLI PTO hookup disassembly .....	50-05-10
BONDIOLI PTO hookup reassembly .....	50-05-11

#### 10 – SLIP CLUTCH

Specifications .....	50-10-1
Description .....	50-10-1
Slip clutch removal and disassembly .....	50-10-2
Slip clutch inspection .....	50-10-4
Slip clutch reassembly and reinstallation .....	50-10-4
Adjusting slip clutch .....	50-10-5

#### 20 – GEAR CASE


Special tools .....	50-20-1
Self-manufactured tools .....	50-20-2
Specifications .....	50-20-3
Assembly accessories .....	50-20-4
Torques for hardware .....	50-20-5


1326 Gear case	
Gear case removal .....	50-20-10
Gear case reinstallation .....	50-20-11
Primary drive removal .....	50-20-14
Primary drive reinstallation .....	50-20-15
Primary drive disassembly .....	50-20-15
Primary drive reassembly .....	50-20-16
Cutterbar drive removal .....	50-20-18
Cutterbar drive reinstallation .....	50-20-18
Cutterbar drive disassembly .....	50-20-19
Cutterbar drive reassembly .....	50-20-20
Impeller drive removal .....	50-20-21
Impeller drive reinstallation .....	50-20-22
Impeller drive disassembly .....	50-20-24
Impeller drive reassembly .....	50-20-24
Spiral bevel gear adjustment .....	50-20-25
Impeller bevel gear adjustment .....	50-20-26

1327 Gear case	
Gear case removal .....	50-20-27
Gear case reinstallation .....	50-20-28
Cutterbar drive removal .....	50-20-29
Cutterbar drive reinstallation .....	50-20-30
Cutterbar drive disassembly .....	50-20-30
Cutterbar drive reassembly .....	50-20-30
Primary drive removal .....	50-20-30
Primary drive reinstallation .....	50-20-33
Primary drive disassembly .....	50-20-33
Primary drive reassembly .....	50-20-34
Impeller drive removal .....	50-20-35
Impeller drive reinstallation .....	50-20-35
Impeller drive disassembly .....	50-20-35
Impeller drive reassembly .....	50-20-35
Spiral gear adjustment .....	50-20-36
Bevel gear adjustment .....	50-20-36

### POWR-GARD PTO DISASSEMBLY

The 1326-1327 mower conditioners are equipped with a front and a rear power line. Disassembly and re-assembly processes are identical for both parts.

 **CAUTION:** Never connect a 540 rpm mower-conditioner to a 1000 rpm tractor.




CC7296-CCL15005AE-200885

#### Remove PTO Shield

Remove hose clamp (A).

Remove the four cap screws (B).


Remove PTO shield (C).



CC7297-CCL15005AE-200885

#### Remove PTO Hookup

Remove cap screw (A) and PTO hookup.




CC7298-CCL15005AE-200885

#### Disassemble POWR-GARD PTO

Support push collar assembly (B) and remove snap ring (A).


Remove push collar and pushbutton latch.



E12122-CCL15005AE-200885




Push back on retainer collar, remove three steel balls (A) from yoke, remove retainer collar (B) and spring (C).




E18306-CCL15005AE-200885

Lift locking bearings (A) up and out of assembly. Remove closure shield from yoke.



E18307-CCL15005AE-200885

Hold in vise, positioned so shaft can't slip out.  
Remove locking bearings (A) from shield.  
Remove yoke and shaft assembly (B) from shield.




E18308-CCL15005AE-200885

Note position of grease fitting (A) prior to disassembly so it can be properly positioned during reassembly.

Remove snap rings (B) from outside.


If snap rings stick, loosen by tapping lightly on ends of bearings with a soft brass hammer or soft brass rod.



E18525-CCL15005AE-200885

Position joint in an open vise with each ear of one yoke supported by a vise jaw.


With a soft hammer or mallet, strike the top ear of the unsupported yoke. This will drive the top bushing outward approximately 9.5 mm (3/8 in.).



E19272-CCL15005AE-200885


Clamp loosened bearing in vise and drive yoke off.

Repeat this procedure for removing bearing directly opposite the one just removed, after which the yoke itself may be removed.



E19273-CCL15005AE-200885


To remove remaining two bushings, support cross as shown making certain that vise jaws are covered with brass protectors. By striking yoke ear, the remaining bushings can be removed as described above.



E19274-CCL15005AE-200885

Disassemble rear section of powershaft in same manner as front section.

Remove nylon bearing (A) from yoke and tube (B).



E18297-CCL15005AE-200885

## POWR-GARD PTO INSPECTION


1. Clean rust, dirt and paint from cap holders.
2. Replace spider and bearing assembly, if worn.



**CAUTION: Do not start tractor while inspecting shaft for straightness.**


3. Check yoke and tube, yoke and shaft for straightness using dial indicator (A). Max. run-out should be 0.90 mm (0.35 in.) in middle of hookup. If hookup is out of tolerance, straighten or replace.

4. Check shaft for roughness, nicks or pitting of surface.
5. Replace compression springs if cracked or rusted.
6. Replace nylon locking bearings if worn.



E21509-2015ZAH-260885

**POWR-GARD PTO – EXPLODED VIEW**



CC 7300

A-Snap ring  
 B-PTO shield  
 C-Latch  
 D-Retainer  
 E-Spring  
 F-Ball

G-Universal joint bearing  
 H-PTO shield  
 I-Universal joint yoke  
 J-Spring pin  
 K-Powershaft shield  
 L-Snap ring

M-Lubrication fitting  
 N-Cross and bearing assembly  
 O-Yoke with shaft  
 P-Cap screw  
 Q-Universal joint yoke  
 R-Nut

S-Powershaft shield  
 T-Yoke with shaft  
 U-Lubrication fitting  
 V-Guide

CC7300-CCL15005AE-200865

### POWR-GARD PTO REASSEMBLY

Reassemble joints. Start one bearing in yoke.  
Position center spider (A) through yoke.

Press bearing into yoke until flush with surface.


Clamp yoke in vise. Use a punch or socket with slightly smaller diameter than that of bearing and press bearing past snap ring groove.

Install snap ring (B).

Position cross and install bearing on opposite side.

Properly position grease fitting to allow greasing before installing third and fourth bearing.

Assemble remaining bearings and lubricate.




E18289-CCL15005AE-200885

If joint is stiff and does not flex freely after assembling, strike each ear of yoke on radius (A) to relieve pressure.



E18749-CCL15005AE-200885

Install closure shield assembly (A), shield (B) and shield bearings.




E18300-CCL15005AE-200885

*NOTE: Apply grease to bearing grooves.*


Install bearings (A) to retain shield as shown.

**A**—Locking bearings  
**B**—Direction of shaft rotation




E18303-CCL15005AE-200885

Install spring (A), retainer collar (B), and steel balls on yoke.



E18301-CCL15005AE-200885

Slide push button collar assembly (B) on yoke and secure with snap ring (A).



E18302-CCL15005AE-200885

## **POWR-GARD PTO REINSTALLATION**

Reverse POWR-GARD PTO removal and disassembly steps for reinstallation.

ARBRES-CCL15005AE-200885

## BONDIOLI PTO DISASSEMBLY

1326 and 1327 mower-conditioners are equipped with a front and a rear power line. Disassembly and re-assembly processes are identical for both parts.



**CAUTION:** Never connect a 540 rpm mower-conditioner to a 1000 rpm tractor.


APBRES-CCL15005BE-200885

### Remove PTO Shield

Remove hose clamp (A).

Remove the two upper and lower cap screws (B).

Remove drive shield (C).




CC7301

CC7301-CCL15005AE-200885

### Remove PTO Hookup

Remove cap screw (A) and PTO hookup.



CC7302

CC7302-CCL15005AE-200885

## PTO SHIELD DISASSEMBLY

Keep cone pressed downward and release catches by pushing with a screwdriver.



CC7303

CC7303-CCL15005AE-200885

**Remove Half Tube**


Open bearing ring to remove half tube.



CC7304-CCL15005AE-200885

**PTO SHIELD REASSEMBLY**

Grease bearing ring groove.



CC7305-CCL15005AE-200885

**Reinstall Shield Tube**


Fit shield tube onto bearing ring by centering the holes over the catches.



CC7306-CCL15005AE-200885

**Reinstall Cone Shield**

Fit cone centering grease fitting to grease filling hole on bearing ring. Press to connect.



CC7307-CCL15005AE-200885



**Check Assembly**

Make sure that catches are properly engaged by tapping on cone.




CC7308

CC7308-CCL15005AE-200885

**PTO HOOKUP DISASSEMBLY**

Remove PTO shield.

Press on snap ring.




CC7309

CC7309-CCL15005AE-200885

**Remove Snap Ring**

Remove snap ring with snap ring pliers.



CC7310

CC7310-CCL15005AE-200885

**Remove Bearing**

Remove the first bearing from the ear.



CC7311

CC7311-CCL15005AE-200885

### Remove First Bearing


Complete removal of first bearing.



CC7312-CCL15005AE-200885

### Remove Snap Ring

After removing snap ring, remove the second bearing.



CC7313-CCL15005AE-200885

### Remove Second Bearing

Remove bearings of outer yoke.



CC7314-CCL15005AE-200885

### PTO HOOKUP REASSEMBLY

Grease the inside of the bearings to hold the needles in place.




CC7315

CC7315-CCL15005AE-200885

### Install First Bearing


Push first bearing in the ear. Hold the needles in place using the journal arm.



CC7316-CCL15005AE-200885

### Install Second Bearing


Repeat the whole process for the second bearing. Adjust bearing position and insert both snap rings.



CC7317-CCL15005AE-200885

### Install Inner Yoke Bearing

Install inner yoke bearings. Make sure that the grease fitting faces the inner yoke.



CC7318-CCL15005AE-200885

### Adjust Bearing Position


Adjust the position of the bearings and insert both snap rings. Tap the ear base lightly to fully seat the snap rings and loosen the joint.



CC7319-CCL15005AE-200885

**Grease Bearings**


Grease the assembly. Pump grease until grease escapes through all four bearings.



CC7320-CCL15005AE-200885

**BONDIOLI PTO – EXPLODED VIEW**

- 1-Universal joint yoke
- 2-Latch
- 3-Universal joint cross
- 4-Lubrication fitting
- 5-Snap ring
- 6-Yoke, with shaft
- 7-Link chain
- 8-Bearing
- 9-Guard
- 10-Guard
- 11-Bearing
- 12-Guard
- 13-Guard
- 14-Drive shaft
- 15-Spring pin
- 16-Universal joint yoke
- 17-Yoke
- 18-Nut
- 19-Cap screw
- 20-Universal drive shaft
- 21-Universal drive shaft



CC5028-CCL15005AE-200885

**SPECIFICATIONS**

**1326**

<b>ITEMS</b>	<b>MEASUREMENT</b>	<b>WEAR TOLERANCE</b>
Lining (2 used), Oil soaked .....		minimum thickness = 2 mm (0.08 in.)
Spring length adjustment .....	36 mm ± 0.8 mm (1.41 in. ± 0.03 in.)	

**1327**

Lining (4 used), Oil soaked .....		minimum thickness = 2 mm (0.08 in.)
Spring length adjustment .....	40 mm ± 0.8 mm (1.57 in. ± 0.03 in.)	

LIMICOU-CCL15010AE-200885

**DESCRIPTION**

For both 1326 and 1327, the slip clutch transmits power between the power line and the gear case. If there is excessive power, the slip clutch acts as a safety device and slips to avoid damage to power train parts.

A one way free wheel is incorporated into the slip clutch. This allows relative speed between gear case and power line especially when the machine is being stopped.


Slip clutch springs must be adjusted to the specified length.

LIMICOU-CCL15010BE-200885

## Slip Clutch

### SLIP CLUTCH REMOVAL (1326 and 1327)


- Remove slip clutch shield.
- Remove the four cap screws (A).
- Remove slip clutch shield (B).



CC7321-CCL15010AE-200885

### Disconnect PTO Hookup


- Remove spring pin (C).
- Remove bushing (D).



CC7322-CCL15010AE-200885

### Remove PTO Hookup


- Pull out clutch yoke (A) from the clutch.
- Note the position of pawls (C) for proper re-installation.
- Do not discard washers (B).



CC7323-CCL15010AE-200885

### Remove Slip Clutch

- Pull out the slip clutch from the main shaft.
- Remove bushing (A).




CC7324-CCL15010AE-200885

### SLIP CLUTCH DISASSEMBLY

Remove the eight nuts.

Remove the eight cap screws.

Disassemble slip clutch.




CC7325

CC7325-CCL15010AE-200885

### 1326 SLIP CLUTCH, EXPLODED VIEW

- A-Washer
- B-Spring
- C-Clutch plate
- D-Clutch hub
- E-Clutch plate
- F-Nut
- G-Cap screw
- H-Lining




CC 7326

CC7326-CCL15010AE-200885

### 1327 SLIP CLUTCH, EXPLODED VIEW

- A-Washer
- B-Spring
- C-Clutch plate
- D-Lining
- E-Clutch disk
- F-Clutch disk
- G-Clutch disk
- H-Clutch disk
- I-Washer
- J-Nut
- K-Cap screw



CC7328-CCL15010AE-200885

### SLIP CLUTCH INSPECTION

Replace parts if cracked or damage from heat is apparent. Replace lining if warped, cracked or worn down to the specified thickness.  
Check disks for straightness.  
Check lining for glazing.

**IMPORTANT: New linings are oil soaked, do not clean.**

LIMICOU-CCL15010CE-200885

### SLIP CLUTCH REASSEMBLY AND REINSTALLATION


Reverse disassembly and removal procedure for slip clutch reassembly and reinstallation.

LIMICOU-CCL15010DE-200885



### SLIP CLUTCH ADJUSTMENT


Turn nut (A) until the specified spring length (B) is obtained.



CC7021-CCL15010AE-200885


SPECIAL TOOLS

D-01210AA




(A)

D-01267A



(B)

D-17525CI




(C)

D-17526CI




(D)

D-17517CI




(E)

JDG-94




(F)

JDH-6



(G)

JDG-114



(H)

CC 7504

A-To remove bearings  
B-To remove bearings

C-To measure gear backlash  
D-To measure gear backlash

E-To measure gear backlash  
F-To measure torque


G-To remove O-ring  
H-To remove snap ring

CC7504-CCL15020AE-200885

**SELF-MANUFACTURED TOOLS**

Wrench


To loosen lock nut of cutterbar shaft.



Adjustment plate

To measure bearing preload.  
To measure gear backlash.

*NOTE: Use medium iron for both tools.*



CC 7496

CC7496-CCL15020AE-200885

### SPECIFICATIONS

ITEMS	DIMENSIONS OF NEW PARTS
1326–1327 Maximum misalignment of impeller drive pulley .....	2.4 mm 0.094 in.
1326–1327 Spring deflection for belt drive idler .....	80 mm 3.15 in.
1326 Press measurement of cutterbar drive quill bearing lip seal .....	0.2 mm (+ 0.2 mm; - 0 mm) 0.008 in. (+ 0.008 in.; - 0 in.)
1326–1327 Axial play for cutterbar drive quill bearing .....	0.03 to 0.07 mm 0.00118 to 0.00275 in.
1326–1327 Impeller drive bearing preload torque .....	0.6 to 1.1 Nm 0.44 to 0.81 ft-lb
1326–1327 Primary drive bearing preload torque .....	1.1 to 2 Nm 0.81 to 1.48 ft-lb
1326–1327 Impeller plain bevel gear backlash .....	0.13 to 0.18 mm 0.0051 to 0.007 in.
1326–1327 Primary drive spiral bevel gear backlash .....	0.10 to 0.35 mm 0.0039 to 0.013 in.
1326 – Nominal shim thickness for primary drive, cutterbar drive and impeller drive covers and quill bearings .....	1 mm 0.004 in.
1327 – Nominal shim thickness for primary drive, cutterbar drive and impeller drive covers and quill bearings .....	1.5 mm 0.006 in.

RENOI-CCL15020AE-200885

**ASSEMBLY ACCESSORIES**

1326-1327 Sealing compound for bearing surfaces of quill bearing and gear case .....	Permatex Form-A-Gasket No. 2 or equivalent
1327 - Thread lock for the ten cap screw securing spiral bevel gear on its hub .....	Loctite 270 or equivalent
1326 - Adhesive sealing compound for the lip seal of the cutterbar drive .....	Loctite 242 and activator T or equivalent
1326 - Sealing compound for lip seals of primary drive and impeller drive .....	Permatex Form-A-Gasket No. 2 or equivalent
1327 - Sealing compound for lip seals of cutterbar drive, impeller drive and primary drive .....	Permatex Form-A-Gasket No. 2 or equivalent
Bearing grease .....	Mobilux 2 or equivalent

RENOI-CCL15020BE-200885

**TORQUES FOR HARDWARE**

1326–1327 Cap screws securing gear case to its bracket .....	230 ± 15 Nm (169 ± 11 ft-lb)
1326–1327 Cap screws securing primary drive, cutterbar drive, impeller drive to gear case .....	See general chart
1327 – Hex. socket screws securing spiral bevel ring gear to its hub .....	41 Nm (30 ft-lb)
1326–1327 Lock nut of nut on cutterbar drive shaft .....	125 ± 12 Nm (92 ± 9 ft-lb)
1326–1327 Gear case fill-and-drain plug .....	30 Nm (22 ft-lb)

### GEAR CASE DESCRIPTION


The gear case has three shafts with identical functions for the two machines:

- Primary drive shaft (input shaft)
- Cutterbar drive shaft
- Impeller drive shaft

The primary drive shaft, connected with the power-line, drives the cutterbar drive shaft by means of a spiral bevel gear set (these gears are matched) and also drives the impeller by means of a plain bevel gear set (these gears are not matched).

RENVOI-CCL15020DE-200885

### 1326 – PRIMARY DRIVE, EXPLODED VIEW




- |                     |                 |              |                |
|---------------------|-----------------|--------------|----------------|
| 1-Cotter pin        | 7-Bearing cup   | 13-Washer    | 19-Cap screw   |
| 2-Nut               | 8-Drive shaft   | 14-Snap ring | 20-Plate       |
| 3-Washer            | 9-Shim          | 15-Seal      | 21-Washer      |
| 4-Plain bevel gear  | 10-Quill        | 16-Pipe plug | 22-Lock washer |
| 5-Spiral bevel gear | 11-Bearing cup  | 17-Case      | 23-Cap screw   |
| 6-Bearing cone      | 12-Bearing cone | 18-Cap screw |                |

CC4612-CCL15020AE-200885

**1326 – CUTTERBAR DRIVE,  
EXPLODED VIEW**

- 1-Vent
- 2-Coupling
- 3-Shims
- 4-Spiral bevel gear
- 5-Bearing cone
- 6-Bearing cup
- 7-Quill bearing
- 8-Cap screw
- 9-Bearing cup
- 10-Bearing cone
- 11-Lip seal
- 12-Conical washer
- 13-Nut
- 14-Oil slinger
- 15-Nut
- 16-Tube support
- 17-Tube




CC4715

CC4715-CCL15020AE-200885



**IMPELLER DRIVE, EXPLODED VIEW**



CC 4281

- 1-Cap screw
- 2-Cover
- 3-Bearing cup


- 4-Bearing cone
- 5-Shim
- 6-Plain bevel gear
- 7-Shaft key

- 8-Drive shaft
- 9-Bearing cone
- 10-Bearing cup
- 11-Cover

- 12-Shim
- 13-Seal
- 14-Cotter pin

CC4281-CCL15020AE-200885

**1327 - PRIMARY DRIVE, EXPLODED VIEW**



CC4714

- 1-Pipe plug
- 2-Cotter pin
- 3-Nut
- 4-Washer

- 5-Plain bevel gear
- 6-Cap screw
- 7-Spiral bevel gear
- 8-Hub
- 9-Bearing cone


- 10-Bearing cup
- 11-Drive shaft
- 12-Shim
- 13-Quill
- 14-Bearing cup

- 15-Bearing cone
- 16-Washer
- 17-Snap ring
- 18-Seal
- 19-Cap screw
- 20-Case

CC4714-CCL15020AE-200885

**1327 – CUTTERBAR DRIVE,  
EXPLODED VIEW**

- 1-Vent
- 2-Coupling
- 3-Shim
- 4-Spiral bevels
- 5-Bearing cone
- 6-Bearing cup
- 7-Quill
- 8-Cap screw
- 9-Bearing cup
- 10-Bearing cone
- 11-O-Ring
- 12-Bushing
- 13-Lip seal
- 14-Snap ring
- 15-Nut



CC 4716


CC4716-CCL15020AE-200885

## GEAR CASE REMOVAL

### Release Idler Tension

Put the machine in raised position and engage safety stops.

Remove nuts (A) to release idler tension.




CC7337  
CC7337-CCL15020AE-200885

### Remove Impeller Drive Pulley

Remove drive belt (A) (groove by groove).

Remove cotter pin (B) and washers.

Remove pulley (C).



CC7338  
CC7338-CCL15020AE-200885

### Secure Gear Case

Remove slip clutch (see relevant group).

Install a piece of wood (A) between stop and platform to keep it in low position.

Secure gear case as shown.




CC7339  
CC7339-CCL15020AE-200885

### Loosen Gear Case Bottom

Thoroughly clean the gear case bottom area (B).

Remove the five self-locking nuts (A).

*NOTE: For convenience, use access port to remove nuts.*



CC7340  
CC7340-CCL15020AE-200885


## Gear Case

### Loosen Upper Gear Case

Pivot down L.H. skid shoe (A).

Remove the two cap screws (D), lock washers and plate securing gear case to bracket.

*NOTE: For convenience, use the lower access port.*



CC7341

CC7341-CCL15020AE-200865


### Remove Gear Case from Machine

Lift up and remove gear case.

Remove and keep washers (A).

Reinstall a new O-ring (B) (coated with oil) on cutterbar. Keep bearing area (C) clean.

Drain gear case if necessary (see operator's manual).




CC7342

CC7342-CCL15020AE-200865

### GEAR CASE REINSTALLATION

Sling the gear case and reinstall it.

Tighten the five self-locking nuts (A) of the gear case bottom.




CC7343

CC7343-CCL15020AE-200865

### Shim Gear Case on Bracket

Install washers (A) as needed to correctly shim the gear case on bracket.




CC7344-CCL15020AE-200885

### Bolt Gear Case to Bracket

Reinstall the plate, the two lock washers and the two cap screws (A) under the bracket.

*NOTE: Do not tighten cap screws at this stage.*



CC7351


CC7351-CCL15020AE-200885

### Adjust Pulley Parallelism

Grease shaft (A) and install drive pulley (B).

Clamp a straight iron bar (D) on the drive pulley. Check and adjust parallelism of pulley by loosening the four cap screws (C) to pivot gear case to centerline of cutterbar drive pulley.

Tighten the four cap screws and nuts (C).





CC7345

CC7345-CCL15020AE-200885

### Adjust Pulley Alignment

Add or remove washers behind pulley (A) not to exceed the specified dimension (B).

Install cotter pin (C).




CC 7499

CC7347,CC7499-CCL15020AE-200885

### Secure Gear Case

Tighten the two cap screws securing gear case to bracket to specified torque.

Reinstall skid shoe (A).



CC7346


CC7346-CCL15020AE-200885

### Reinstall Drive Belt and Slip Clutch

Reinstall drive belt (groove by groove).

Reinstall slip clutch (see relevant group).

Remove the piece of wood between platform and stop.




CC7497

CC7497-CCL15020AE-200885

### Reinstall Idler Pulley

Reinstall idler eyebolt and tighten nut (A) until specified spring deflection is obtained. Tighten lock nut.

Fill the gear case with oil if necessary (see operator's manual).




CC7381-CCL15020AE-200885

### PRIMARY DRIVE REMOVAL

#### Loosen Primary Drive

Remove the six cap screws (A).


Remove the two supports (B).



CC7348-CCL15020AE-200885

### Remove Quill

With a soft hammer loosen and remove quill.




CC7349-CCL15020AE-200885

### Clean Shims and Bearing Surfaces

Remove shims (A) and clean them.

Clean the bearing surfaces (B).




CC7350-CCL15020AE-200885

### PRIMARY DRIVE REINSTALLATION

Seal the bearing surfaces with specified sealing compound.  
Install correct thickness of shims.  
Install primary drive and tighten the six cap screws to the specified torque.

**IMPORTANT: Replacement of primary drive parts requires new adjustment of gears (see relevant group).**




CC7352

CC7352-CCL15020AE-200885

### PRIMARY DRIVE DISASSEMBLY

#### Remove Gears

- Remove primary drive (see relevant group).
- Remove cotter pin (A).
- Remove castellated nut (B).
- Remove plain bevel gear and spiral bevel gear.




CC7353

CC7353-CCL15020AE-200885

#### Remove Primary Drive Shaft

- With a soft hammer, remove shaft.
- Discard seal ring (A).
- Clean sealing area (B).




CC7354

CC7354-CCL15020AE-200885

#### Remove Bearing

- Press bearing out of shaft.



CC7355


CC7355-CCL15020AE-200885



## Gear Case

### Remove Bearing Cups

Remove the two opposite bearing cups, using D-01210AA slide hammer puller.



CC7357


CC7357-CCL15020AE-200885

### Remove Bearing

Remove bearing out of spiral bevel gear.

Use D-01267AA puller.

Simultaneously screw in the two cap screws (A) to separate bearing, then press out bearing.




CC7356

CC7356-CCL15020AE-200885

## PRIMARY DRIVE REASSEMBLY

### Press Bearing Cups

Press the two opposite bearing cups until cups bottom out against shoulder.




CC7359

CC7359-CCL15020AE-200885

### Reinstall Bearing

Press bearing until inner face bottoms out against shoulder.



CC7358


CC7358-CCL15020AE-200885

## Gear Case

### Reinstall Bearing on Shaft

Press bearing until inner race bottoms out against snap ring.

*NOTE: Do not forget to install the washer between snap ring and bearing.*



CC7360

CC7360-CCL15020AE-200885


### PRIMARY DRIVE REASSEMBLY

Reinstall shaft and pinions, reversing the previous steps.

Grease bearing with specified grease.

Do not tighten castellated nut (A) at this stage.

Do not spread cotter pin (B) at this stage.



CC7361


CC7361-CCL15020AE-200885

### Press Lip Seal

Put grease between the two lips of the lip seal.

Use specified sealing compound to retain seal in its housing.

Press lip seal until it is flush with the edge of the hub.



CC7362


CC7362-CCL15020AE-200885

### Adjust Bearing Preload

Bolt the special adjusting plate to the shaft (see self-manufactured tools).

Tighten castellated nut (A) to obtain the specified preload torque (use JDG 94 spring scale).

Secure castellated nut with cotter pin (B).



CC7363

CC7363-CCL15020AE-200885

### Reinstall Primary Drive

See relevant group for primary drive reinstallation.


RENVOI-CCL15020EE-200885

### CUTTERBAR DRIVE REMOVAL

Remove primary drive if necessary (see relevant group).

Remove the six cap screws (A).

Remove cutterbar drive.



CC7364


CC7364-CCL15020AE-200885

### Remove Support Tube

Clean shims and bearing surfaces (A).

Remove the four cap screws (B).

Separate cutterbar drive from support tube.




CC7365

CC7365-CCL15020AE-200885

### CUTTERBAR DRIVE REINSTALLATION

#### Index Quill Bearing

*NOTE: Quill bearing must be indexed before securing it.*



CC 7818

CC7818-CCL15020AE-200885

## Gear Case


### Secure Quill

Apply specified sealing compound to bearing surfaces.

Reinstall correct thickness of shims.

Tighten cap screws to the specified torque.

**IMPORTANT: Replacement of cutterbar drive parts may require adjustment of spiral bevel gears (see relevant group).**




CC7366-CCL15020AE-200885

### Reinstall Support Tube

Reinstall support tube, making sure that it is correctly positioned.

*NOTE: Do not tighten the four cap screws and nuts (A) to the final torque. They will be tightened after gear case reinstallation.*

Reinstall primary drive (see relevant group).




CC7367-CCL15020AE-200885

## CUTTERBAR DRIVE DISASSEMBLY

### Remove Lock Nuts

Remove cutterbar drive (see relevant group).


Loosen and remove nut and lock nut (A) as well as oil slinger (B).



CC7368-CCL15020AE-200885

### Remove Main Shaft

Press main shaft out of quill.




CC7369-CCL15020AE-200885

### Remove Bearing

Remove bearing from quill.

Discard lip seal (A).

Remove the two opposite bearing cups (B) in the same manner as the primary drive quill bearing cups.



CC7370


CC7370-CCL15020AE-200885

### CUTTERBAR DRIVE REASSEMBLY

#### Install Main Shaft

Press bearing cups into quill (same method as for primary drive quill bearing). Grease bearing with specified grease.

Install main shaft and press on bearing by tightening nut until axial play is four times greater than specified dimension (move quill bearing by hand). Use dial indicator D17525C1 – D17526C1 – D17C17C1.



CC7371

CC7371-CCL15020AE-200885


#### Prepare Lip Seal to Be Pressed

Remove nut from shaft.

Install conical washer (A).

Put grease between the two lips of the seal.

Use specified adhesive sealing compound to retain seal in its housing.




CC7372

CC7372-CCL15020AE-200885

#### Press Lip Seal

Press lip seal to the specified measurement (A).




CC7373

CC7373-CCL15020AE-200885

## Gear Case

### Install Nuts and Oil Slinger

Install the two nuts (B) and the oil slinger (A) between them.



CC7374


CC7374-CCL15020AE-200885

### Adjust Bearing Axial Play

Slightly tighten nut (A) against bearing. Tighten lock nut to the specified torque against nut (A). Simultaneously screw nut (A) and counter nut to adjust the specified bearing axial play (move quill bearing by hand).

**IMPORTANT: Never loosen nut (A) during operation.**

Recheck axial play after hitting both ends of shaft with a soft hammer and having rotated shaft several times.



CC7375


CC7375-CCL15020AE-200885

### IMPELLER DRIVE REMOVAL

#### Loosen Front Cover

Remove cotter pin (A).

Remove the four cap screws (B).



CC7376


CC7376-CCL15020AE-200885

#### Remove Main Shaft

Remove cover, remove lip seal (A) from cover and discard it.

Remove shaft from gear case, clean bearing surfaces (B) of cover and gear case.

Clean and keep shims.



CC7377

CC7377-CCL15020AE-200885

## Gear Case


### Remove Rear Cover

Remove the three cap screws.

Remove rear cover and shims.

Clean bearing surfaces (A) of cover and gear case.

Clean and keep shims.



CC7378-CCL15020AE-200885

### IMPELLER DRIVE REINSTALLATION

*NOTE: Replacing impeller drive parts may require a new bearing preload and/or bevel gear adjustment. Refer to the following instructions for bearing preload adjustment and to the relevant group for bevel gear adjustment. Go to "cover reinstallation" steps if no part is replaced.*

RENOI-CCL15020FE-200885


### BEARING PRELOAD ADJUSTMENT

#### Install Rear Cover

Temporarily install rear cover with the specified nominal thickness of shims.

Secure with three cap screws.

Remove primary drive (see relevant group).



CC7379-CCL15020AE-200885

#### Adjust Preload Torque


Grease bearing with specified grease.

Install main shaft and front cover with the specified nominal thickness of shims. Secure with two cap screws.

Bolt the adjustment plate (self-manufactured tool) to the main shaft.

Remove or add shims under rear cover to obtain the specified preload torque.

Use JDG 94 spring scale.



CC7380-CCL15020AE-200885

### Adjust Impeller Bevel Gear Backlash

Adjust impeller bevel gear backlash (see relevant group).

Reinstall primary drive (see relevant group).


RENVOI-CCL15020GE-200885

## COVER REINSTALLATION

### Reinstall Rear Cover

Apply specified sealing compound to bearing surfaces (A) and install the correct thickness of shims.

Tighten the three cap screws to the specified torque.




CC7378-CCL15020BE-200885

### Reinstall Front Cover

Grease bearing with specified grease and install main shaft.

Install front cover with shims and specified sealing compound on bearing surfaces.

Tighten the four cap screws to the specified torque.



CC7382-CCL15020AE-200885


### Reinstall Lip Seal

Wrap the splined shaft with thin oiled paper to avoid damaging seal lip.

Put grease between the two lips of the lip seal.

Use specified sealing compound to retain seal in its housing and press it into housing until it is flush with the surface of the cover.

Reinstall cotter pin on shaft and spread it.



CC7383-CCL15020AE-200885




### IMPELLER DRIVE DISASSEMBLY

#### Remove Bearings

Remove impeller drive (see relevant group).

Press bearings out of main shaft.

Use D-01267AA puller.




CC7384

CC7384-CCL15020AE-200885

#### Remove Bevel Gear

Press gear from main shaft.




CC7385

CC7385-CCL15020AE-200885

### IMPELLER DRIVE REASSEMBLY

#### Reinstall Bevel Gear

Put key (A) into its housing and press gear on shaft until gear bottoms out against shaft shoulder.




CC7386

CC7386-CCL15020AE-200885

#### Reinstall Bearings

Press bearings on shaft until inner races bottom out against shoulder.



CC7387

CC7387-CCL15020AE-200885

### SPIRAL BEVEL GEAR ADJUSTMENT

Remove primary drive, cutterbar drive and impeller drive (see relevant group).  
Clean and coat the teeth of the cutterbar drive with blueing.  
Install the primary drive with specified nominal thickness of shims (Gear teeth must be cleaned).  
Use two cap screws for securing.




CC7388-CCL15020AE-200885

### Check Tooth Contact

Install cutterbar drive with specified nominal thickness of shims. Use only two cap screws for securing.

Manually rotate primary shaft several turns in direction indicated.






CC7389-CCL15020AE-200885

### Adjust Tooth Contact

Look through the cutterbar drive bore for correct tooth contact:

- A—Contact is correct**
- B—Cutterbar bevel gear is too far away.**  
**Shims must be removed from cutterbar quill bearing.**
- C—Cutterbar bevel gear is too close.**  
**Shims must be added to cutterbar quill bearing.**

Repeat previous steps and change shim thickness until correct tooth contact is obtained.



CC 7390

CC7390-CCL15020AE-200885

### Check and Adjust Spiral Bevel Gear Backlash


Secure self-manufactured adjusting plate (A) to shaft. Install the dial indicator tip 100 mm (3.94 in.) from the shaft center.

Check specified backlash by moving spiral bevel gear and immobilizing cutterbar shaft.

*NOTE: Correct tooth contact normally involves correct backlash.*

Modify thickness of shims (B) of the primary drive quill bearing until backlash is obtained.

Install primary drive (see relevant group).



CC7391-CCL15020AE-200885

### IMPELLER BEVEL GEAR ADJUSTMENT

*NOTE: This adjustment must be made after the spiral bevel gear adjustment. Bearing preload adjustment of the impeller drive must be correct (see relevant group if necessary).*


Install impeller drive with specified nominal thickness of shims behind cover (A). Secure the covers with two cap screws.

**IMPORTANT: Total thickness of shims of the two covers must be maintained so that correct preload of roller bearings is not altered.**

Secure adjusting plate (B) to shaft. Install the dial indicator tip 50 mm (1.97 in.) from shaft center.

Immobilize cutterbar shaft and manually move the primary drive shaft.

Remove or add shims under cover (A) to obtain the specified backlash.




CC7392-CCL15020AE-200885

## GEAR CASE REMOVAL

### Release Idler Tension

Raise machine and engage safety stops (B).

Remove nuts (A) to release idler tension.



CC7393


CC7393-CCL15020AE-200885

### Remove Impeller Drive Pulley

Remove drive belt (A) (groove by groove).

Remove cotter pin (B) and washers (C).

Remove pulley (D).



CC7498

CC7498-CCL15020AE-200885

### Secure Gear Case

Remove slip clutch (see relevant group).

Install a piece of wood (A) between stop and platform to hold platform in low position.

Secure gear case as shown.

Remove the four cap screws (B) securing gear case to bracket.



CC7395


CC7395-CCL15020AE-200885

### Remove Gear Case from Machine

Lift up and remove gear case.

Drain gear case if necessary (see operator's manual).

Clean the bracket area.



CC7394


CC7394-CCL15020AE-200885

### 1327 – GEAR CASE INSTALLATION

Grease shaft and splines (A).

Reinstall the gear case onto its bracket.

Manually reinstall the four cap screws securing the gear case to its bracket.




CC7619

CC7619-CCL15020AE-200885

### Adjust Pulley Parallelism and Secure Gear Case

Grease shaft (A) and install drive pulley (B). Clamp straight iron bar (C) on drive pulley.

Adjust pulley parallelism by rotating gear case in the axis of cutterbar drive shaft. Secure gear to its bracket by tightening the four cap screws to the specified torque.





CC7396

CC7396-CCL15020AE-200885

### Adjust Pulley Alignment

Install or remove washers behind pulley (A) not to exceed specified dimension (B).

Install washer and spread cotter pin in hole (C).




CC7397,CC7499-CCL15020AE-200885

### Reinstall Drive Belt and Slip Clutch

Reinstall drive belt (groove by groove).

Reinstall slip clutch (see relevant group).

Remove the piece of wood between platform and stop.




CC7495-CCL15020AE-200885

### Reinstall Idler Pulley

Reinstall idler eyebolt and tighten nut (A) until specified spring deflection is obtained. Tighten lock nut.

Fill gear case with oil if necessary (see operator's manual).



CC7398-CCL15020AE-200885


### CUTTERBAR DRIVE REMOVAL

Remove gear case (see relevant group).

Remove the six cap screws (A).

Remove quill bearing and shims.

Clean bearing surfaces (B) and shims.




CC7399

CC7399-CCL15020AE-200885

### CUTTERBAR DRIVE REINSTALLATION

Reinstall cutterbar drive with correct thickness of shims. Seal bearing surfaces with specified sealing compound. Note that drain plug is indexed. Tighten cap screws to specified torque.

**IMPORTANT: Replacing cutterbar drive parts requires new adjustment of spiral bevel gears (see relevant group).**



CC7400

CC7400-CCL15020AE-200885


### CUTTERBAR DRIVE DISASSEMBLY

#### Remove Lock Nuts

Remove cutterbar drive (see relevant group).

Loosen and remove the nut and lock nut (A).

Use self-manufactured wrench (see self-manufactured tools).




CC7452

CC7452-CCL15020AE-200885

#### Remove Main Shaft

Press main shaft out of quill.




CC7453

CC7453-CCL15020AE-200885

## Gear Case

### Remove Sealing Bushing

Remove bushing (A).




CC7454-CCL15020AE-200885

### Remove O-Ring

Remove O-ring from bushing.

Use JDH-6 tool.




CC7455-CCL15020AE-200885

### Remove Snap Ring

Remove snap ring from quill bearing.

Use JDG-114 snap ring pliers.




CC7456-CCL15020AE-200885

### Remove Lip Seal and Bearing

Remove bearing and lip seal from quill bearing.

Discard lip seal (B).

Remove the two opposite bearing cups (A) in same manner as for 1326 (see relevant group).




CC7457-CCL15020AE-200885



## CUTTERBAR DRIVE REASSEMBLY

### Install Main Shaft

Press bearing cup into quill in the same manner as for 1326 (see relevant group).  
Grease bearing with specified grease.  
Install main shaft into quill and press bearing on shaft. Stop to press when the quill is about 3 mm (0.12 in.) axially loosened.




CC7458  
CC7458-CCL15020AE-200885

### Install Bushing and Nut

Clean lip seal area (D) with solvent.  
Oil a new O-ring and install it in bushing (A).

Install bushing (A) with its chamfer (B) in position shown.

Install nut (C).




CC7459  
CC7459-CCL15020AE-200885

### Adjust Bearing Preaxial Play

Tighten nut (A) until axial play is four times greater than specified dimension (move quill manually).

Use dial indicator D175251 – D 1756C1 – D 17C17C1.




CC7460  
CC7460-CCL15020AE-200885

### Adjust Bearing Axial Play

Install lock nut (B) and tighten to specified torque against nut (A). Simultaneously screw nut and lock nut to adjust specified bearing axial play (move quill manually).

**IMPORTANT: Never loosen nut (A) or lock nut (B) during operation.**

Recheck axial play after hitting both ends of shaft with a soft hammer and rotating shaft several times.




CC7461  
CC7461-CCL15020AE-200885

## Gear Case

### Install Lip Seal

Put grease between the two lips of the lip seal.

Press lip seal into quill until it bottoms out against the shoulder. Use specified sealing compound to seal lip seal in its housing.




CC7462-CCL15020AE-200885

### Reinstall Snap Ring

Reinstall snap ring.

Reinstall cutterbar drive (see relevant group).

Use JDG-114 snap ring pliers.




CC7456

CC7456-CCL15020AE-200885

### PRIMARY DRIVE REMOVAL

Remove cutterbar drive (see relevant group).

Remove primary drive. Refer to 1326 primary drive removal since the process is identical.



CC7576


CC7576-CCL15020AE-200885

### PRIMARY DRIVE REINSTALLATION

Reinstall primary drive with correct thickness of shims. Seal bearing surfaces with specified sealing compound.

Tighten the six cap screws to the specified torque.

**IMPORTANT: Replacing primary drive parts requires gear adjustment (see relevant group).**



CC7579

CC7579-CCL15020AE-200885


### PRIMARY DRIVE DISASSEMBLY

Remove primary drive (see relevant group).

Remove cotter pin (A).

Remove castellated nut (B).


Remove spiral bevel gear and plain bevel gear.



CC7575-CCL15020AE-200885

### Remove Shaft Bearing, Bearing Cups and Lip Seal

Refer to 1326 "Primary drive disassembly" from step "Remove primary drive shaft" to step "Remove bearing cups" since the process is identical.




CC7580-CCL15020AE-200885

### Disassemble Spiral Bevel Gear

Loosen and remove the ten cap screws (A).

Separate spiral bevel gear from its hub.




CC7581-CCL15020AE-200885

### Remove Bearing

Press bearing out of hub.

Use special tool D01267-A.



CC7582-CCL15020AE-200885

### PRIMARY DRIVE REASSEMBLY


#### Reassemble Spiral Bevel Gear

Clean hub threads with solvent.

Reassemble spiral bevel gear and hub.

Tighten cap screws to specified torque.


Use specified thread lock to secure cap screws.



CC7463-CCL15020AE-200885

#### Reassemble Primary Drive


Refer to 1326 "Primary drive reassembly" since the process is identical.



CC7574-CCL15020AE-200885

### IMPELLER DRIVE REMOVAL

Refer to 1326 "Impeller drive removal" since the process is identical.



CC7464-CCL15020AE-200885

### IMPELLER DRIVE REINSTALLATION

Refer to 1326 "Impeller drive reinstallation" since the process is identical.

RENVOI-CCL15020HE-200885

### **IMPELLER DRIVE DISASSEMBLY**

Refer to 1326 "Impeller drive disassembly" since the process is identical.

RENOI-CCL15020IE-200885

### **IMPELLER DRIVE REASSEMBLY**

Refer to 1326 "Impeller drive reassembly" since the process is identical.

RENOI-CCL15020JE-200885

### **SPIRAL BEVEL GEAR ADJUSTMENT**

Refer to 1326 "Spiral bevel gear adjustment" since the process is identical.

RENOI-CCL15020KE-200885

### **IMPELLER BEVEL GEAR ADJUSTMENT**

Refer to 1326 "Impeller bevel gear adjustment" since the process is identical.

RENOI-CCL15020LE-200885



# Section 100

## CUTTING COMPONENTS – REPAIR

### CONTENTS OF THIS SECTION IN GROUPS

#### 05 – DISKS

Specifications .....	100-05-1
Disk removal .....	100-05-2
Disk reinstallation .....	100-05-2

#### 10 – CUTTERBAR

Torque chart .....	100-10-1
Assembly accessories .....	100-10-1
Special tools .....	100-10-2
Cutterbar description .....	100-10-2

#### 1326 Cutterbar

Cutterbar removal .....	100-10-5
Cutterbar reinstallation .....	100-10-6
Cutterbar separation .....	100-10-7
Cutterbar reassembly .....	100-10-9
Pinion shaft removal & disassembly .....	100-10-11
Pinion shaft reassembly & reinstallation .....	100-10-13
Quill bearing removal & disassembly .....	100-10-13
Quill bearing reassembly & reinstallation .....	100-10-15
Intermediate gear removal & Disassembly .....	100-10-17
Intermediate gear reassembly & reinstallation .....	100-10-19
Drive gear removal .....	100-10-19
Drive gear reinstallation .....	100-10-21

#### 1327 Cutterbar

Cutterbar removal .....	100-10-22
Cutterbar reinstallation .....	100-10-25
Cutterbar separation .....	100-10-25
Cutterbar reassembly .....	100-10-26
Pinion shaft removal .....	100-10-27
Pinion shaft reinstallation .....	100-10-27
Quill bearing removal .....	100-10-28
Quill bearing reinstallation .....	100-10-28
Intermediate gear removal & disassembly .....	100-10-28
Intermediate gear reassembly & reinstallation .....	100-10-28

COUPE-CCL110001AE-200885





**TORQUES FOR HARDWARE**

Disk self locking nut ..... 180 ± 18 Nm  
(133 ± 13.3 ft-lb)


*NOTE: Locking nut must be replaced after five  
reinstallations.*

DISQUES-CCL110005AE-200885

## DISK REMOVAL

### Prepare the Machine


Put the machine in raised position and engage safety stops (A).  
Position tongue in operating position.  
Lock the safety screen (B) in raised position.  
Clean the concerned disk area.



CC7330-CCL110005AE-200885

### Loosen Self-Locking Nut


Use a piece of wood (A) to wedge the disks.  
Remove the self-locking nut and the cupped spring washer.



CC7331-CCL110005AE-200885

### Remove Disk

Remove the piece of wood.  
Remove disk using two crow-bars.



CC7332

CC7332-CCL110005AE-200885

## DISK REINSTALLATION


**IMPORTANT:** Before reinstalling disk, clean splines and seating surfaces.

DISQUES-CCL110005BE-200885

### Reinstall Disk

Reinstall disk on its shaft.

**IMPORTANT:** Each disk must be perpendicular to its neighbour. This is a general rule for 1326 (6 disks) and 1327 (7 disks) cutterbars.



CC 7033


CC7033-CCL110005AE-200885

### Install Self-Locking Nut

Reinstall the cupped spring washer (A) in correct direction.

Manually reinstall the self locking nut (B).

**IMPORTANT:** Replace the self-locking nut after five reinstallations.



CC 7333


CC7333-CCL110005AE-200885

### Tighten Disk

Install a piece of wood to wedge disk.

Tighten self-locking nut to specified torque.

Remove the piece of wood.



CC7334

CC7334-CCL110005AE-200885

### Check the Installation

Move disk manually up and down and rotate it to check correct installation.

Lower safety screen.

DISQUES-CCL110005CE-200885

**TORQUES FOR HARDWARE**

1326-1327 Hex. socket screws securing the two halves of cutterbar in the middle .....	360 Nm (265 ft-lb)
1326-1327 Cap screws securing the cutterbar in the periphery .....	70 Nm (51 ft-lb)
1327 – Cap screws securing both sides of cutterbar to the machine .....	127 ± 13 Nm (90 ± 10 ft-lb)
1326-1327 Four cap screws securing disk quill bearing inside of the cutterbar .....	70 Nm (51 ft-lb)

BARRE-CCL110010AE-200885

**ASSEMBLY ACCESSORIES**

1327 – Lock thread securing self-locking nut of the L.H. disk .....	Loctite 270 or equivalent
1326-1327 Adhesive compound to retain cutter- bar O-ring for convenient operation .....	Cyanocrilate adhesive or Neoprene bond

BARRE-CCL110010BE-200885


**SPECIAL TOOLS**

**JDH-6**




**A**

**D-01267A**




**B**

**D-01210AA**



**C**

**JDE-76A**



**D**

CC7500

A-To remove O-ring  
B-To remove bearing

C-To remove bearing  
D-To install or remove bearing and lip seal

CC7500-CCL110010AE-200885


**DESCRIPTION**

Two steel case halves enclose a bearing mounted gear assembly. 1326 cutterbar has six disks; The components of the gear assy. are one main drive gear with splined drilled drive shaft, six timed pinion shafts for each disk and intermediate

gears to transmit and reverse rotation. 1327 cutterbar has seven disks, there is an additional pinion shaft for the seventh disk and the main drive. All gears are helical machined type and run in oil bath.

BA9RE-CCL110010CE-200885

1326 CUTTERBAR, EXPLODED VIEW




CC 7583

- |                           |                     |                            |                      |
|---------------------------|---------------------|----------------------------|----------------------|
| 1-Upper half of cutterbar | 8-Oil seal          | 15-Washer                  | 22-Drive gear        |
| 2-Bearing                 | 9-Bearing           | 16-Lower half of cutterbar | 23-Intermediate gear |
| 3-O-ring                  | 10-Deflector washer | 17-Hex. socket screw       | 24-Intermediate gear |
| 4-O-ring                  | 11-Snap ring        | 18-Quill cap screw         | 25-Pinion shaft      |
| 5-Quill                   | 12-Bearing          | 19-Snap ring               | 26-Intermediate gear |
| 6-O-ring                  | 13-Snap ring        | 20-Snap ring               | 27-Intermediate gear |
| 7-Spacer                  | 14-Plastic bushing  | 21-Drive gear bearing      | 28-O-ring            |

CC7583-CCL110010AE-200885

1327 CUTTERBAR, EXPLODED VIEW



CC 7494

1-Upper half of cutterbar  
 2-O-ring  
 3-O-ring  
 4-O-ring  
 5-Quill

6-Snap ring  
 7-Bearing  
 8-Snap ring  
 9-Plastic bushing

10-Washer  
 11-Lower half of cutterbar  
 12-Hex. socket screw  
 13-Quill cap screw


14-Intermediate gear  
 15-Pinion shaft  
 16-Intermediate gear  
 17-O-ring

CC7494-CCL110010AE-200885

## CUTTERBAR REMOVAL

### Prepare Machine


Raise the machine and engage safety stops (A).  
Open tongue (B).  
Lock safety screen in upper position.  
Drain cutterbar if necessary (see operator's manual).



CC7330  
CC7330-CCL110010BE-200885

### Access to L.H. Side of Cutterbar

Pivot down L.H. skid shoe (A).  
Clean L.H. cutterbar area.  
Put an adequate lifting device under the middle of the cutterbar.




CC7486  
CC7486-CCL110010AE-200885

### Loosen L.H. Side of Cutterbar

Remove the two cap screws and nuts (A) and the six lock nuts (B) securing L.H. side of cutterbar.

*NOTE: Use access hole for convenience to remove the self-locking nuts.*




CC7401  
CC7401-CCL110010AE-200885

### Loosen R.H. Side of Cutterbar

Remove R.H. disk (see relevant group).  
Remove the four cap screws (A) and two lock nuts (B).

*NOTE: Length of cap screws is different, note their location for proper reinstallation.*



CC7402  
CC7402-CCL110010AE-200885



## Cutterbar


### Remove Cutterbar

Lower cutterbar using lifting device.

Remove and discard O-ring (A).

Keep bearing area (B) clean.

Remove and keep plate spacer (C).




CC7403-CCL110010AE-200885

### CUTTERBAR REINSTALLATION

#### Prepare O-Ring

Clean the O-ring and bearing surface.

Oil a new O-ring (B) and install it.



CC7487-CCL110010AE-200885

#### Secure Cutterbar


Reinstall cutterbar on the machine.

Tighten the four cap screws and two lock nuts to secure R.H. side of cutterbar.

Reinstall plate spacer (A) between cutterbar and bracket.

Bolt L.H. side of cutterbar.

Reinstall L.H. skid shoe.



CC7488-CCL110010AE-200885

#### Final Assembly

Reinstall R.H. disk (see relevant group).

Reinstall safety screen.

Fill cutterbar with oil if necessary (see operator's manual for proper oil specifications and quantity).

BARRE-CCL110010DE-200885

## Cutterbar


### CUTTERBAR SEPARATION

Remove cutterbar (see relevant group).

Remove disks (see relevant group).

Clean entire cutterbar.

Drain cutterbar (see Operator's Manual).



CC7404


CC7404-CCL110010AE-200885

### Remove Skid Plates

Loosen the two cap screws (A).

Remove lock nut (B).

Remove skid plate (C).



CC7405

CC7405-CCL110010AE-200885

### Remove Wear Plates


Remove the ten cap screws and nuts (A).

Remove the thirteen cap screws (B).

*NOTE: Do not remove cap screws and nuts in front of each quill bearing.*

Remove the four wear plates (C).

*NOTE: Length of cap screws is different. Note their location for proper reinstallation.*




CC7406

CC7406-CCL110010AE-200885

### Remove Hex. Socket Screws

Symmetrically remove the hex. socket screws starting from the center toward each end.

**IMPORTANT: Maintain each screw area firmly tightened with proper tool while operating.**



CC7407

CC7407-CCL110010AE-200885

## Cutterbar


### Remove Angles and Reinforcements

Turn over cutterbar.

Remove the remaining nuts and screws.

Remove angles and reinforcements (A).

*NOTE: Length of cap screws is different. Note their location for proper reinstallation.*



CC7408-CCL110010AE-200885


### Separate Cutterbar

Gently separate cutterbar halves.

Collect and keep washers (A).

Discard plastic bushings (B).

Remove and discard O-ring (C).



CC7409-CCL110010AE-200885

### Clean Cutterbar

Clean cutterbar with a dry cloth.

Remove all foreign material from cutterbar.

Clean the two O-ring areas.


BARRE-CCL110010EE-200885

## CUTTERBAR REASSEMBLY

### Check Intermediate Gears

Check that all intermediate gears (A) are properly positioned on their shafts. Mark gears with a center punch for retiming, if necessary.

**IMPORTANT:** All pinion shafts (B) are timed. Do not change their relative positions. See Step "Pinion Shaft Removal" for timing, if necessary.




CC7410-CCL110010AE-200885

### Install Sealing Bushings

Install new plastic bushings (A).

*NOTE: These plastic bushings have the dual function of sealing and locking the hex. socket screw. Make sure that they are properly seated.*

Use grease to hold washers (B) in position.



CC7411-CCL110010AE-200885

### Install New O-Ring

Install a new O-ring in its housing.

*NOTE: Apply specified adhesive compound at four points of the circumference to hold O-rings for convenient installation.*




CC7412-CCL110010AE-200885

### Reassemble Cutterbar

Reinstall cutterbar by gently turning the upper half (A) over the lower half.

Looking through joint (B) be sure O-ring remains installed in its housing.


Clamp both sides of the cutterbar.



CC7413  
CC7413-CCL110010AE-200885

### Check Timing


Check disk timing by temporarily installing them. Each disk must be perpendicular to its neighbour. This is a general rule. See Step "Pinion Shaft Removal" for timing, if necessary.



CC7414  
CC7414-CCL110010AE-200885

### Reinstall Hex. Socket Screws


Symetrically reinstall hex. socket screws from the center towards each end. Tighten to the specified torque.



CC7415  
CC7415-CCL110010AE-200885

### Reinstall Reinforcements

Prepare the two front reinforcements (A) for reinstallation. Prepare the two rear reinforcements (B) for reinstallation.




CC7416  
CC7416-CCL110010AE-200885

## Cutterbar

### Bolt Cutterbar Reinforcements

Bolt the rear reinforcement (A) with five cap screws (in front of quill bearings). Bolt the front reinforcement with cap screws (B). Install the five short reinforcements (C) and bolt them with nuts and cap screws (in front of quill bearings).


Tighten hardware to specified torque.



CC7417-CCL110010AE-200885

### Reinstall Wear Plates


Bolt the five wear plates (A) with nine cap screws and nuts. Install the eleven cap screws (B) of the rear reinforcement. Install the two cap screws (C) of the front reinforcement. Tighten hardware to specified torque.



CC7418-CCL110010AE-200885

### Reinstall Skid Plates

Reinstall skid plates (C). Tighten lock nut (B). Tighten cap screws (A). Reinstall cutterbar (see relevant group).



CC7489-CCL110010AE-200885

### PINION SHAFT REMOVAL AND DISASSEMBLY


Separate cutterbar (see relevant group).

BARRE-CCL110010FE-200885

### Time Pinion Shafts

Rotate one pinion shaft (A) to align its engraved mark (B) with the axis of the cutterbar. All other engraved marks on pinion shafts must be perpendicular to their neighbour.

This is a general rule for 1326 and 1327 cutterbars.




CC7419

CC7419-CCL110010AE-200885

### Remove Pinion Shaft

Maintain neighbouring gears firmly clamped with two iron sheets.

Remove pinion shaft with a smooth hammer.




CC7420

CC7420-CCL110010AE-200885

### Remove O-Ring

Remove O-ring from pinion shaft.

Use JDH-6 O-ring hook.




CC7421

CC7421-CCL110010AE-200885

### Remove Pinion Shaft Bearing

Press bearing off pinion shaft.

Use D-01267AA bearing puller.




CC7422

CC7422-CCL110010AE-200885

## PINION SHAFT REASSEMBLY AND REINSTALLATION

### Reinstall Bearing

Press bearing until bearing inner race bottoms against gear shoulder.




CC7423-CCL110010AE-200885

### Reinstall New O-Ring

Oil new O-ring (A), install carefully on shaft and seat against bearing.

*NOTE: Shaft splines can be wrapped with thin oiled paper to protect O-ring during assembly.*




CC7424

CC7424-CCL110010AE-200885

### Reinstall Pinion Shaft

Reinstall pinion shaft with a smooth hammer. Check that engraved mark (A) is correctly positioned in its previous direction. Check that all engraved marks on pinion shafts are perpendicular. This is a general rule for 1326 and 1327 cutterbars.

Reassemble cutterbar (see relevant group).



CC7425

CC7425-CCL110010AE-200885

## QUILL BEARING REMOVAL AND DISASSEMBLY


Remove pinion shaft (see relevant group).

BARRE-CCL110010GE-200885



**Remove Quill Bearing**

Remove the four cap screws and remove quill bearing from cutterbar half.




CC7426  
CC7426-CCL110010AE-200885

**Remove O-Rings**

Remove the four O-rings (A) and discard.

Remove spacer (B) (Only for replaceable quill bearing).

Remove deflector washer (C) located on opposite side (D).




CC7427  
CC7427-CCL110010AE-200885

**Remove Bearing  
(Only for replaceable quill)**

Remove bearing from quill.

Use JDE-76A pilot bearing adapter.




CC7428  
CC7428-CCL110010AE-200885

**Remove Lip Seal**

Remove lip seal from quill.

Use JDE-76A pilot bearing adapter.




CC7429  
CC7429-CCL110010AE-200885

## QUILL BEARING REASSEMBLY AND REINSTALLATION

### Reinstall a New Oil Seal

Put grease between the two lips of the seal.  
Press a new oil seal into quill until seal lip side is flush with quill surface.  
Use JDE-76A pilot bearing adapter.


*NOTE: Be careful to press lip seal in the right direction.*



CC7430-CCL110010AE-200885

### Reinstall Bearing


Press bearing until bearing bottoms out against casting shoulder.



CC7431-CCL110010AE-200885


### Reinstall Deflector Washer

Put grease in area (A) and install deflector washer (B) into its housing.



CC7432-CCL110010AE-200885

*NOTE: Install deflector washer (B) with concave face upward.*




CC 7433

CC7433-CCL110010AE-200885

## Cutterbar

### Reinstall O-Rings

Clean bearing surface.  
Oil new O-rings and install them into their housing.




CC7434

CC7434-CCL110010AE-200885

### Reinstall Quill Bearing

Clean quill bearing surface on cutterbar.  
Reinstall quill bearing with four new cap screws (new cap screws are coated with lock thread).

*NOTE: Do not tighten cap screws.  
Quill bearing must be slightly loose.*



CC7426

CC7426-CCL110010BE-200885


### Reinstall Pinion Shaft

Reinstall pinion shaft (see relevant group).

BARRE-CCL110010HE-200885

### Bolt Quill Bearing

Tighten the four new cap screws of the quill bearing to specified torque. Reassemble cutterbar (see relevant group).



CC7435

CC7435-CCL110010AE-200885

## INTERMEDIATE GEAR REMOVAL AND DISASSEMBLY

Separate cutterbar (see relevant group).


BARRE-CCL110010IE-200885

### Remove Intermediate Gears

Maintain neighbouring gears firmly clamped with two iron sheets

Remove intermediate gears with two levers.

**IMPORTANT: Do not modify relative position of neighbouring gears. See Step "Pinion Shaft Removal" for timing if this should occur.**




CC7436

CC7436-CCL110010AE-200885

### Separate Inner Race Bearing

Separate inner race bearing from its seat using a chisel.




CC7437

CC7437-CCL110010AE-200885

### Remove Inner Race Bearing

Remove inner race bearing with slide hammer.

Use D-01210AA slide hammer.




CC7438

CC7438-CCL110010AE-200885

### Intermediate Gear Disassembly

Mark snap ring with a chisel 10 mm (0.4 in.) from one end.




CC7439

CC7439-CCL110010AE-200885

### Bend Snap Ring

Clamp snap ring 40 mm (1.05 in.) from opposite marked end, insert a screwdriver into mark and bend snap ring.




CC7440

CC7440-CCL110010AE-200885

### Remove Snap Ring

Use a second thin screwdriver to remove snap ring from its housing.




CC7441

CC7441-CCL110010AE-200885

### Remove Bearing

Press bearing out of gear.

Use JDE-76A pilot bearing adapter.



CC7442


CC7442-CCL110010AE-200885

## INTERMEDIATE GEAR REASSEMBLY AND REINSTALLATION

### Reinstall New Bearing

Prepare a new bearing to be pressed.

*NOTE: In order to avoid separation of the two bearing parts, keep inner plastic bushing (A) in place.*




CC7443

CC7443-CCL110010AE-200885

### Press Bearing – Install Snap Ring

Press bearing until it bottoms out against the opposite snap ring.

Install snap ring.



CC7444


CC7444-CCL110010AE-200885

### Reinstall Intermediate Gear

With a smooth hammer reinstall gear on cutterbar until bearing bottoms out against bearing surface.

*NOTE: This gear is not symmetrical. Refer to its neighbouring gear for proper side mounting.*  
*NOTE: The old inner bearing race can be used for installing bearing.*

Reassemble cutterbar (see relevant group).



CC7445

CC7445-CCL110010AE-200885

## DRIVE GEAR REMOVAL


Separate cutterbar (see relevant group).

BARRE-CCL110010JE-200885

## Cutterbar

### Retain Gears

Retain gears with an iron sheet.



CC7446-CCL110010AE-200885

### Remove Drive Gear Snap Ring


Gently turn over cutterbar.  
With snap ring pliers remove drive gear snap ring.



CC7447-CCL110010AE-200885

### Remove Drive Gear


Remove drive gear from bearing.



CC7448-CCL110010AE-200885

### Remove Bearing Snap Ring

With snap ring pliers remove snap ring.




CC7449-CCL110010AE-200885

## Cutterbar

### Remove Bearing

With a smooth hammer remove bearing from its housing.

*NOTE: Bearing is not press fitted and this operation does normally not require much force.*




CC7450

CC7450-CCL110010AE-200885

### DRIVE GEAR REINSTALLATION

Grease bearing (A) and reinstall it into its housing.

With snap ring pliers reinstall snap ring.




CC7491

CC7491-CCL110010AE-200885

Gently turn over cutterbar half.

Reinstall drive gear.

*NOTE: There is no timing for this gear.*



CC7451

CC7451-CCL110010AE-200885

### Reinstall Snap Ring


Gently turn over cutterbar half.

With snap ring pliers reinstall snap ring.

Grease area (A).

Turn over cutterbar and remove iron sheet.

Reassemble cutterbar (see relevant group).



CC7492

CC7492-CCL110010AE-200885



## CUTTERBAR REMOVAL

### Prepare Machine


Raise the machine and engage safety latches (A).  
Open tongue.  
Drain cutterbar, if necessary (see operator's manual).



CC7465-CCL110010AE-200885

### Remove Left-Hand Divider


Remove the three cap screws (A).  
Remove L.H. divider (B).



CC7466-CCL110010AE-200885

### Remove Right-Hand Divider


Remove cap screws (A).  
Remove R.H. divider (B).



CC7467-CCL110010AE-200885

### Disconnect Main Shaft

Remove spring pin (A). Disconnect spider from attenuator (B) and remove spider.




CC7468-CCL110010AE-200885

## Cutterbar

### Remove Cutterbar Shaft

Remove drive shaft (A).




CC7469

CC7469-CCL110010AE-200885

### Remove Upper Shield

Remove cap screws (A).

Remove upper shield (B).




CC7470-CCL110010AE-200885

### Remove Disk Deflector

Remove cap screws (A).

Remove upper deflector (B).




CC7471

CC7471-CCL110010AE-200885

### Remove Attenuator

Remove spider with its attenuator (A) from the drive disk. Block the disks as shown in (B).



CC7472


CC7472-CCL110010AE-200885

## Cutterbar

### Remove Outer Disks

Remove right-hand disk (see relevant group).


Remove left-hand disks in the same manner.



CC7473-CCL110010AE-200885

### Remove Adjustable Skid Shoes

Remove adjustable left-hand and right-hand skid shoes (A).




CC7474-CCL110010AE-200885

### Remove Disk Shoes

Remove left-hand and right-hand disk shoes (A).

Clean both sides of cutterbar.




CC7475-CCL110010AE-200885

### Remove Cutterbar

Put an adequate lifting device under the middle of the cutterbar.

Remove cap screws and nuts (A) (four on right-hand and five on left-hand side). Carefully keep them to be reinstalled in the same place.

Remove cutterbar.



CC7476-CCL110010AE-200885


## CUTTERBAR REINSTALLATION

### Secure Cutterbar

Reinstall cutterbar on machine using the lifting device.

Tighten cap screws (A) to the specified torque.

*NOTE: For proper tightening immobilize cap screw and apply the torque to the nut.*



CC7476


CC7476-CCL110010BE-200885

### Reinstall Disk Shoes and Disks

Reinstall left-hand and right-hand disk shoes (reverse the disk shoe removal step).

Reinstall right-hand disk (see relevant group).

Reinstall left-hand disk. Refer to instructions given for right-hand disk. Use specified lock thread for nut on this disk.



CC7477

CC7477-CCL110010AE-200885

### Final Assembly

Reverse disassembly procedure for installation of remaining parts.

BARRE-CCL110010KE-200885


## CUTTERBAR SEPARATION

Remove cutterbar (see relevant group).

Remove disks (see relevant group).

Drain cutterbar (see operator's manual).

Remove the remaining disk shoes and cleaning plates (B) by removing cap screws and nuts (A).




CC7478

CC7478-CCL110010AE-200885

## Cutterbar

### Remove Stiffener

Remove all bolts (A) to separate stiffener (B) from cutterbar (C). Do not remove bolts (D) which are located in front of each disk hub. Clean cutterbar.



CC7479-CCL110010AE-200885

### Separate Cutterbar

Refer to 1326 "Cutterbar Separation" group at step "Remove Hex. Socket Screws" since the process is identical.

BARRE-CCL110010LE-200885


### CUTTERBAR REASSEMBLY

Refer to 1326 "Cutterbar Reassembly" group up to step "Reinstall Hex. Socket Screws" since the process is identical.

BARRE-CCL110010ME-200885

### Secure Cutterbar

Reinstall cap screws in front of each quill bearing and tighten to specified torque.




CC7481

CC7481-CCL110010AE-200885

## Cutterbar

### Reinstall Stiffener

Secure stiffener (A) to cutterbar with cap screws (B).




CC7482-CCL110010AE-200885

### Reinstall Disk Shoes

Reinstall and secure the remaining disk shoes (B) and cleaning plates.

Tighten cap screws (A).



CC7478-CCL110010AE-200885

### PINION SHAFT REMOVAL

Refer to 1326 "Pinion Shaft Removal and Disassembly" group up to step "Remove Pinion Shaft" since the process is identical.

BARRE-CCL1100100E-200885

### PINION SHAFT REINSTALLATION

Refer to 1326 "Pinion Shaft Reassembly and Reinstallation" at step "Reinstall Pinion Shaft" since the process is identical.

BARRE-CCL110010PE-200885

### **QUILL BEARING REMOVAL**

Refer to 1326 "Quill Bearing Removal and Disassembly" up to step "Remove O-rings" since the process is identical.

BARRE-CCL110010QE-200885

### **QUILL BEARING REINSTALLATION**

Refer to 1326 "Quill Bearing Reassembly and Reinstallation" from step "Reinstall Deflector Washer" since the process is identical.

BARRE-CCL110010RE-200885

### **INTERMEDIATE GEAR REMOVAL AND DISASSEMBLY**

Refer to 1326 "Intermediate Gear Removal and Disassembly" since the process is identical.

BARRE-CCL110010SE-200885

### **INTERMEDIATE GEAR REASSEMBLY AND REINSTALLATION**

Refer to 1326 "Intermediate Gear Reassembly and Reinstallation" since the process is identical.

BARRE-CCL110010TE-200885





**Section 110**

# **HYDRAULIC SYSTEM – REPAIR**

## **CONTENTS OF THIS SECTION IN GROUPS**

### **05 – LIFT CYLINDERS**


Special tools .....	100-05-1
Self-manufactured tools .....	100-05-1
Lift cylinder description .....	100-05-2
Lift cylinder disassembly and inspection recommendations .....	100-05-2
Lift cylinder removal .....	100-05-2
Lift cylinder reinstallation .....	100-05-3
Lift cylinder disassembly .....	100-05-3
Lift cylinder reassembly .....	100-05-5

HYDRAUL-CCL111001AE-200885




**SPECIAL TOOLS**

**JDH-6**



**A**

**D-05112ST**



**B**

CC7501

**A--To remove O-ring**

**B--To remove cylinder head**

CC7501-CCL111005AE-200885

**TORQUE FOR HYDRAULIC FITTINGS**

Hydraulic fittings to cylinder barrel ..... 21 to 24 Nm  
(15.5 to 17.7 ft-lb)


VERINS-CCL111005AE-200885

## Lift cylinder

### LIFT CYLINDER DESCRIPTION

The lift system consists of a single line (A) from the tractor to a master double acting cylinder (B) and a slave single acting cylinder (C).

The two cylinder lines are connected when the master cylinder is fully extended.



### LIFT CYLINDER DISASSEMBLY AND INSPECTION RECOMMENDATIONS

In general, cleanliness is the most important factor in hydraulic repair. Wash the parts in a safe solvent, then dry with compressed air. Inspect parts for damage. Refer to FOS manual for proper diagnosing of damage. Lubricate parts before assembly and reinstallation. Tighten hydraulic fittings to the specified torque. Reinstall hoses exactly as they were.

VERINS-CCL111005BE-200885

### LIFT CYLINDER REMOVAL (Right and Left)

Raise the machine frame with a hydraulic jack until frame raises the platform (F).


Shim platform with wooden shims (A).

Slowly lower machine until cylinder (B) is getting loose (manually move it).

Disconnect the two hoses (C).

Remove cotter pins (D) and the two pins (E).

Remove cylinder (B).



CC7546-CCL111005AE-200885

## LIFT CYLINDER REINSTALLATION

Reverse the previous cylinder removal steps for cylinder reinstallation.

VERINS-CCL111005CE-200885


## BLEED HYDRAULIC LINE

Connect hydraulic line to the tractor hydraulic supply.  
Raise the machine and keep pressure in hydraulic line.  
Unscrew right-hand side fitting slightly until all air has escaped.  
Tighten fitting after bleeding.  
Relieve pressure in hydraulic line.

VERINS-CCL111005DE-200885

## AVOID HIGH PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pin holes and nozzles which eject fluids under high pressure. Use a piece of cardboard or paper to search for leaks. Do not use your hand. If any fluid is injected into the skin, consult a doctor immediately, otherwise this may result in a serious infection.




L 102 134

L102134-CCL111005-200885

## LIFT CYLINDER DISASSEMBLY (Right and Left)

Remove cylinder (see relevant group).  
Clamp cylinder in a vise.  
Unscrew cylinder head and remove it.  
Remove rod.  
Use hook spanner D-05112ST.




CC7336

CC7336-CCL111005AE-200885

### LEFT-HAND LIFT CYLINDER, EXPLODED VIEW

- A-Hydraulic cylinder barrel
- B-Lock nut
- C-Seal
- D-O-ring
- E-Piston
- F-Rod
- G-Cylinder head
- H-O-ring
- I-Seal
- J-Seal




CC 7484

CC7484-CCL111005AE-200885

### RIGHT-HAND LIFT CYLINDER, EXPLODED VIEW

- A-Hydraulic cylinder barrel
- B-Snap ring
- C-Rod
- D-Cylinder head
- E-O-ring
- F-Piston ring
- G-Seal



CC7485

CC7485-CCL111005AE-200885

**LIFT CYLINDER REASSEMBLY**

Reverse cylinder disassembly steps for cylinder reassembly.

VERINS-CCL111005EE-200885





