





Bobcat®

Operation & Maintenance Manual Three-Point Tiller

3TIL48 (48 Inch) S/N ADL700101 & Above
3TIL60 (60 Inch) S/N ADKY00101 & Above
3TIL74 (74 Inch) S/N ADL400101 & Above



CONTENTS

FOREWORD..... III
SAFETY & TRAINING RESOURCES..... IX
OPERATING INSTRUCTIONS OI-1
PREVENTIVE MAINTENANCE PM-1
MACHINE SIGN TRANSLATIONS MST-1
SPECIFICATIONS..... SPEC-1
WARRANTY WARRANTY-1
ALPHABETICAL INDEX INDEX-1

REFERENCE INFORMATION

Write the correct information for YOUR three-point tiller in the spaces below. Always use these numbers when referring to your three-point tiller.

Three-Point Tiller Serial Number

NOTES:

YOUR BOBCAT® DEALER:

ADDRESS:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Drève Richelle 167
B-1410 WATERLOO
Belgium

FOREWORD

**SAFETY &
TRAINING
RESOURCES**

**OPERATING
INSTRUCTIONS
(OI)**

**PREVENTIVE
MAINTENANCE
(PM)**

**MACHINE SIGN
TRANSLATIONS
(MST)**

**SPECIFICATIONS
(SPEC)**

WARRANTY

**ALPHABETICAL
INDEX**



FOREWORD

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the three-point tiller. **READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR three-point tiller.** If you have any questions, see your Bobcat dealer.

BOBCAT COMPANY IS ISO 9001:2000 CERTIFIED	V
DELIVERY REPORT	VI
FEATURES AND ACCESSORIES	VIII
Standard Items	VIII
IMPLEMENT IDENTIFICATION	VII
SERIAL NUMBER LOCATION	VI
Implement Serial Number	VI



Thank you very much
for your reading.
Please click here
to get more information.