



2950 Tractor



JOHN DEERE

TECHNICAL MANUAL

2950 Tractor

TM4407 (01AUG86) English



John Deere Werke Mannheim

TM4407 (01AUG86)

LITHO IN U.S.A.
ENGLISH



2950 TRACTOR TECHNICAL MANUAL TM-4407 (Apr-86)

CONTENTS

The engine information has been removed from this manual. For engine information, refer to engine component technical manual, CTM-4, 3179, 4239, and 6359 Engines.

SECTION 10 - GENERAL

- Group 00 - Specifications and Special Tools
- Group 05 - Predelivery, Delivery, and After-Sales Inspections
- Group 10 - Lubrication and Service
- Group 15 - Tune-Up
- Group 20 - Tractor Separation

SECTION 20 - ENGINE

- Group 00 - Specifications
- Group 05 - Radiator

SECTION 30 - FUEL AND AIR INTAKE SYSTEM

- Group 00 - Specifications and Special Tools
- Group 05 - General Information, and Diagnosing Malfunctions
- Group 10 - Fuel Tank and Water Trap
- Group 15 - Cold Weather Starting Aids
- Group 20 - Speed Control Linkage
- Group 25 - Air Cleaner

SECTION 40 - ELECTRICAL SYSTEM

- Group 00 - Specifications and Special Tools
- Group 05 - Description, Diagnosing Malfunctions and Tests
- Group 06 - Connector Repair
- Group 10 - Wiring Harnesses
- Group 15 - Controls and Instruments
- Group 20 - Lighting System
- Group 25 - Wiring Diagrams
- Group 30 - Starting Motor
- Group 35 - Alternator

SECTION 50 - POWER TRAIN

- Group 00 - Specifications and Special Tools
- Group 05 - Description, Operation and Lubrication System
- Group 10 - Clutch Operating Linkages
- Group 15 - Engine Clutch
- Group 20 - Hi-Lo Shift Unit
- Group 25 - Creeper Transmission
- Group 30 - Transmission Shift Linkages
- Group 35 - Synchronized Transmission and Transmission Oil Pump
- Group 40 - Differential
- Group 45 - Final Drives
- Group 50 - Independent PTO
- Group 55 - Mechanical Front Wheel Drive

SECTION 60 - STEERING SYSTEM AND BRAKES

- Group 00 - Specifications and Special Tools
- Group 05 - Steering System
- Group 10 - Brakes

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1986
DEERE & COMPANY
Moline, Illinois
All rights reserved
Previous Edition
Copyright© 1982, 1984
Deere & Company

CONTENTS—Continued**SECTION 70 - HYDRAULIC SYSTEM**

- Group 00 - Specifications and Special Tools
- Group 05 - Description, Diagnosing Malfunctions and Tests
- Group 10 - Oil Reservoir, Filter, Valves and Oil Cooler
- Group 15 - Hydraulic Pump
- Group 20 - Rockshaft
- Group 25 - Selective Control Valve (Poppet Valve Type) and Breakaway Coupler
- Group 26 - Selective Control Valve (Spool Type) and Quick Coupler
- Group 30 - Remote Cylinder

SECTION 80 - ENGINE

- Group 00 - Specifications
- Group 05 - Front Axle
- Group 10 - Front and Rear Wheels

SECTION 90 - OPERATOR'S STATION

- Group 00 - Specifications and Special Tools
- Group 05 - Air Conditioning System
- Group 10 - Cab Ventilation and Heating
- Group 15 - Seats
- Group 20 - SOUND-GARD Body
- Group 25 - ROLL-GARD Protective Structure

Section 10 GENERAL

CONTENTS OF THIS SECTION

	Page		Page
GROUP 00 - SPECIFICATIONS AND SPECIAL TOOLS		GROUP 05 - PREDELIVERY, DELIVERY AND AFTER-SALES INSPECTIONS	
Specifications	10-00-3	Tractor Storage	10-05-1
Serial Numbers	10-00-3	Predelivery Inspection	10-05-2
Model Numbers	10-00-3	Delivery Inspection	10-05-9
Engine	10-00-3	After-Sales Inspection	10-05-10
Engine Clutch	10-00-4	GROUP 10 - LUBRICATION AND SERVICE	
Cooling System	10-00-4	Lubrication and Service	10-10-1
Fuel System	10-00-4	GROUP 15 - TUNE-UP	
Electrical System	10-00-4	Preliminary Engine Testing	10-15-1
Synchronized Transmission	10-00-4	Dynamometer Test	10-15-1
Hi-Lo Shift Unit	10-00-4	Testing Compression Pressure	10-15-2
Creeper Transmission	10-00-5	Engine Tune-Up	10-15-2
Differential and Final Drives	10-00-5	Checking Tractor Operation	10-15-7
Differential Lock	10-00-5	Standard Torques	10-15-8
PTO	10-00-5	GROUP 20 - TRACTOR SEPARATION	
Mechanical Front Wheel Drive	10-00-5	Separating between Engine and	
Hydrostatic Steering	10-00-6	Tractor Front End	10-20-1
Foot Brakes	10-00-6	Removal and Installation of Engine	10-20-5
Handbrake	10-00-6	Removal and Installation of	
Hydraulic System	10-00-6	Clutch Housing	10-20-8
Capacities	10-00-6	Removal and Installation of	
Travel Speeds	10-00-6	Final Drives	10-20-10
Front and Rear Wheels	10-00-6	Removal and Installation of	
Dimensions and Weights	10-00-6	Rockshaft	10-20-15
Predelivery, Delivery and		Removal and Installation of	
After-Sales Inspections	10-00-7	SOUND-GARD® Body	10-20-17
Lubrications and Service	10-00-8		
Tune-up	10-00-9		
Tractor Separation	10-00-10		
Standard Torques	10-00-11		
Special Tools	10-00-13		



Thank you very much
for your reading.
Please click here
to get more information.