


# 4055, 4255, and 4455 Tractors Repair

For complete service information, also see:

4055, 4255, and 4455 Tractors Operation and Tests . . . . .	
6076 Engine . . . . .	
Radial Piston Pumps . . . . .	CTM7
Engine Accessories . . . . .	CTM11
MFWD Axles, 1100 Series . . . . .	CTM17



**John Deere Waterloo Works**  
**TM1458 (09JUL01)**

LITHO IN U.S.A.  
ENGLISH

## FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

### FOS MANUALS—REFERENCE

### TECHNICAL MANUALS—MACHINE SERVICE

### COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

## NOTICE TO THE DEALER

**IMPORTANT:** The changes listed below make your current TM obsolete. Discard TM-1458 dated MAY-89. Please remove this page and route through your service department.

• **SECTION 20—**

Added Fan And Viscous Clutch

• **SECTION 50—**

Complete Revision To This Section

• **SECTION 55—**

Complete Revision To This Section

• **SECTION 70—**

Added Remote Cylinder

• **SECTION 80—**

Revision To Specifications

• **SECTION 90—**

Added SOUND-GARD Door Adjustment

• **SECTION 99—**

Revised Dealer Fabricated Tools

*Major revisions to this TM are listed above. Some Sections and Groups will have specification, procedure, or formatting changes not listed on this notification.*

RX, TM1458, DLR -19-10OCT90



# Contents

## SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—Machine Specifications
- Group 15—Predelivery Service
- Group 20—Tune-Up
- Group 25—Lubrication

## SECTION 15—SEPARATION

- Group 05—Front Axle
- Group 10—Front End
- Group 15—Front End and Engine
- Group 20—Engine
- Group 25—SOUND-GARD Body
- Group 30—Power Shift Clutch Housing
- Group 35—QUAD-RANGE Clutch Housing
- Group 40—Transmission
- Group 45—Final Drive
- Group 50—Hi-Crop Final Drive

## SECTION 20—ENGINE

- Group 05—Service
- Group 10—Cooling System
- Group 15—Dynamometer Test and Engine Break-In

## SECTION 30—FUEL AND AIR

- Group 05—Air Intake System
- Group 10—Diesel Fuel System

## SECTION 40—ELECTRICAL REPAIR

- Group 05—Connector Repair
- Group 10—Harness Replacement
- Group 15—Alternator
- Group 20—Starting Circuit Replacement
- Group 25—Lighting Circuit Repair
- Group 30—INTELLITRAK Monitoring System
- Group 35—Accessory Components
- Group 40—Auxiliary Lighting & Electrical Components (European Version)

## SECTION 50—POWER TRAIN--QUAD-RANGE TRANSMISSION

- Group 05—Clutch Control Valve
- Group 10—Clutch Operating Piston Housing

- Group 15—Perma-Clutch
- Group 20—Quad-Range Planetary
- Group 25—Quad-Range Transmission and Charge Pump
- Group 30—Shift Lever Assembly
- Group 35—PTO Gear Train
- Group 40—Adjust PTO Clutch Rod

## SECTION 55—POWER TRAIN--POWER SHIFT TRANSMISSION

- Group 05—Remove/Install Traction Clutch Valve Housing
- Group 10—Traction Clutch Valve Housing
- Group 15—Remove/Install Transmission Control Valve Housing
- Group 20—Transmission Control Valves and Accumulators
- Group 25—Remove/Install Traction Clutch
- Group 30—Traction Clutch and Drive Shaft
- Group 35—Input Planetary
- Group 40—Reduction Gear Train
- Group 45—Output Planetary
- Group 50—Speed Selector Assembly
- Group 55—Charge Pump Assembly
- Group 60—PTO Gear Train With MFWD
- Group 65—PTO Gear Train Without MFWD
- Group 70—Adjust PTO Clutch Rod
- Group 75—MFWD Gear Train
- Group 80—MFWD Clutch

## SECTION 56—DIFFERENTIAL AND FINAL DRIVE

- Group 05—Differential
- Group 10—Differential Lock Valve
- Group 15—Final Drive
- Group 20—Hi-Crop Final Drive

## SECTION 60—STEERING AND BRAKES

- Group 05—Remove/Install Power Steering Components
- Group 10—Steering Column
- Group 15—Metering Pump
- Group 20—Steering Valve
- Group 25—Steering Motor

Continued on next page

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

TM1458-19-09JUL01

COPYRIGHT© 1990  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION™ Manual



Thank you very much  
for your reading.  
Please click here  
to get more information.