

6120 to 6420 and 6120L to 6520L Tractors Repair

TECHNICAL MANUAL 6120 to 6420 and 6120L to 6520L Tractors Repair

TM4647 01DEC05 (ENGLISCH)

For complete service information also see:

6120 to 6420 and 6120L to 6520L Tractors Operation and Tests	TM4646
6120 to 6420 and 6120L to 6520L Tractors Diagnostics	TM4722
Front-Wheel Drive Axles - AS Series	CTM102
Front-Wheel Drive Axles - 700 Series	CTM103
POWERTECH™ Diesel Engines	CTM104
Mechanical Fuel Injection Systems	CTM207
Electronic Fuel Injection Systems (Level 4)	CTM170
Electronic Fuel Injection Systems (Level 1)	CTM284
Electronic Fuel Injection Systems (Level 11)	CTM220
Electronic Fuel Injection Systems (Level 12)	CTM331
Alternators and Starting Motors	CTM77



John Deere Werke Mannheim

North American Version
LITHO IN U.S.A.

Introduction

Foreword

This "Repair" manual is valid for the following tractor types:

6120, 6220, 6320 and 6420

6120L, 6220L, 6320L, 6420L, 6520L

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to potential for personal injury.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

LX24888,00004EE -19-01DEC02-1/1

Version Date

01 December 2005

LX18600,0000551 -19-02NOV05-1/1

Contents

SECTION 05—SAFETY

Group 05—Safety Measures

SECTION 10—GENERAL INFORMATION

Group 05—Specifications

Group 10—Tune-Up

Group 15—Predelivery Inspection

SECTION 20—ENGINE

Group 00—Installing and Removing Components

SECTION 30—FUEL, AIR INTAKE, COOLING AND EXHAUST SYSTEMS

Group 05—Speed Control

Group 10—Fuel System

Group 15—Air Intake System

Group 20—Cooling System

Group 25—Cold-Weather Starting Aid

Group 30—Exhaust System

SECTION 40—ELECTRICAL SYSTEM

Group 05—Connectors

Group 10—Wiring Harnesses

Group 15—Charging Circuit

Group 20—Starter Motor Circuit

Group 25—Fuses, Relays and Switches

Group 30—Monitoring Systems

Group 40—Electrical Components

SECTION 50—SYNCRPLUS TRANSMISSION

Group 00—Installing and Removing Components

Group 05—Transmission Shift Controls

Group 10—Perma Clutch II Module

Group 15—Gear Transmission

SECTION 51—POWER REVERSER TRANSMISSION

Group 00—Installing and Removing Components

Group 05—Transmission Shift Controls

Group 10—Power Reverser Module

Group 15—Gear Transmission

SECTION 53—AUTOPOWR/IVT TRANSMISSION

Group 00—Installing and Removing Components

Group 05—Transmission Shift Controls

Group 10—Input Housing

Group 15—Output Housing

Group 20—Differential Drive Shaft Assembly

SECTION 55—POWRQUAD, POWRQUAD PLUS AND AUTOQUAD TRANSMISSIONS

Group 00—Installing and Removing Components

Group 05—Transmission Shift Controls

Group 10—PowrQuad Module

Group 15—Creeper Transmission

Group 20—Option Transmission

Group 25—Range Transmission

SECTION 56—DRIVE SYSTEMS

Group 00—Installing and Removing Components

Group 05—U-Jointed Shafts and Torsion Damper

Group 10—Front-Wheel Drive Clutch

Group 15—Differential

Group 20—Hydraulic Pump Drive

Group 25—Final Drives

Group 30—Rear PTO

Group 35—Front PTO

Group 40—Front Implement Drive

SECTION 60—STEERING AND BRAKES

Group 05—Hydrostatic Steering

Group 10—Steering Cylinder

Group 15—Brake Valve

Group 20—Rear Brakes

Group 40—AutoTrac

SECTION 70—Hydraulic System

Group 05—Controls

Group 10—Hydraulic Pump and Charge Oil Pump

Group 15—Valves

Group 20—Rockshaft

Group 25—Selective Control Valves and Couplers

Group 30—Independent Control Valve (ICV)

SECTION 80—MISCELLANEOUS

Group 00—Installing and Removing Components

Group 05—Main Frame

Group 10—Front Axle

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2005
DEERE & COMPANY
European Office Mannheim
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 2004, 2003, 2002, 2001

05

Group 15—Front Wheels, Rear Wheels and Fenders

Group 20—Trailer Mounting and Swinging Drawbar

Group 25—Triple Link Suspension (TLS) of Front-Wheel Drive Axle

10

SECTION 90—OPERATOR'S CAB

Group 00—Installing and Removing Components

Group 05—Controls and Instruments

Group 10—Air Conditioning System

20

Group 11—ClimaTrak

Group 15—Heating System

Group 20—Seats

Group 25—Operator's Cab

Group 26—Low-Clearance Cab

Group 30—Cab Suspension

30

SECTION 99—Special Tools (Dealer-Fabricated)

Group 05—Special Tools (Dealer-Fabricated)

Group 10—Special Tools (available from the dealer)

40

50

51

53

55

56



Thank you very much
for your reading.
Please click here
to get more information.