

AMT600, AMT622 and AMT626 All Material Transporters

For complete service information, also see:

John Deere K Series Air Cooled
Engines



John Deere Horicon Works
TM1363 (15AUG91)

LITHO IN U.S.A.
ENGLISH

Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, other materials needed to do the job and service parts kits.

Section 10, Group 15—Repair Specifications, consist of all applicable specifications, wear tolerances and specific torque values for various components on each individual machine.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center.

This manual is part of a total product support program.

FOS MANUALS—REFERENCE

TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

JOHN DEERE DEALERS

This is a complete revision for TM1363 AMT600 and AMT622 All Material Transporter.

Discard TM1363 dated (09MAY90) and replace with this manual.

New information added to this manual includes:

1. AMT626 repair and diagnostic information.
2. Fuel pump is no longer serviceable.
3. Steering gear repair information has been revised as a result of a steering ratio change.

4. Rear axle installation procedure was changed to improve brake disk alignment.

5. Long axle extension kit specifications were added to axle installation procedures.

NOTE: For complete engine repair information, CTM5 John Deere K-Series Air Cooled Engines Component Technical Manual is also required. Use the component technical manual in conjunction with this machine manual.

Contents

SECTION 10—GENERAL INFORMATION

- Group 05—Safety
- Group 10—General Specifications
- Group 15—Repair Specifications
- Group 20—Fuels and Lubricants
- Group 25—Serial Number Locations
- Group 30—Features and Attachments

SECTION 20—ENGINE REPAIR

- Group 05—Remove and Install Engine

SECTION 30—FUEL SYSTEM REPAIR

- Group 05—Fuel Pump
- Group 10—Fuel Tank
- Group 15—Fuel Filter

SECTION 40—ELECTRICAL REPAIR

- Group 05—Starting System
- Group 10—Charging System
- Group 15—Lighting and Controls
- Group 20—Battery Cable and Wiring Harness

SECTION 50—POWER TRAIN REPAIR

- Group 05—Drive Belt
- Group 10—Drive Chains and Sprockets
- Group 15—Drive Pulley
- Group 20—Driven Pulley
- Group 25—Transaxle
- Group 30—Drive Axles

SECTION 60—STEERING AND BRAKE REPAIR

- Group 05—Front Wheel Bearings, Steering Yoke, and Fork
- Group 10—Steering Quadrant—AMT622/626
- Group 15—Brakes

SECTION 80—MISCELLANEOUS REPAIR

- Group 05—Seat, Shroud, and Fenders—AMT600
- Group 10—Seat, Shroud, and Fenders—AMT622/626

- Group 15—Cargo Box, Frame Panels, and Platform
- Group 20—Drive Wheels
- Group 25—Throttle Cable
- Group 30—Hydraulic Lift Pump

SECTION 210—TEST & ADJUSTMENT SPECIFICATIONS/OPERATIONAL CHECKOUT PROCEDURE

- Group 05—Test and Adjustment Specifications
- Group 10—Operational Checkout Procedure—AMT600
- Group 11—Operational Checkout Procedure—AMT622/626

SECTION 220—ENGINE OPERATION, TESTS & ADJUSTMENTS—AMT600

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

SECTION 225—ENGINE OPERATION, TESTS & ADJUSTMENTS—AMT622/626

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

SECTION 240—ELECTRICAL OPERATION, TESTS & ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments
- Group 20—Wiring Schematics

SECTION 250—POWER TRAIN OPERATION, TESTS & ADJUSTMENTS

- Group 05—Component Location
- Group 10—Theory of Operation
- Group 15—Diagnosis, Tests & Adjustments

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1363-19-15AUG91

COPYRIGHT©1991
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1990, 1987 Deere & Company



Thank you very much
for your reading.
Please click here
to get more information.