


John Deere JD544B Loader



John Deere Dubuque Works
TM-1094 (Jan-80)

LITHO IN U.S.A.



JD544-B LOADER

Technical Manual
TM-1094 (Jan-80)

CONTENTS

Section 10 - GENERAL

- Group 5 Specifications
- Group 10 Predelivery, Delivery, and After-Sale Services
- Group 15 Lubrication

Section 20 - ENGINE

- Group 5 Engine Removal and Installation
- Group 10 Basic Engine
- Group 15 Engine Lubrication System
- Group 20 Engine Cooling System
- Group 25 Fuel System
- Group 30 Speed Control Linkage (Refer to Section 70)
- Group 35 Air Intake System
- Group 40 Specifications and Special Tools

Section 30 - ELECTRICAL SYSTEM

- Group 5 Batteries
- Group 10 Charging System
- Group 15 Delco-Remy Starting System
- Group 20 John Deere Starting System
- Group 25 Miscellaneous Electrical Components
- Group 26 Heating and Air Conditioning Systems
- Group 30 Specifications and Special Tools

Section 40 - POWER TRAIN

- Group 5 Drive Shafts
- Group 10 Damper Assembly
- Group 15 Transmission
- Group 20 Final Drives
- Group 25 Differential
- Group 30 Specifications and Special Tools

Section 50 - HYDRAULIC SYSTEM

- Group 5 Transmission Pump
- Group 10 Transmission Control Valve
- Group 15 Steering and Brake Pump
- Group 20 Steering Valve
- Group 25 Brake System
- Group 30 Loader Pump
- Group 35 Loader Control Valve
- Group 40 Cylinders
- Group 45 Miscellaneous Hydraulic Components
- Group 47 Backhoe Swing Cylinder
- Group 49 Backhoe Control Valve
- Group 50 Specifications and Special Tools

Section 60 - MISCELLANEOUS COMPONENTS

- Group 5 Loader and Engine Frames
- Group 10 Loader Boom and Buckets
- Group 15 Seats
- Group 20 Canopy and Cab
- Group 21 Backhoe
- Group 25 Specifications and Special Tools


Section 70 - SYSTEM TESTING

- Group 5 General Information - Seven Basic Steps of Testing and Diagnosis
- Group 10 Engine
- Group 15 Electrical System
- Group 16 Heating and Air Conditioning Systems
- Group 20 Power Train
- Group 25 Hydraulic System
- Group 26 Hydraulic System (Analyzer)
- Group 30 Miscellaneous Components
- Group 35 Specifications and Special Tools

INDEX

The specifications and design information contained in this manual were correct at the time this machine was manufactured. It is John Deere's policy to continually improve and update our machines. Therefore, the specifications and design information are subject to change without notice. Wherever applicable, specifications and design information are in accordance with SAE and ICED standards.

INTRODUCTION



Use FOS Manuals for Reference

This technical manual is part of a twin concept of service:

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

•FOS Manuals—for reference

Fundamentals of Service (FOS) Manuals cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failure and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.



When a service technician should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.

•Technical Manuals—for actual service

Technical Manuals are concise service guides for a specific machine. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.



Use Technical Manuals for Actual Service

This technical manual was planned and written for you, an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.


Some features of this manual:

- Inside front cover - "Table of Contents" and "Maintenance Without Accident".
- Section 10 - General specifications and services.
- Sections 20 through 60 - Removal, repair testing (components removed), installation, and adjustment.
- Section 70 - Detailed explanation of system operation, diagnosis, visual inspection, testing, and adjustments.
- Specifications grouped and illustrated at the end of each section.


MAINTENANCE WITHOUT ACCIDENT WORK SAFELY



T27999

 This safety alert symbol identifies important safety messages in this manual and on the loader. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.


**EVERY EMPLOYER HAS A
SAFETY PROGRAM. KNOW
WHAT IT IS!**



T27501N


Consult your shop supervisor for specific instructions on a job, and the safety equipment required.

For instance, you may need: Hard hat, safety shoes, safety goggles, heavy gloves, reflector vests, ear protectors, respirators.



T27502N


ALWAYS AVOID loose clothing or any accessory—flopping cuffs, dangling neckties and scarves, or rings and wrist watches—that can catch in moving parts and put you out of work.



T32701N

BE ALERT!

Plan ahead—work safely—avoid accidental damage and injury. If a careless moment does cause an accident or fire, react quickly with the tools and skills at hand—know how to use a first aid kit and a fire extinguisher—and where to get aid and assistance. In an emergency, split-second action is the key to safety.



T27504N



Thank you very much
for your reading.
Please click here
to get more information.