

120C Excavator Repair

REPAIR TECHNICAL MANUAL

120C

TM1935 18AUG15 (ENGLISH)

For complete service information also see:

120C Excavator Operation and Tests TM1934

Alternators and Starting Motors CTM77

PowerTech 4.5L and 6.8L Diesel Engines
Level 12 Electronic Fuel System With
Stanadyne DE10 Pump CTM331

Super Caddy Oil Cleanup Procedure CTM310

PowerTech 4.5L & 6.8L Diesel Engines
Tier 1/Stage I, Tier 2/Stage II, Tier
3/Stage IIIA, Tier 3/Stage IIA Tier
III, (Base Engine) TM1104

JDG10274 Ultrasonic Undercarriage
Measurement Gauge

PDF



DOWNLOAD



John Deere Construction and Forestry

Table of contents

FOREWORD

TECHNICAL INFORMATION FEEDBACK FORM

Section 00 - GENERAL INFORMATION

Group 0001 - Safety

Group 0003 - Torque Values

Section 01 - TRACKS

Group 0130 - Track System

Section 02 - AXLES AND SUSPENSION SYSTEMS

Group 0250 - Axle Shaft, Bearings, and Reduction Gears

Group 0260 - Hydraulic System

Section 04 - ENGINE

Group 0400 - Removal and Installation

Section 05 - ENGINE AUXILIARY SYSTEMS

Group 0510 - Cooling System

Group 0520 - Intake System

Group 0560 - External Fuel Supply Systems

Section 07 - DAMPENER DRIVE (FLEX COUPLING)

Group 0752 - Elements

Section 17 - FRAME OR SUPPORTING STRUCTURE

Group 1740 - Frame Installation

Group 1749 - Chassis Weights

Section 18 - OPERATOR'S STATION

Group 1800 - Removal and Installation

Group 1810 - Operator Enclosure

Group 1821 - Seat and Seat Belt

Group 1830 - Heating and Air Conditioning

Section 32 - BULLDOZERS (BACKFILL BLADE)

Group 3201 - Blades

Group 3260 - Hydraulic System

Section 33 - EXCAVATOR

Group 3302 - Buckets

Group 3340 - Frames

Group 3360 - Hydraulic System

Section 43 - SWING OR PIVOTING SYSTEM

Group 4350 - Mechanical Drive Elements

Group 4360 - Hydraulic System

Section 99 - DEALER FABRICATED TOOLS

Group 9900 - Dealer Fabricated Tools

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

**CAUTION:**

This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

Technical Information Feedback Form

We need your help to continually improve our technical publications. Please copy this page and FAX or mail your comments, ideas and improvements.

Technical Manual Fax

SEND TO: John Deere Dubuque Works
18600 South John Deere Road
Attn: Publications, Dept. 324
Dubuque, IA 52004-0538
USA

FAX NUMBER: 1-563-589-5800 (USA)

Publication Number: _____

Page Number: _____

Ideas, Comments:

Name: _____

Phone: _____

Email Address: _____

THANK YOU!



Thank you very much
for your reading.
Please click here
to get more information.