

SideHill 9500 Combine Repair Operation And Tests

For complete service information also see:

9400, 9500 and 9600 Maximizer
Combines—Repair TM1401
9400, 9500 and 9600 Maximizer
Combines—Operation and Tests TM1402
6076 Engine CTM42
Cam Lobe Motors CTM19

John Deere Harvester Works
TM1545 (04JAN01)

LITHO IN U.S.A.
ENGLISH

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

This technical manual covers information unique to the SideHill 9500 Combine:

- Tune Up and Adjustment
- Electrical System
- Power Train Repair
- Power Steering and Brakes
- Header Repair
- Feeder House Repair

See TM1401; 9400, 9500 and 9600 Combines—Repair—for information on the following:

Engine	Section 20
Fuel and Air	Section 30
Electrical (Except Leveling)	Section 40
Power Train Repair (Except Removing and Installing Transmission and Remove and Install Final Drive)	Section 50
Power Steering and Brakes (Except Removing and Installing Brake Drum	Section 60
Hydraulic Repair (Except Remove and Install Valve Block Solenoid, Repair Check Valve, Remove and Install Right- and Left-Hand Cylinders)	Section 70
Air Conditioning	Section 90
Headers (Except Cutter Bar, 200 and 900 Series Cutting Platform)	Section 100
Feeder House (Except for Remove and Install Feeder House, Conveyor, Floor Plate, Conveyor Drum, Shaft Slip Clutch)	Section 110
Separator	Section 120
Grain Tank Unloading	Section 130
Engine Gearcase	Section 140
Dial-A-Matic Header Height Control	Section 160



Contents

SECTION 10—GENERAL

- Group 05—Safety
- Group 10—Identification Number Location
- Group 15—Specifications

SECTION 40—ELECTRICAL SYSTEM

- Group 05—Circuit Breakers and Relays
- Group 10—Leveling System Repair

SECTION 50—POWER TRAIN REPAIR

- Group 05—Transmission and Differential
- Group 10—Ring and Pinion Final Drive

SECTION 60—POWER STEERING AND BRAKES

- Group 05—Brakes

SECTION 70—HYDRAULIC REPAIR

- Group 05—Hydraulic Valves

SECTION 100—HEADER DRIVE REPAIR

- Group 05—Header Drive Shaft Repair

SECTION 110—FEEDER HOUSE REPAIR

- Group 05—Feeder House/Conveyor
- Group 10—Feeder House Conveyor Drum
- Group 15—Conveyor Shaft and Slip Clutch

SECTION 350—SIDEHILL 9500 LEVELING SYSTEM—DIAGNOSTICS

- Group 05—SideHill Leveling System
- Group 10A—SideHill 9500 Leveling System—Electrical Diagnostics
- Group 20A—SideHill 9500 Leveling System—Hydraulic Diagnostics
- Group 20B—SideHill 9500 Leveling System—Theory of Operation

Index

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1545-19-04JAN01

COPYRIGHT© 1993
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright 1992 Deere & Company

Contents

10

40

50

60

70

100

110

350

INDX

Section 10 GENERAL

10

Contents

Page

Group 05—Safety	10-05-1
Group 10—Identification Number Location	10-10-1
Group 15—Specifications	10-15-1

HANDLE FLUIDS SAFELY—AVOID FIRES

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



DX,FLAME -19-04JUN90

10
05
1
-UN-23AUG88
TS227

PREVENT BATTERY EXPLOSIONS

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



DX,SPARKS -19-03MAR93


-UN-23AUG88
TS204

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



DX,FIRE2 -19-03MAR93

-UN-23AUG88
TS291

PREVENT ACID BURNS

Sulfuric acid in battery electrolyte is poisonous. It is strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid the hazard by:


1. Filling batteries in a well-ventilated area.
2. Wearing eye protection and rubber gloves.
3. Avoiding breathing fumes when electrolyte is added.
4. Avoiding spilling or dripping electrolyte.
5. Use proper jump start procedure.

If you spill acid on yourself:

1. Flush your skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush your eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 quarts).
3. Get medical attention immediately.



TSS203 -UN-23AUG88

DX,POISON -19-21APR93


AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



DX,FLUID -19-03MAR93


X9811 -JUN-23AUG88

10
305

PARK MACHINE SAFELY

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.



DX,PARK -19-04JUN90


TS230 -JUN-24MAY89

10
05
4

SUPPORT MACHINE PROPERLY

Always lower the attachment or implement to the ground before you work on the machine. If you must work on a lifted machine or attachment, securely support the machine or attachment.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.



DX,LOWER -19-04JUN90

-UN-23AUG88
TS229


WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




DX,WEAR -19-10SEP90

-UN-23AUG88
TS206

WORK IN CLEAN AREA

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




DX,CLEAN -19-04JUN90

-UN-18OCT88
T6642EJ

SERVICE MACHINES SAFELY

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.



DX, LOOSE -19-04JUN90


TS228 -UN-23AUG88

10
575

WORK IN VENTILATED AREA

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



DX, AIR -19-04JUN90

TS220 -UN-23AUG88

ILLUMINATE WORK AREA SAFELY

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




DX, LIGHT -19-04JUN90

TS223 -UN-23AUG88

REPLACE SAFETY SIGNS

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.



DX, SIGNS1 -19-04JUN90


TS201 -UN-23AUG88

10
05
6

USE PROPER LIFTING EQUIPMENT

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



DX,LIFT -19-04JUN90

TS226 -UN-23AUG88

SERVICE TIRES SAFELY


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



DX,RIM -19-24AUG90

TS211 -UN-23AUG88

AVOID HEATING NEAR PRESSURIZED FLUID LINES

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can be accidentally cut when heat goes beyond the immediate flame area.



DX,TORCH -19-03MAR93

TS953 -UN-15MAY90

REMOVE PAINT BEFORE WELDING OR HEATING


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Do all work outside or in a well ventilated area. Dispose of paint and solvent properly.

Remove paint before welding or heating:

- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.



DX,PAINT -19-03MAR93

10
05
7
-UN-23AUG68
TS220

USE PROPER TOOLS

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



DX,REPAIR -19-04JUN90

-UN-08NOV89
TS779

PRACTICE SAFE MAINTENANCE

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.



-UN-23AUG88

TS218

DX.SERV -19-03MAR93

DISPOSE OF WASTE PROPERLY


Improperly disposing of waste can threaten the environment and ecology. Potentially harmful waste used with John Deere equipment include such items as oil, fuel, coolant, brake fluid, filters, and batteries.

Use leakproof containers when draining fluids. Do not use food or beverage containers that may mislead someone into drinking from them.

Do not pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants escaping into the air can damage the Earth's atmosphere. Government regulations may require a certified air conditioning service center to recover and recycle used air conditioning refrigerants.

Inquire on the proper way to recycle or dispose of waste from your local environmental or recycling center, or from your John Deere dealer.



-UN-26NOV90

TS1133

DX.DRAIN -19-03MAR93

LIVE WITH SAFETY

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



DX,LIVE -19-25SEP92

TS231 -19-07OCT88

10
05
9

Safety

10
05
10

Group 10 Identification Number Location

COMBINE IDENTIFICATION NUMBER


Located on left-hand side above rear axle.



H01,9000ID,B -19-09AUG93

ENGINE SERIAL NUMBER

The engine serial number is located on rear side of engine.



SH,9500ID,D -19-29APR92

Identification Number Location

10
10
2

Specifications

SPECIFICATIONS

10
15
2

Finger Bar:	Type adjustable
	Area 0.48 m ² (744 sq. in.)
Separator:	Type straw walkers
	Width 1397 mm (55 in.)
Cleaning Shoe:	Chaffer width 1286 mm (51 in.)
	Chaffer length 1220 mm (48 in.)
	Sieve width 1286 mm (51 in.)
	Sieve length 1159 mm (46 in.)
	Precleaner width 1286 mm (51 in.)
	Precleaner length 840 mm (33 in.)
	Total area 4.11 m ² (6370 sq. in.)
Straw Walkers:	Type Lip
	Number of walkers 4
	Length 4500 mm (177 in.)
	Total area 6.26 m ² (9702 sq. in.)
Grain Tank:	Capacity 182 Bu (S.N. 645301—)
	204 Bu (S.N. 650301—)
	Average unloading rate 4200L/min (120 bu./min.)
Weights:	Less header (base equipment on a Corn Combine) 12 154 kg (26,795 lbs.)
Capacities:	Fuel tank 530L (140 gal.)
	Cooling system (with heater) 36L (38 U.S. qts.)
	Engine crankcase (with filter) 25L (26-1/2 U.S. qts.)
	Transmission 9.6L (10 U.S. qts.)
	Final Drives (each) 8.5L (9 U.S. qts.)
	Feeder House Reverser Gearcase 1.9L (2 U.S. pts.)
	Primary Countershaft Gearcase 1.4L (2-1/2 U.S. pts.)
	Straw Walker Drive Gearcase 0.7L (1-1/2 U.S. pts.)
	Dual-Range Cylinder Drive Gearcase 1.9L (2 U.S. qts.)
	Engine Gearcase 16L (17 U.S. qts.)
	Loading Auger Gearcase 4.7L (5 U.S. qts.)
	Hydraulic/Hydrostatic Reservoir 34L (36 U.S. qts.)

TM1545,1015.A -19-29MAR93

OPERATING SPEEDS

Speeds shown are average and can vary from machine to machine. Speeds are rated at high idle with separator engaged, no load.

Engine:

Slow Idle (Separator Off)- 1200 rpm.

Mid Speed- 1680 rpm.

Fast Idle (Separator Engaged)- 2340 rpm.

Full Load Rated Speed- 2200 rpm.

Separator Drive Shaft Speed- 1550 rpm.

Main Countershaft Speed- 1550 rpm.

Hydrostatic Pump Speed With:

Ring and Pinion Final Drives-3510 rpm.

Cylinder Speed:

High Range-480-980 rpm.

Low Range-240-480 rpm.

Feeder House Lower Shaft- Variable Speed 520-715.

Secondary Countershaft- 530 rpm.

Cleaning Fan:

Standard- 750-1350 rpm.

Optional- 500-980 rpm.

Clean Grain Elevator- 400 rpm.

Tailings Elevator- 465 rpm.

Shoe Crankshaft- 280 rpm.

Straw Walkers- 170 rpm.

Unloading Auger Countershaft- 1060 rpm.

Specifications

Loading Auger- 430 rpm.

Inner Grain Tank Unloading Augers-Front and Rear-
360 rpm.

Vertical and Horizontal Unloading Augers-390 rpm.

Straw Chopper:

High (Grain) 2130 rpm.

Low (Corn) 1595 rpm.

Straw Spreader Shaft- 235 rpm.

Shoe Grain Supply Augers Shaft- 405 rpm.



SH,9500SP,B -19-18MAR93

Specifications

10
15
5

DIMENSION REFERENCE POINTS

10
15
6



H44451

-UN-27APR92

H44451

SH,9500SP,J -19-29APR92

Specifications

DIMENSIONS

The grain tank auger is 217 mm (8-1/2 in.) above the cab roof.

Additional clearance can be gained by removing the grain tank loading auger. See "REMOVING GRAIN TANK LOADING AUGER".


DIMENSION*	w/14 ft. Unloading Auger	w/17 ft. Unloading Auger	w/20 ft. Unloading Auger
A	7.8 m (25 ft. 7 in.)	8.7 m (28 ft. 7 in.)	9.6 m (31 ft. 7-in.)
B	8.1 m (26 ft. 7 in.)	8.1 m (26 ft. 7 in.)	8.1 m (26 ft. 7-in.)
C	4.28 m (14 ft. 1 in.)	4.28 m (14 ft. 1 in.)	4.28 m (14 ft. 1-in.)
D	4.01 m (13 ft. 2 in.)	4.01 m (13 ft. 2 in.)	4.01 m (13 ft. 2-in.)
E	3.92 m (12 ft. 10 in.)	3.92 m (12 ft. 10 in.)	3.92 m (12 ft. 10-in.)
F	0.74 m (2 ft. 5 in.)	0.74 m (2 ft. 5 in.)	0.74 m (2 ft. 5-in.)
G	4.19 m (13 ft. 9 in.)	4.35 m (14 ft. 3 in.)	4.51 m (14 ft. 10-in.)
H	4.02 m (13 ft. 2 in.)	4.18 m (13 ft. 8 in.)	4.34 m (14 ft. 3-in.)
I	4.53 m (14 ft. 10-in.)	4.53 m (14 ft. 10-in.)	
J	3.44 m (11 ft. 4 in.)	3.44 m (11 ft. 4 in.)	
K**	-	-	-

* Dimensions shown are with 24.5 x 32 drive tires.

** For adjustable rear axle, see REAR AXLE ADJUSTMENT.

SH,9500SP,C -19-29APR92

METRIC BOLT AND CAP SCREW TORQUE VALUES



Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft	N·m	lb-ft
M6	4.8	3.5	6	4.5	9	6.5	11	8.5	13	9.5	17	12	15	11.5	19	14.5
M8	12	8.5	15	11	22	16	28	20	32	24	40	30	37	28	47	35
M10	23	17	29	21	43	32	55	40	63	47	80	60	75	55	95	70
M12	40	29	50	37	75	55	95	70	110	80	140	105	130	95	165	120
M14	63	47	80	60	120	88	150	110	175	130	225	165	205	150	260	190
M16	100	73	125	92	190	140	240	175	275	200	350	225	320	240	400	300
M18	135	100	175	125	260	195	330	250	375	275	475	350	440	325	560	410
M20	190	140	240	180	375	275	475	350	530	400	675	500	625	460	800	580
M22	260	190	330	250	510	375	650	475	725	540	925	675	850	625	1075	800
M24	330	250	425	310	650	475	825	600	925	675	1150	850	1075	800	1350	1000
M27	490	360	625	450	950	700	1200	875	1350	1000	1700	1250	1600	1150	2000	1500
M30	675	490	850	625	1300	950	1650	1200	1850	1350	2300	1700	2150	1600	2700	2000
M33	900	675	1150	850	1750	1300	2200	1650	2500	1850	3150	2350	2900	2150	3700	2750
M36	1150	850	1450	1075	2250	1650	2850	2100	3200	2350	4050	3000	3750	2750	4750	3500

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.












Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES

SAE Grade and Head Markings	1 or 2 ^b	5	5.1	5.2	8	8.2
	NO MARK 					
SAE Grade and Nut Markings	2	5		8		
	NO MARK 					

Size	Grade 1				Grade 2 ^b				Grade 5, 5.1, or 5.2				Grade 8 or 8.2			
	Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a		Lubricated ^a		Dry ^a	
	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft	N-m	lb-ft
1/4	3.7	2.8	4.7	3.5	6	4.5	7.5	5.5	9.5	7	12	9	13.5	10	17	12.5
5/16	7.7	5.5	10	7	12	9	15	11	20	15	25	18	28	21	35	26
3/8	14	10	17	13	22	16	27	20	35	26	44	33	50	36	63	46
7/16	22	16	28	20	35	26	44	32	55	41	70	52	80	58	100	75
1/2	33	25	42	31	53	39	67	50	85	63	110	80	120	90	150	115
9/16	48	36	60	45	75	56	95	70	125	90	155	115	175	130	225	160
5/8	67	50	85	62	105	78	135	100	170	125	215	160	215	160	300	225
3/4	120	87	150	110	190	140	240	175	300	225	375	280	425	310	550	400
7/8	190	140	240	175	190	140	240	175	490	360	625	450	700	500	875	650
1	290	210	360	270	290	210	360	270	725	540	925	675	1050	750	1300	975
1-1/8	470	300	510	375	470	300	510	375	900	675	1150	850	1450	1075	1850	1350
1-1/4	570	425	725	530	570	425	725	530	1300	950	1650	1200	2050	1500	2600	1950
1-3/8	750	550	950	700	750	550	950	700	1700	1250	2150	1550	2700	2000	3400	2550
1-1/2	1000	725	1250	925	990	725	1250	930	2250	1650	2850	2100	3600	2650	4550	3350

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Make sure fasteners threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.


^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without any lubrication.

^b Grade 2 applies for hex cap screws (not hex bolts) up to 152 mm (6-in.) long. Grade 1 applies for hex cap screws over 152 mm (6-in.) long, and for all other types of bolts and screws of any length.

O-RING BOSS FITTING TORQUE CHART


STRAIGHT FITTING

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



ANGLE FITTING

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer (B) contacts face of boss.
3. Turn fitting head-end (C) counterclockwise to proper index (maximum of one turn).
4. Hold fitting head-end (C) with a wrench and tighten locknut (A) and back-up washer (B) to proper torque value.



NOTE: Do not allow hoses to twist when tightening fittings.


TORQUE VALUE CHART

Thread Size	Torque	
	N-m	(lb-ft)
3/8-24 UNF	8	(6)
7/16-20 UNF	12	(9)
1/2-20 UNF	16	(12)
9/16-18 UNF	24	(18)
3/4-16 UNF	46	(34)
7/8-14 UNF	62	(46)
1-1/16-12 UN	102	(75)
1-3/16-12 UN	122	(90)
1-5/16-12 UN	142	(105)
1-5/8-12 UN	190	(140)
1-7/8-12 UN	217	(160)

NOTE: Torque tolerance is $\pm 10\%$.

FLAT FACE O-RING SEAL FITTING TORQUE CHART

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



FLAT FACE O-RING SEAL FITTING TORQUE

Tube mm	Nominal O.D. (in.)	Dash Size	Thread Size in.	Swivel Nut Torque	
				N-m	(lb-ft)
6.35	0.250	-4	9/16-18	24	18
9.52	0.375	-6	11/16-16	30	22
12.70	0.500	-8	13/16-16	47	35
15.88	0.625	-10	1-14	75	55
19.05	0.750	-12	1 3/16-12	114	84
22.22	0.875	-14	1 3/16-12	114	84
25.40	1.000	-16	1 7/16-12	155	115
31.75	1.250	-20	1 11/16-12	193	142
38.10	1.500	-24	2-12	225	166

NOTE: Torque tolerance is +15 -20%.

SAE FOUR BOLT FLANGE FITTING TORQUE CHART

1. Inspect the sealing surfaces for nicks or scratches, roughness or out-of-flat condition. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If these defects cannot be polished out, replace the component.


2. Install the correct O-ring (and backup washer if required) into the groove using petroleum jelly to hold it in place.

3. For split flange; loosely assemble split flange halves, being sure that the split is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring.

4. For single piece flange; put hydraulic line in the center of the flange and install four cap screws. With the flange centrally located on the port, hand tighten cap screws to hold it in place. Do not pinch O-ring.

5. For both single piece flange and split flange, be sure the components are properly positioned and cap screws are hand tight. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten the two remaining cap screws. Tighten all cap screws within the specified limits shown in the chart.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT overtighten.



H41160 -JUN-31OCT89

SAE FOUR BOLT FLANGE FITTING TORQUE

Nominal Flange Size	Cap Screw Size ¹	N·m		Torque ² (lb-ft)	
		Min.	Max.	Min.	Max.
1	7/16 - 14 UNC	56	68	(42)	(50)
/	M10 X 1.5*	66	81	(49)	(60)

1. SAE Grade 5 or better cap screws with plated hardware.

2. Tolerance $\pm 10\%$. The torques given are enough for the given size connection with the recommended working pressure. Torques can be increased to the maximum shown for each cap screw size if desired. Increasing cap screw torque beyond this maximum will result in flange and cap screw bending and connection failures.

*Metric 10.9

PREVENT HYDRAULIC SYSTEM CONTAMINATION

IMPORTANT: Cleanliness is very important when working on the hydraulic system. Prevent contamination by assembling the cylinders, hoses, couplers, and valves in a clean area of the shop.

Leave protective caps on the fluid openings until ready to make the connection. Keep couplers clean. Abrasive particles, like sand or metal fragments, can damage seals, barrels and pistons, causing internal leakage.

HX, TM1545, FA -19-09AUG93

10
15
13

10
15
14

CHECK OIL LINES AND FITTINGS



! **CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Check all oil lines, hoses and fittings regularly for leaks or defects. Make sure all clamps are in position and tight. Make sure hoses are not twisted or touching machine parts which are moving. Replace damaged parts.

IMPORTANT: Tighten fittings as specified in torque chart.

If necessary, use two wrenches to prevent hoses from twisting, bending or breaking tubing and fittings.



X9811 -UN-23AUG88

H44023 -UN-23FEB92

HX,1401,1010X -19-11DEC92

Section 40 ELECTRICAL SYSTEM

Contents

Page

Group 05—Circuit Breakers and Relays

Armrest Control Panel	40-05-1
Control Panel Rocker Type Switch Replacement	40-05-4
Control Panel Knob and Toggle Type Switch Replacement	40-05-4


Group 10—Leveling System Repair

Dashpot Orifice Adjustment	40-10-4
Replacing Complete Control Box	40-10-5
Tilt Limit Switches	40-10-5
Remove and Install Sidehill Leveling Limit Switches	40-10-6
Adjust Sidehill Leveling Limit Switches . . .	40-10-7

40

ARMREST CONTROL PANEL

- A—DIAL-A-MATIC™ (Optional)
- B—DIAL-A-SPEED™ Control (Optional)
- C—Header Engage
- D—Unloading Auger Engage
- E—Separator Engage
- F—Manual Reel Speed
- G—Reel Fore-and-Aft (Optional)
- H—Cylinder Speed
- I—Concave Spacing
- J—Lighter
- K—Cleaning Fan Speed
- L—Four-Wheel Drive (Optional)
- M—Engine Speed
- N—Unloading Auger Swing
- O—Ash Tray
- P—Hydrostatic Drive Control Lever
- Q—Reel Lift/Feederhouse Speed
- R—Header Lift
- T—Manual Tilt Control
Sidehill 9500
- U—Auto Leveling System On/Off,
Sidehill 9500



H43549

40
05


-19-11JUN91

H43549

HX,1401,4005,AE-19-18NOV92

Circuit Breakers and Relays/Armrest Control Panel

40
05
2



H45003
-JUN-20AUG92

HX,1545,4005,AB-19-18NOV92

Circuit Breakers and Relays/Armrest Control Panel

- | | | | |
|---|--|---|--------------------------------------|
| 1—Panel | 14—Toggle Switch, Yellow, (Header Engage) | 24—Switch Cap, Black, Fan Speed | 35—Washer |
| 2—Ashtray | 15—Screw (4 used) | 25—Rocker Switch, Fan Speed | 36—Nut |
| 3—Nut | 16—Switch Cap, Black, Manual Tilt Control | 26—Printed Circuit Board | 37—Bracket |
| 4—Knob, Unloading Auger | 17—Rocker Switch, Black, Manual Tilt Control | 27—Switch Cap, Black, Concave Clearance | 38—Clamp |
| 5—Knob, Dial-A-Matic | 18—Switch Cap, Black, Reel Fore/Aft | 28—Rocker Switch, Concave Clearance | 39—Flange Nut |
| 6—Knob, Dial-A-Speed | 19—Rocker Switch, Reel Fore/Aft | 29—Switch Cap, Black, Cylinder Speed | 40—Cap Screw |
| 7—Lock Nut | 20—Switch Cap, Orange, Engine Speed | 30—Rocker Switch, Cylinder Speed | 41—Switch Cap, Unloading Auger Swing |
| 8—Switch, Dial-A-Matic | 21—Rocker Switch, Engine Speed | 31—Lighter | 42—Rocker Switch, Manual Reel Speed |
| 9—Switch, Dial-A-Speed | 22—Switch Cap, Orange, Four Wheel Drive | 32—Cover | 43—Rocker Switch, UA Swing |
| 10—Switch, Unloading Auger-ENGAGE | 23—Rocker Switch, Four Wheel Drive | 33—Lighter Housing | 44—Switch Cap, Auto Tilt/ON/OFF |
| 11—Switch Cap, Black, Rabbit/Turtle (Manual Reel Speed) | | 34—Spacer | 45—Rocker Switch, Auto Tilt/ON/OFF |
| 12—Relay, Header Engage | | | |
| 13—Toggle Switch, Yellow, (Separator Engage) | | | |

Legend for Armrest Control Panel

HX.1545.4005.A -19-18NOV92

40
05
3

SWITCH KNOB DESCRIPTION/COLOR CODE

Before operating this combine, become familiar with the switches and controls.


Orange - ground drive and engine speed.

Yellow - drive engagement.

Black - operating adjustments and controls.




-UN-24JUN91
H43628



H43630

Automatic Level OFF/ON Switch



H43629

Manual Leveling Switch

-UN-24JUN91
H43630

-UN-24JUN91
H43629

TM1545.4005.A -19-09AUG93

CONTROL PANEL ROCKER TYPE SWITCH REPLACEMENT

1. Pry off switch cap (A).
2. Pull switch (B) straight up with pliers.
3. To install the new switch push it straight down, making sure that rib and groove (C) align.



TM1545,4005.B -19-09AUG93


CONTROL PANEL KNOB AND TOGGLE TYPE SWITCH REPLACEMENT

1. Remove four screws (A) under control panel (B). One is under ashtray. Lift up panel, pulling harness with it.
2. Turn panel over and remove four screws. Remove circuit board if you are replacing toggle switch or unloading auger engage switch.



TM1545,4005.C -19-09AUG93

REMOVE AND INSTALL LEVEL SENSING CONTROL SWITCHES, TRANSISTORS AND DASHPOT



A—Wiring Lead
B—Switch

C—Transistor
D—Dashpot

E—Nut
F—Nut

G—Pendulum
H—Orifice Screw



H45360
-JUN-13NOV92

TM1545,4010,A -19-09AUG93

Leveling System Repair

NOTE: Switch, transistors, and dashpot, CAN NOT be repaired. They MUST be replaced.

1. Remove control box cover.
2. Replace switch (B) and transistor (C) as required.
3. Swing pendulum (G) to left to replace dashpot (D). Remove nuts (E and F). Install dashpot with NEW nuts (E and F).
4. Turn in adjusting orifice screw (H) until tilting the control box with the hands will not cause the pendulum to move. Back out orifice screw (H) until the pendulum (G) sluggishly swings when the control box is tilted.



TM1545,4010,B -19-09AUG93

DASHPOT ORIFICE ADJUSTMENT

IMPORTANT: Never steam clean or spray water on leveling control box. Moisture could condense in control box and cause malfunction.

When transporting or hauling combine, turn in the screw (B) on the bottom of the level sensing control box. This prevents the pendulum from moving. Turn screw out ten turns and lock with locking nut for field operation.

1. Manually move pendulum to either side; then release after combine is tilted. Leveling system should return combine to level position and then shut off. Two conditions could result, indicating needed dashpot orifice adjustment.

A. Combine stays fully tilted to same side. This indicates that the dashpot orifice is too small, causing pendulum to always actuate the tilt switch. This condition may affect the adjustment of the level sensing control box when replacing complete control box. Screw dashpot orifice outward until condition B occurs. Proceed to corrective action for condition B.


B. Combine comes to level and then levels in opposite direction. This condition indicates that the dashpot orifice is too large, causing pendulum to swing to other side rather than stopping in centered position. Turn the absorber orifice screw inward until correct leveling action is obtained.

TM1545,4010,C -19-09AUG93

2. Loosen bolts (A) to adjust the control box.
3. Rotate bottom edge of control box toward high side of separator.

NOTE: Rotating bottom edge of control box 3 mm (1/8 in.) will change level of separator about one degree.

4. Tighten bolts (A).




-JUN-08-JUL191
H43669

HX,1545,4010,C -19-18NOV92

REPLACING COMPLETE CONTROL BOX

1. Remove defective control box from combine.
2. Loosen locking nut (A); then back off ten complete turns on the shipping screw. Retighten lock nut.
3. Install new control box on combine.
4. Adjust dashpot orifice. (See instructions in this group.)




HX.1545.4010.D -19-09AUG93

H45027
-UN-27AUG92

TILT LIMIT SWITCHES

The right and left tilt limit switches (A) are located in front of the left-hand side leveling cylinder. These limit switches stop the leveling action when the machine is at the end of its leveling cycle by cutting off electrical current flow to the tilt solenoids of the leveling control valve. This prevents the combine hydraulic system pressure from going to relief valve setting when at full tilt which can cause overheating if sustained.




TM1545.4010.D -19-29MAR93

H43667
-UN-08JUL91


REMOVE AND INSTALL SIDEHILL LEVELING LIMIT SWITCHES

1. Disconnect wiring lead connectors (A).
2. Remove limit switches (B).
3. Switches CANNOT be repaired. They **MUST** be replaced.
4. Install switches.



H44745
-UN-29JUN92

- A—Wiring Lead (2 used)
- B—Switch (2 used)
- C—Self-Locking Screw (2 used)
- D—Bracket
- E—Connector (2 used)
- F—Bracket
- G—Screw and Flange Nut (2 used)
- H—Clip
- I—Angle (2 used)
- J—Bolt and Flange Nut (4 used)
- K—Cap Screw, Washer, and Lock Nut (2 used)



H44746
-UN-29JUN92

HX,1545,4010,AD-19-09AUG93



ADJUST SIDEHILL LEVELING LIMIT SWITCHES

IMPORTANT: Damage to hydraulic system may result if switches are not adjusted properly.

1. Start engine and press bottom (O) of leveling control switch (A) to turn off automatic leveling system.

IMPORTANT: Parking brake must be disengaged before tilting combine.

2. Press top of manual leveling switch (B) until combine reaches leveling limit (right-hand cylinder fully extended and left-hand cylinder fully retracted). Hold leveling switch in left tilt position for approximately 15 seconds to be certain right-hand cylinder is fully extended. Turn off engine.





HX,1545,4010,AE-19-09AUG93

3. Check to be certain stop (A) is against limit switch plunger (B) and switch is actuated (indicated by yellow eight in middle of steering column at (C)). If stop is not against limit switch, loosen nut (D) and turn cap screw (E) to move switch against stop.

4. If leveling cylinder stops before it reaches its leveling limit, loosen nut (D) and turn cap screw (E) to move switch away from stop. Press leveling switch to allow cylinder to fully extend. Move switch against stop.

5. Tilt combine in opposite direction and repeat procedure for switch (F).



HX,1401,4025,F -19-18NOV92

Leveling System Repair/Adjust Sidehill Leveling Limit Switches

40
10
8

Section 50 POWER TRAIN REPAIR

Contents

Page

Group 05—Transmission and Differential

Transmission Drive Shaft Assembly	50-05-1
Remove Transmission	50-05-2
Install Transmission	50-05-3
Adjust Gearshift Linkage	50-05-4


Group 10—Ring and Pinion Final Drive

Remove Final Drive	50-10-1
Install Final Drive	50-10-5

50

Contents

TRANSMISSION DRIVE SHAFT ASSEMBLY



1—Yolk
2—Snap Ring
3—Washer

4—Bolt
5—Lubrication Fitting
6—Strap

7—Cap Screw
8—U-Joint Assembly
9—Seal

10—Lubrication Fitting
11—Spacer
12—Drive Shaft

Legend—Transmission Drive Shaft

H45745 -UN-11MAR93

TM1545,5005,A -19-09AUG93


REMOVE TRANSMISSION

CAUTION: Approximate weight of transmission is 306 kg (675 lbs).

Raise feeder house and lower safety stop.

Block wheels before working on combine.


1. (Not Illustrated) Remove hydrostatic motor. (See procedure in TM1401, Section 50, Group 20.)
2. Tap down lock straps (B).
3. Remove four cap screws (C) from yoke.
4. Remove bearing caps (A). Both sides.
5. Remove U-Joint.



H44512
-JUN-21MAY 92

HX,1545,5005,A -19-18NOV92

6. Remove cap screw and washer (A).
7. Remove yoke and spacer (B).
8. Disconnect hydraulic line mounting bracket from transmission (C).
9. (Not Illustrated) Disconnect shift cable at front of transmission.




H44857
-JUN-03AUG92

HX,1545,5005,AB-19-18NOV92

50
05
2

10. Disconnect service brake lines (A).
11. Disconnect parking brake cables (B).
12. Place a jack under transmission.
13. Remove two lower attaching cap screws to front axle. Raise jack slightly and remove two upper cap screws (C).
14. Remove transmission.




HX,TM1545,BC -19-09AUG93

INSTALL TRANSMISSION

CAUTION: Use a lifting device for heavy components.


Raise feeder house and lower safety stop.

1. Use jack to position transmission, install four cap screws (C) to front axle. Tighten to 320 N·m (235 lb-ft).
2. Fill transmission with 9.6L (10 qt) 80W90 lubricant.
3. Connect service brake lines (A) and parking brake cables (B).
4. Connect shift cable (not shown).




TM1545,5005,B -19-09AUG93

5. Attach hydraulic line mounting brake (C) to transmission.
6. Install spacer (D) with small diameter into bore of brake drum against snap ring.
7. Install yoke (B) with cap screw and washer (A). Torque cap screw (A) to 87 N·m (64 lb-ft).



TM1545,5005,C -19-29MAR93

8. Install U-joint.
9. Place bearing caps (A) into yoke and install with four cap screws (C). Torque cap screws (C) to 28 N·m (25 lb-ft).
10. Bend lock straps (B) up against head of cap screws.
11. Install hydrostatic motor (not shown). (See procedure in TM1401, Section 50, Group 20).
12. Adjust gear shift linkage. (**See Adjust Gearshift Linkage in this group.**)




H44512 -JUN-21MAY92

50
05
4


TM1545,5005.D -19-09AUG93

ADJUST GEARSHIFT LINKAGE

1. Shift transmission into second gear. Gearshift lever should be leaning slightly forward.
2. From under cab, loosen nut (A). Remove and adjust balljoint (B) to get 237 mm (9 5/16 in.) dimension, center line of ball joint to center line of bolts (C). Do not adjust clamp (D).
3. Remove ball joint (G) from shift arm (E). Adjust shift arm straight down.
4. Loosen nut (F) and adjust balljoint (G) until stud on balljoint aligns with hole in shift arm (E). Reinstall balljoint (D) to shift arm (E).
5. Check for 237 mm (9 5/16 in.) dimension (H). Do not adjust clamp (I).



H39321 -JUN-11OCT88



H39322 -JUN-11OCT88



- A—Nut
- B—Balljoint
- C—237 mm (9.3 in.) Dimension
- D—Ball Joint and Clamp
- E—Shift Arm
- F—Nut
- G—Balljoint
- H—237 mm (9-5/16 in.) Dimension
- I—Clamp

TM1545,5005.E -19-09AUG93

REMOVE FINAL DRIVE

CAUTION: To prevent personal injury be certain to have all safety locking stops in place.

1. Hold handle (A) and release safety stop by removing spring locking pin (B).
2. Lift stop off of catch and lower it down into cylinder rod.
3. Insert spring locking pin in handle.



HX,1545,5010,A -19-18NOV92

H45378 -UN-18NOV92

H45379 -UN-18NOV92

50
10
1

Ring and Pinion Final Drive/Remove Final Drive

4. Loosen wheel bolts one turn. Do NOT remove at this time.


⚠ CAUTION: Block up front axle before removing wheels. Jack must have a minimum rating of 5443 kg (6 ton).

5. Raise combine with jack (A).

6. Block up front axle.

⚠ CAUTION: The approximate weight of tire and wheel is 340 kg (750 lb) (without liquid ballast).

7. Support tire and wheel (B) and remove wheel bolts to remove front tire and wheel.



H44829 -UN-09JUL92

HX,1545,5010,CA-19-09AUG93

8. Disconnect U-Joint (A) at transmission.




H44820 -UN-09JUL92

HX,1545,5010,CB-19-18NOV92

9. Release tension on springs (A).

10. Disconnect spring assemblies at (B).



H44821 -UN-09JUL92

HX,1545,5010,CC-19-18NOV92

50
10
2

Ring and Pinion Final Drive/Remove Final Drive

11. Remove cover (A).




HX,1545,5010,CD-19-18NOV92

H44822 -UN-09JUL92

! CAUTION: Use hoist and attach chain as illustrated to prevent housing from pivoting when cylinder is disconnected.


12. Attach chain and hoist.



HX,1545,5010,CE-19-18NOV92

H44823 -UN-09JUL92

13. Remove retainer (A) on both sides.




HX,1545,5010,CF-19-18NOV92

H44824 -UN-09JUL92

14. Remove cap screw (A).

15. Push pin with retainer (B) toward outside of combine and remove from cylinder.



HX,1545,5010,CG-19-18NOV92


H44825 -UN-09JUL92

Ring and Pinion Final Drive/Remove Final Drive

16. Remove cap screw (A).
17. Drive out pivot (B) from inside.

CAUTION: The approximate weight of final drive is 340 kg (750 lb).

18. Remove final drive (See procedure in TM1401, Section 50, Group 15).
19. Repair final drive as required. (See procedure in TM1401, Section 50, Group 15).




H44826
-UN-09JUL92

50
10
4

HX,1545,5010,B -19-09AUG93

20. Replace seal (A) and bushing (B) as required.

NOTE: Seal and bushing are press fit. Press seal flush to pivot bore. Seal lip facing into housing.




H44827
-UN-09JUL92

TM1545,5010,A -19-29MAR93

INSTALL FINAL DRIVE

1. Line up final drive and drive pivot (B) in from outside.
2. Use spanner wrench at notches (C) to line up hole in pivot and install cap screw (A). Torque to 500 N·m (369 lb-ft).




H44826 -UN-09JUL92



H44828 -UN-09JUL92

TM1545,5010,B -19-09AUG93


3. Line up piston rod end.
4. Push pin with retainer (B) toward inside of combine.
5. Install cap screw (A). Torque to 130 N·m (96 lb-ft).



H44825 -UN-09JUL92

TM1545,5010,C -19-29MAR93

6. Install retainer (A) on both sides.



H44824 -UN-09JUL92

HX,1545,5010,CK-19-18NOV92

Ring and Pinion Final Drive/Install Final Drive

7. Remove chain and hoist.

8. Install cover (A).




HX,1545,5010,CL-19-18NOV92

H44822
-UN-09JUL92

9. Connect spring assemblies at (B).

10. Tighten spring tension (A).



TM1545,5010,D -19-09AUG93

H44821
-UN-09JUL92

11. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).


Washer (D) on rear spring should align with upper mark (E) on rear spring carrier (F).

To raise left-hand side of header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring an equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.

To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.

Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.




- A—Washer
- B—Lower Mark
- C—Front Spring Carrier
- D—Washer
- E—Upper Mark
- F—Rear Spring Carrier
- G—Adjusting Nut
- H—Adjusting Nut

TM1545,HX5010,A-19-09AUG93

H44239
-UN-14APR92

Ring and Pinion Final Drive/Install Final Drive

12. Connect U-joint (A) at transmission. Torque bolts to 28 N·m (21 lb-ft).
13. Install tire and wheel.
14. Tighten bolts to 200 N·m (150 lb-ft) then an additional 90°.
15. Remove blocks and jack.
16. Release cylinder lock bar and lower feeder house.



TM1545,5010,E -19-09AUG93

H44820 -UN-09JUL92

50
10
7

Ring and Pinion Final Drive/Install Final Drive

50
10
8

Section 60 POWER STEERING AND BRAKES

Contents

Page

Group 05—Brakes

Remove Brake Drum	60-05-1
Install Brake Drum	60-05-2

Contents


REMOVE BRAKE DRUM

CAUTION: Raise feeder house and lower safety stop. Block up wheels before working on machine.

Engine must be off and key removed.


Cracking of hydraulic line fittings to lower feeder house results in an instantaneous dropping of feeder house and header.

1. Hold handle (A) and release safety stop by removing spring locking pin (B). Lift stop off latch and lower it down onto cylinder rod. Insert spring locking pin in handle.



-UN-18NOV92

H45378



-UN-18NOV92

H45379

HX,1545,6010,A -19-18NOV92

2. Tap down lock straps (B).
3. Remove four cap screws (C) from yoke.
4. Remove bearing caps (A) on both sides.
5. Remove U-Joint.



-UN-21MAY92


H44512

HX,1401,6010,AC-19-30SEP92

Brakes/Install Brake Drum

6. Remove cap screw and washer (A).
7. Remove yoke (B) and spacer (C).
8. Remove brake drum (D).
9. Inspect parts and replace as required.

A—Cap Screw and Washer
B—Yoke
C—Spacer
D—Brake Drum




HX,1545,6010,CA-19-18NOV92

INSTALL BRAKE DRUM

1. Install brake drum (D).
2. Install spacer (C) with small diameter into bore of brake drum against snap ring and yoke (B).
3. Install washer and cap screw (A). Torque to 87 N·m (64 lb-ft).

A—Cap Screw and Washer
B—Yoke
C—Spacer
D—Brake Drum



TM1545,6005,A -19-09AUG93

4. Install U-joint.
5. Install parts (A—C). Torque bolts (C) to 28 N·m (21 lb-ft).
6. Secure lock strap around cap screw heads.



TM1545,6005,B -19-29MAR93

Section 70 HYDRAULIC REPAIR

Contents

Page

Group 05—Hydraulic Valves

Service Equipment and Tools	70-05-1
Leveling Solenoid Valve and Flow Divider .	70-05-2
Leveling Valve Oil Lines and Hoses	70-05-4
Flow Divider Valve	70-05-5
Remove and Install Valve Block Solenoid .	70-05-6
Prevent Hydraulic System Contamination .	70-05-6
Check Oil Lines and Fittings	70-05-7
Repair Check Valve	70-05-10
Remove Right Leveling Cylinder	70-05-12
Install Right Leveling Cylinder	70-05-14
Remove Left Leveling Cylinder	70-05-16
Install Left Leveling Cylinder	70-05-18
Disassemble Leveling Cylinders	70-05-24
Assemble Leveling Cylinders	70-05-26
Leveling Header	70-05-27

70

SERVICE EQUIPMENT AND TOOLS


*NOTE: Order tools from the SERVICE-GARD™ Catalog.
Some tools may be available from a local
supplier.*

Number	Name	Use
D15032NU	Vacuum Pump Kit	To pull vacuum on the reservoir when removing and installing system components

TM1545,7005,A -19-29MAR93

70
05
1

LEVELING SOLENOID VALVE AND FLOW DIVIDER



70
05
2

-UN-16OCT92

H45310

HX.1545.7005.A -19-18NOV92

Hydraulic Valves/Leveling Solenoid Valve and Flow Divider


1—Bracket	6—O-Ring (6 used)	12—Solenoid Valve	15—O-Ring (3 used)
2—Screw, M8 x 20 (2 used)	7—O-Ring (3 used)	13—Screw, M8 x 80 (3 used)	16—O-Ring
3—Flow Divider	8—Straight Adapter	14—Straight Adapter (2 used)	17—Straight Fitting
4—O-Ring	9—Straight Adapter		18—Straight Fitting
5—Straight Adapter	10—O-Ring (3 used)		19—Tee Fitting
	11—Screw, M8 x 70 (2 used)		

Legend—Leveling Valve/Flow Divider

TM1545,7005.B -19-09AUG93

70
05
3

LEVELING VALVE OIL LINES AND HOSES



70
05
4

-UN-16OCT92

H45311

HX.1545.7005.C -19-18NOV92

Hydraulic Valves/Flow Divider Valve

- 1—Hose, 34-1/2 x 1 in.
- 2—O-Ring (4 used)
- 3—O-Ring (5 used)

- 4—Hose, 30-1/2 x 1 in.
- 5—Pressure Oil Line
- 6—Return Oil Line


- 7—Hose, 30-1/2 x 1 in.
- 8—Plug
- 9—Plug

- 10—Hose, 26-1/4 x 13/16 in.
- 11—Oil Line

Legend for Valve Oil Lines

HX,1545,7005,D -19-09AUG93

FLOW DIVIDER VALVE



- 1—O-Ring (2 used)
- 2—Plug (2 used)

- 3—O-Ring
- 4—Rubber Back-Up Ring


- 5—O-Ring
- 6—Valve

- 7—Flow Divider

H45312 -UN-16OCT92

HX,1545,7005,E -19-18NOV92

REMOVE AND INSTALL VALVE BLOCK SOLENOID



- | | | | |
|----------------------------|---------------------|--------------------------|--------------------|
| 1—Short Spool (2 used) | 8—Guide (2 used) | 14—Pin (2 used) | 20—O-Ring |
| 2—Spring (2 used) | 9—Ring (4 used) | 15—Bearing Cone (2 used) | 21—Drain Plug |
| 3—Long Spool (2 used) | 10—O-Ring (2 used) | 16—O-Ring (2 used) | 22—Fitting |
| 4—Case (2 used) | 11—Pin (2 used) | 17—Cap (2 used) | 23—O-Ring |
| 5—Electrical Coil (2 used) | 12—Tube (2 used) | 18—Solenoid Kit | 24—Spool Kit |
| 6—End Plate (2 used) | 13—Plunger (2 used) | 19—Bushing (2 used) | 25—O-Ring (2 used) |
| 7—Screw (8 used) | | | |

HX,1545,7005,F -19-09AUG93

PREVENT HYDRAULIC SYSTEM CONTAMINATION

IMPORTANT: Cleanliness is very important when working on the hydraulic system. Prevent contamination by assembling the cylinders, hoses, couplers, and valves in a clean area of the shop.

Leave protective caps on the fluid openings until ready to make the connection. Keep couplers clean. Abrasive particles, like sand or metal fragments, can damage seals, barrels and pistons, causing internal leakage.

HX, TM1545, FA -19-09AUG93

CHECK OIL LINES AND FITTINGS



⚠ CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Check all oil lines, hoses and fittings regularly for leaks or defects. Make sure all clamps are in position and tight. Make sure hoses are not twisted or touching machine parts which are moving. Replace damaged parts.

IMPORTANT: Tighten fittings as specified in torque chart.

If necessary, use two wrenches to prevent hoses from twisting, bending or breaking tubing and fittings.



-UN-23AUG88

X9811


-UN-23FEB92

H44023

70
05
7

REMOVE AND INSTALL VALVE BLOCK SOLENOID

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.



If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

“Cracking” hydraulic lines fitting to lower header will result in an instantaneous dropping of the header and expulsion of the sealing O-ring in the fitting.

1. Lower header to ground. Stop engine. Operate hydraulic controls to relieve pressure.


HX,1545,7005,G -19-09AUG93

2. Install D15032NU Vacuum pump on reservoir. This will allow removing the valve without draining the reservoir. If vacuum pump is NOT available, drain reservoir. Approximate capacity is 34 L (36 qt).

3. Remove parts (A—G).

4. Remove cap (H).

A—End Plate
 B—Screws (4 used)
 C—Case
 D—Electrical Coil
 E—Spool
 F—Spring
 G—Spool
 H—Cap



HX,1401,7015,C -19-12AUG92


Hydraulic Valves/Check Oil Lines and Fittings

5. Disassemble cap parts (A—G).

6. Inspect parts. Replace parts that are worn or damaged.

7. Assemble parts (A—G).

- | | |
|-----------|----------------|
| A—Guide | E—Bearing Cone |
| B—Tube | F—Spring |
| C—Plunger | G—Bushing |
| D—Pin | |



H44549 -UN-03AUG92

HX,1401,7015,D -19-12AUG92

8. Install cap (H).

9. Install parts (A—G).

- | |
|-------------------|
| A—End Plate |
| B—Screws (4 used) |
| C—Case |
| D—Electrical Coil |
| E—Spool |
| F—Spring |
| G—Spool |
| H—Cap |



H44548 -UN-03AUG92

HX,1401,7015,E -19-12AUG92

70-05-9


REPAIR CHECK VALVE

1. Lower header to ground. Stop engine. Operate hydraulic controls to relieve pressure.

! **CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

! **CAUTION:** "Cracking" hydraulic lines fitting to lower header will result in an instantaneous dropping of the header and expulsion of the sealing O-ring in the fitting.




X9811 -JUN-23AUG88

70
05
10

HX,1545,7005,H -19-18NOV92

2. Install D15032NU Vacuum Pump on reservoir. This will allow removing the valve without draining the reservoir. If vacuum pump is not available, drain reservoir. Approximate capacity is 34 L (36 qt.).

3. Remove two cap screws (A) and check block (B).




H44550 -JUN-03AUG92

HX,1545,7005,I -19-09AUG93

Hydraulic Valves/Repair Check Valve

4. Remove parts (A—F).

- A—Poppet
- B—Ball Check
- C—Spring
- D—Spring
- E—O-Ring
- F—Plug



HX,1401,7015,H -19-09AUG93

H44551 -UN-03AUG92


5. Disassemble parts (A—F).

6. Inspect parts. Replace parts that are worn or damaged.

7. Assemble parts (A—E).

8. Install set screw.

- | | |
|----------|--------------|
| A—Plug | D—Spring |
| B—Ball | E—Restrictor |
| C—Poppet | F—Set Screw |




HX,1545,7015,BA-19-09AUG93

H44552 -UN-03AUG92

9. Install parts (A—F).


- A—Poppet
- B—Ball Check
- C—Spring
- D—Spring
- E—O-Ring
- F—Plug



HX,1545,7015,BB-19-09AUG93

H44551 -UN-03AUG92


10. Inspect O-rings (A). Replace if necessary.



HX,1401,7015,K -19-09AUG93

H44553 -UN-03AUG92

11. Install check block (B) using cap screws (A).



HX,1401,7015,L -19-09AUG93



H44550 -UN-03AUG92

REMOVE RIGHT LEVELING CYLINDER

! **CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

1. Turn off engine and remove key.
2. Place block under combine frame (A).




TM1545,7005,D -19-09AUG93

X9811 -UN-23AUG88

H44559 -UN-03AUG92

Hydraulic Valves/Remove Right Leveling Cylinder


3. Open bleed screw (A) allowing combine to settle on block. Do not close bleed screw.
4. Disconnect hydraulic lines (B).



HX,1401,7020,D -19-12AUG92

H44557 -UN-03AUG92

5. Remove cap screw (A) and pin (B).




HX,1401,7020,E -19-12AUG92

H44560 -UN-03AUG92

⚠ CAUTION: The approximate weight of cylinder is 36 kg (80 lbs).

6. Attach lifting device.
7. Remove four cap screws (A) and pillow blocks (B).
8. Turn cylinder 90° and separate cylinder from trunnion.
9. Inspect parts and repair as needed.



HX,1545,7005,M -19-09AUG93


H44558 -UN-03AUG92

INSTALL RIGHT LEVELING CYLINDER

1. Assemble cylinder to trunnion.

⚠ CAUTION: The approximate weight of cylinder is 36 kg (80 lbs).


2. Install four cap screws (A) and pillow blocks (B).
Torque to 130 N·m (96 lb-ft).



TM1545A,7005A,A-19-09AUG93

H44558 -UN-03AUG92

3. Install pin (B) and cap screw (A). Torque to 130 N·m (96 lb-ft).




TM1545,7005,F -19-29MAR93

H44560 -UN-03AUG92

4. Connect hydraulic lines (B).

5. Close bleed screw (A).




TM1545,7005,G -19-29MAR93

H44557 -UN-03AUG92

70
05
14

Hydraulic Valves/Install Right Leveling Cylinder

6. Start engine.
7. Remove block (A).
8. Manually tilt to either side and hold for fifteen seconds. Return combine to level. Repeat tilting in opposite direction.
9. Perform tilting cycle three times to rephase system.



H44559 -UN-03AUG92

TM1545,7005,H -19-09AUG93



70
05
15

REMOVE LEFT LEVELING CYLINDER

CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.


If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

1. Turn off engine and remove key.
2. Place block under combine frame (A).



TM1545,7005,1 -19-09AUG93


3. Open bleed screw (A) allowing combine to settle on block. Do not close bleed screw.
4. Remove hydraulic lines (B—D).



HX,1401,7020,M -19-12AUG92

Hydraulic Valves/Remove Left Leveling Cylinder

5. Remove cap screw (A) and pin (B).




HX.1401.7020.N -19-12AUG92

H44560 -UN-03AUG92

CAUTION: The approximate weight of cylinder and trunnion is 45 kg (100 lbs).

6. Attach a safe lifting device.
7. Remove hose clamp (A) and four cap screws (B) retaining trunnion assembly to final drive.
8. Remove cylinder and trunnion assembly from final drive.



TM1545.7005.J -19-29MAR93

H44560 -UN-03AUG92

70
05
17

Hydraulic Valves/Install Left Leveling Cylinder

9. Remove four cap screws (A) and pillow blocks (B).
10. Turn cylinder 90° and separate cylinder from trunnion.
11. Inspect parts and repair as needed.



TM1545,7005,K -19-09AUG93

INSTALL LEFT LEVELING CYLINDER


CAUTION: The approximate weight of cylinder and trunnion is 45 kg (100 lbs.).

1. Attach a safe lifting device.
2. Assemble cylinder and trunnion assembly.
3. Install pillow blocks (B) and four cap screws (A). Torque to 130 N·m (96 lb-ft).



TM1545,7005,L -19-09AUG93


4. Assemble trunnion assembly to final drive. Install four cap screws (B). Torque to 620 N·m (457 lb-ft).
5. Attach hose clamp (A) to bracket.



TM1545,7005,M -19-09AUG93

Hydraulic Valves/Install Left Leveling Cylinder


6. Install pin (B) and cap screw (A). Torque to 130 N·m (96 lb-ft).



HX,TM1545,FB -19-09AUG93

H44560 -UN-03AUG92

7. Attach hydraulic lines (B—D).
8. Close bleed screw (A).




TM1545,7005,N -19-29MAR93

H44555 -UN-03AUG92

70-05-19

Hydraulic Valves/Install Left Leveling Cylinder

9. Start engine.
10. Remove block (A).
11. Manually tilt to either side and hold for fifteen seconds. Return combine to level. Repeat tilting in opposite direction.
12. Perform tilting cycle three times to rephase system.



H44559 -UN-03AUG92

70
05
20



TM1545,7005,O -19-09AUG93

REMOVE AND DISASSEMBLE LEVELING CYLINDER VALVE BLOCK

- ⚠ CAUTION:** The valve block may be serviced with the leveling cylinder on the combine. Be certain to support both leveling cylinders before removing valve block.
- ⚠ CAUTION:** Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.


1. Turn off engine and remove key.
2. Place block under combine frame (A) on both sides.
3. Drain leveling system. Disconnect hoses from valve block. Mark hoses to insure correct installation.
4. Plug all outlets in valve block. Clean valve block for disassembly.



X9811 -JUN-23AUG88

H44559 -JUN-03AUG92

70
05
21



1—Fitting	8—Seat	14—Ball	20—O-Ring
2—Back-Up Ring	9—O-Ring	15—O-Ring	21—Fitting
3—O-Ring	10—Washer	16—Ring	22—Valve Block
4—Spring	11—O-Ring	17—Bleed Screw	23—Cap Screw, 3/8 x 2-1/2 (4 used)
5—Case	12—Ring	18—Pin	24—Washer
6—Back-Up Washer	13—Gasket	19—Plunger	
7—O-Ring			

Legend For Valve Block

5. Remove four cap screws (23) from valve block to cylinder.

6. Remove valve block.

7. Disassemble valve block. Remove all O-rings and backup washers. Replace with new parts.

8. Wash parts in clean solvent and dry with compressed air.

9. Inspect valve block and components. Continuous settling of a leveling cylinder and frequent rephasing, indicates defective backup washer (6), O-ring (7) or O-ring (11). A defective seat (8), or valve block (22) may also cause this. These parts may cause leakage of oil from balance beam hose to drain line.

10. Plunger (19) and pin (18) must move freely in valve block. If one or both of these parts stick. Combine will not level and relief valve will open.

TM1545.7005.Q -19-09AUG93

ASSEMBLE/INSTALL VALVE BLOCK

1. Install internal components of valve block. Coat parts with hydraulic oil during installation.

2. Ring (16) must be heated in hot oil to allow installation on bleed screw (17). Tighten bleed screw to 8—11 N·m (6—8 lb-ft).

3. Attach valve block to cylinder with four bolts (23) previously removed. Torque to 40 N·m (30 lb-ft).

TM1545.7005.S -19-09AUG93


Hydraulic Valves/Install Left Leveling Cylinder

4. Connect hoses to valve block.
5. Fill reservoir with oil.
6. Start engine, manually tilt combine to either side and hold for fifteen seconds. Return combine to level. Repeat tilting opposite direction.
7. Perform tilting cycle three times to rephase system.

TM1545,7005,T -19-29MAR93

70
05
23

DISASSEMBLE LEVELING CYLINDERS



H45747 -UN-11MAR93

- | | | | |
|------------------|-----------------------------|--------------------------|------------------------|
| 1—Fitting | 14—Ball | 25—Shim, 3/4 x 0.038 in. | 36—Piston |
| 2—Back-Up Ring | 15—O-Ring | 26—Shim, 3/4 x 0.015 in. | 37—O-Ring |
| 3—O-Ring | 16—Ring | 27—O-Ring (2 used) | 38—O-Ring |
| 4—Spring | 17—Bleed Screw | 28—Back-Up Ring | 39—Barrel |
| 5—Case | 18—Pin | (2 used) | 40—Back-Up Ring |
| 6—Back-Up Washer | 19—Plunger | 29—Tube | 41—Guide |
| 7—O-Ring | 20—O-Ring | 30—Nut | 42—Seal |
| 8—Seat | 21—Plug | 31—O-Ring (2 used) | 43—Seal |
| 9—O-Ring | 22—Valve Block | 32—Wear Ring (2 used) | 44—Lock Ring |
| 10—Washer | 23—Cap Screw, 3/8 x 2-1/2 | 33—Back-Up Ring (2 used) | 45—Nut |
| 11—O-Ring | in. | 34—Seal | 46—Lubricating Fitting |
| 12—Ring | (4 used) | 35—Piston Ring | 47—Rod |
| 13—Gasket | 24—Washer, 3/8 in. (4 used) | | |

70
05
24

Hydraulic Valves/Disassemble Leveling Cylinders


NOTE: If cylinder is to be serviced with valve block in place, open bleed screw to remove cylinder pressure.

1. Clean cylinder to prevent contamination of internal parts.
2. Remove four cap screws (23) and remove valve block (22) if needed.
3. Use a JDG-28 spanner wrench or brass drive to loosen nut (45) from rod guide.
4. Push guide (41) into barrel (39) and remove lock ring (44).
5. Pull and turn rod (47) out of barrel with guide and piston assemblies.
6. Remove nut (30).
7. Remove piston assembly (36) and guide assembly (41) from rod (47).
8. Inspect parts. Contamination, causing scoring of barrel (39) and damage to piston ring (35) and wear ring (32) is most likely failure. Wear ring (32) centers piston (36) in barrel (39) and does not seal. Sealing is done by the seal (34) and is forced against the cylinder wall by backup rings (33). A damaged seal (34) may cause settling of the leveling cylinder.
9. Remove all O-rings and seals, clean parts and dry with compressed air.

TM1545,7005,V -19-29MAR93

70
05
25

ASSEMBLE LEVELING CYLINDERS



H45747 -UN-11MAR93

- | | | | |
|------------------|--|-----------------------------|------------------------|
| 1—Fitting | 14—Ball | 24—Washer, 3/8 in. (4 used) | 36—Piston |
| 2—Back-Up Ring | 15—O-Ring | 25—Shim, 3/4 x 0.038 in. | 37—O-Ring |
| 3—O-Ring | 16—Ring | 26—Shim, 3/4 x 0.015 in. | 38—O-Ring |
| 4—Spring | 17—Bleed Screw | 27—O-Ring (2 used) | 39—Barrel |
| 5—Case | 18—Pin | 28—Back-Up Ring (2 used) | 40—Back-Up Ring |
| 6—Back-Up Washer | 19—Plunger | 29—Tube | 41—Guide |
| 7—O-Ring | 20—O-Ring | 30—Nut | 42—Seal |
| 8—Seat | 21—Plug | 31—O-Ring (2 used) | 43—Seal |
| 9—O-Ring | 22—Valve Block | 32—Wear Ring (2 used) | 44—Lock Ring |
| 10—Washer | 23—Cap Screw, 3/8 x 2-1/2 in. (4 used) | 33—Back-Up Ring (2 used) | 45—Nut |
| 11—O-Ring | | 34—Seal | 46—Lubrication Fitting |
| 12—Ring | | 35—Piston Ring | 47—Rod |
| 13—Gasket | | | |

70
05
26

Hydraulic Valves/Leveling Header

1. Install parts from seal kit in guide (41). Coat parts with hydraulic oil before installation. Install nut (45) on rod (47) and install guide assembly (41) on rod (47).
2. Install seal kit on piston (36). Coat parts with hydraulic oil before installation.
3. Install piston assembly (36) on rod (47).
4. Install rod nut (30). Torque nut to 463 N·m (341 lb-ft).
5. Coat cylinder barrel bore (39) with hydraulic oil.
6. Slide rod assembly into barrel (39).
7. Push guide assembly (41) into barrel bore far enough to install lock ring (44).
8. Thread nut (45) on rod guide (41).
9. Use JDG-28 Spanner Wrench and torque nut (45) to 390 N·m (287 lb-ft).

TM1545.7005.X -19-29MAR93


70
05
27

LEVELING HEADER


IMPORTANT: Check leveling each time a header is changed.

Gearshift lever must be in neutral and the parking brake lever released before tilting combine.

1. Press bottom of switch (A) to turn off leveling system.
2. Press switch (B) to tilt combine to the far left and far right positions for 15 seconds. This rephases leveling cylinders.
3. Drive combine onto a level surface and shut off engine.
4. Lubricate feeder house front sheets.
5. Check drive tire inflation for correct pressure.



-UN-14APR92
H44237



-UN-14APR92
H44238

TM1545.7005.Y -19-09AUG93

Hydraulic Valves/Leveling Header

6. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).


7. Washer (D) on rear spring should align with upper mark (E) on rear spring carrier (F).

8. To raise left-hand side of header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring an equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.

9. To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.

10. Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.



- A—Washer
- B—Gauge Mark
- C—Front Spring Carrier
- D—Washer
- E—Gauge Mark
- F—Rear Spring Carrier
- G—Nut

70
05
28

TM1545,7005,Z -19-09AUG93

Section 100
HEADER DRIVE REPAIR

Contents

Page

Group 05—Header Drive Shaft Repair


Disassemble Header CV Drive Shaft 100-05-3

Assemble Header CV Drive Shaft 100-05-10

100

Contents

HEADER DRIVE SHAFT



H45750
-UN-22MAR93

- | | | | |
|-----------------------|-------------|------------------------|-------------------------------|
| 1—Yoke | 5—Shaft | 9—Shield | 13—U-Joint |
| 2—Lubrication Fitting | 6—Bearing | 10—Shield | 14—Bolt, M12 x 70
(4 used) |
| 3—Snap Ring | 7—Snap Ring | 11—Lubrication Fitting | |
| 4—U-Joint | 8—Decal | 12—Tube | |


Legend—Header Drive Shaft*

*444 Corn Head and 914 BPU ONLY

TM1545,10005,A -19-09AUG93

100
05
1

HEADER CV DRIVE SHAFT



H45750
-UN-22MAR93


- | | | | |
|-----------------------|-----------------------|------------|-------------------------------|
| 1—Yoke | 6—Lubrication Fitting | 10—Decal | 14—Yoke Tube |
| 2—Lubrication Fitting | 7—Yoke Shaft | 11—Shield | 15—U-Joint |
| 3—Snap Ring | 8—Snap Ring | 12—Shield | 16—Bolt, M12 x 70
(4 used) |
| 4—U-Joint | 9—Shield Retainer | 13—Bearing | |
| 5—U-Joint Yoke | | | |

Legend—CV Header Drive Shaft

100
05
2

DISASSEMBLE HEADER CV DRIVE SHAFT

1. Separate shaft (A) into two halves by pulling apart.



-UN-22MAR93

H45751



-UN-22MAR93

H45752

TM1545,10005,C -19-29MAR93

100
05
3

Header Drive Shaft Repair/Disassemble Header CV Drive Shaft

2. Insert screw driver in shaft shield holes (A) and push snap ring (B) toward U-joints.

3. Remove shield from shaft assembly.



H45753 -UN-22MAR93



H45754 -UN-22MAR93

100
05
4

TM1545,10005,D -19-29MAR93

TM1545 (04JAN01)


100-05-4

040101
PN=89

Header Drive Shaft Repair/Disassemble Header CV Drive Shaft


4. Remove shield bearing (A) and snap ring (B) from shaft.

5. Inspect bearing for wear. Replace as necessary.



TM1545,10005,E -19-29MAR93

6. Remove all snap rings (A) from u-joint yokes.



TM1545,10005,F -19-29MAR93

Header Drive Shaft Repair/Disassemble Header CV Drive Shaft

7. Support center yoke (A) on bottom and drive U-joint bearing out with driver. Bearing cap will be partially forced out of yoke.



H45757
-JUN-22MAR93

TM1545,10005,G -19-29MAR93

100
05
6

8. Rotate shaft with exposed bearing cap (C) up. Support end yoke (A) in vise and drive center yoke (B) down to push out bearing cap (C).



H46069
-JUN-04AUG93

TM1545,10005,H -19-09AUG93

TM1545 (04JAN01)

100-05-6

040101
PN=91

Header Drive Shaft Repair/Disassemble Header CV Drive Shaft

9. Remove drive shaft assembly from vise and rotate. Clamp exposed bearing cap in vise.


10. Drive center yoke (A) up off bearing cap.



TM1545,10005,I -19-09AUG93

H45759 -UN-22MAR93

11. Remove drive shaft from vise and rotate. Support end yoke (A) in vise and drive center yoke down (B) to drive out opposite bearing cap (C).



TM1545,10005,J -19-09AUG93

H46089 -UN-04AUG93

100
05
7

Header Drive Shaft Repair/Disassemble Header CV Drive Shaft

12. Rotate shaft in vise and clamp bearing cap in vise.


13. Drive center yoke (A) up off bearing cap.



TM1545,10005,K -19-09AUG93

H45759 -UN-22MAR93


14. Separate end yoke (A) from center yoke (B).



TM1545,10005,L -19-09AUG93

H45760 -UN-22MAR93

15. Support center yoke (A) on bottom and drive U-joint bearing out with driver.




TM1545,10005,M -19-09AUG93

H45761 -UN-22MAR93

100
05
8

Header Drive Shaft Repair/Disassemble Header CV Drive Shaft


16. Clamp bearing cap (A) in vise and drive center yoke (B) up as done previously.



TM1545,10005,N -19-09AUG93

H45762 -UN-22MAR93

17. Support shaft yoke (A) in vise. Drive down center yoke (B) to partially remove opposite bearing yoke (C).




TM1545,10005,O -19-09AUG93

H46069 -UN-04AUG93

18. Separate center yoke from shaft yoke.

19. Inspect ball (A) and socket (B) of yoke ends for wear or galling.

20. Replace yoke and shaft if worn.




TM1545,10005,P -19-09AUG93

H45763 -UN-22MAR93

Header Drive Shaft Repair/Assemble Header CV Drive Shaft

21. Remove U-joint from end yoke (A) and shaft yoke (B) using same procedure. Note position of grease fittings before removal of U-joints.

22. Clean all yokes in solvent. Inspect yokes for wear. Replace as necessary.




TM1545,10005,Q -19-09AUG93

H45764 -UN-22MAR93

ASSEMBLE HEADER CV DRIVE SHAFT

1. Install new U-joints in end yoke (A) and shaft yoke (B). Check position of grease fittings.

2. Install bearing caps and snap rings.




TM1545,10005,R -19-09AUG93

H45764 -UN-22MAR93

3. Install center yoke (B) on shaft yoke.


4. Install bearing caps (A) and snap rings.



TM1545,10005,S -19-09AUG93

H45762 -UN-22MAR93

5. Grease ball (A) and socket (B) before assembly.




TM1545,10005,T -19-29MAR93

H45763 -UN-22MAR93

100
05
10

Header Drive Shaft Repair/Assemble Header CV Drive Shaft

6. Install end yoke (A) to center yoke (B). Be sure ball engages socket.



TM1545,10005,U -19-09AUG93

H45760 -UN-22MAR93

7. Install bearing caps and snap rings.




TM1545,10005,V -19-29MAR93

H45765 -UN-22MAR93

8. Install snap ring (B) on shaft.

9. Install bearing (A) smooth side to U-joints on shaft in groove.



TM1545,10005,W -19-09AUG93

H45765 -UN-22MAR93

Header Drive Shaft Repair/Assemble Header CV Drive Shaft

10. Slide shield over shaft and bearing. Align tabs on bearing with holes in shield (A).

11. Insert screw drivers in holes (A).

12. Pry snap ring (B) into groove of shield.



H45753 -UN-22MAR93



H45754 -UN-22MAR93

100
05
12

TM1545,10005,X -19-29MAR93

TM1545 (04JAN01)

100-05-12

040101
PN=97

Header Drive Shaft Repair/Assemble Header CV Drive Shaft

13. Repeat disassembly and assembly procedures for opposite half of drive shaft if necessary.

14. Assemble two shaft halves together to complete shaft assembly.



H46752 -UN-22MAR93

TM1545,10005,Y -19-09AUG93

100
05
13

Header Drive Shaft Repair/Assemble Header CV Drive Shaft

100
05
14

Section 110 FEEDER HOUSE REPAIR

Contents

Page

Group 05—Feeder House/Conveyor

Remove and Install Feeder House	110-05-1
Install Feeder House	110-05-4
Disassemble and Assemble Feeder Conveyor	110-05-7
Remove and Install Floor Plate	110-05-12
Adjusting Conveyor Tension	110-05-13

Group 10—Feeder House Conveyor Drum

Specifications	110-10-1
Disassemble and Assemble Feeder House Conveyor Drum	110-10-1

Group 15—Conveyor Shaft and Slip Clutch

Other Material	110-15-1
Specifications	110-15-1
Remove and Install Top Conveyor Shaft	110-15-2
Remove and Install Lower Paddle Shaft	110-15-6
Disassemble and Assemble Idlers	110-15-13
Disassemble and Assemble Lower Shaft and Slip Clutch	110-15-14

Contents

110


REMOVE AND INSTALL FEEDER HOUSE

1. Leave header attached to feeder house to act as a counterbalance.
2. Remove feeder house side shields.
3. Remove hose clamps on both sides.
4. Push hoses (A) up and through conveyor drive support (B) on both sides.
5. Disconnect wiring harness (C) and push harness up through conveyor drive support.

IMPORTANT: Do NOT disconnect hoses or dirt will get into hydraulic system.

6. Disconnect reverser cable (D) under feeder house.

- A—Hoses
- B—Support
- C—Harness
- D—Reverser Cable



TM1545,11005,A -19-09AUG93

H42371 -UN-25SEP90


H42614 -UN-25SEP90

110
05
1

Feeder House/Conveyor/Remove and Install Feeder House

7. Loosen nuts (A) to loosen belt (D).
8. Remove cap screw (B) from pump strap.
9. Remove cap screw from electric clutch module strap (C).
10. Remove belt (D) from upper sheave.
11. Lay belt (B) on top of feeder house.


A—Nut
B—Cap Screw
C—Strap
D—Belt



H43650
-UN-01JUL91

TM1545,11005,C -19-09AUG93


12. Disconnect parking brake cables (A) from support (B).



H44321
-UN-11JUN92

TM1545,11005,B -19-29MAR93

13. Loosen nuts (A) to relieve spring tension.
14. Remove cap screws (B) to remove spring assembly.




H44223
-UN-13APR92

TM1545,11005,E -19-29MAR93

Feeder House/Conveyor/Remove and Install Feeder House

15. Remove cap screws (A) and (B) securing pulley assembly.


16. Lay cable and spring assembly on top of feeder house.



TM1545,11005,F -19-29MAR93


17. Remove cylinder rod pin (A) on both sides.

⚠ CAUTION: To prevent injury, block feeder house securely.



TM1545,11005,G -19-29MAR93

18. Pull down lever (A) to drop feed plate.




TM1545,11005,H -19-29MAR93

19. Remove cap screw (A) on both sides with 30 mm socket.

20. Back combine away slowly.


21. Inspect feeder house components. Repair or replace as necessary.



TM1545,11005,I -19-09AUG93

INSTALL FEEDER HOUSE


1. Slowly drive forward to connect feeder house.
2. Apply thread lock and sealer (medium strength) to cap screw threads (A).
3. Install cap screw (A). Tighten to 620 N·m (457 lb-ft).



H44227
-UN-13APR92

TM1545,11005,J -19-29MAR93


4. Pull up lever (A) to raise feed plate.



H43640
-UN-27JUN91

TM1545,11005,K -19-29MAR93


5. Install cylinder pin (A) on both sides.



H44226
-UN-13APR92

TM1545,11005,L -19-29MAR93

6. Install cap screws (A) and (B) to pulley assembly.




H44224
-UN-13APR92

TM1545,11005,M -19-29MAR93

110
05
4

Feeder House/Conveyor/Install Feeder House

7. Install cap screws (B) to secure spring assembly.
8. Tighten nuts (A) to adjust spring tension.




H44223
-UN-13APR92

TM1545,11005,N -19-29MAR93

9. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).
10. Washer (D) on rear spring should align with the upper mark (E) on rear spring carrier (F).
11. To raise left-hand side of the header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring an equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.

12. To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.
13. Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.



H44239
-UN-14APR92

- A—Washer
- B—Gauge Mark
- C—Front Spring Carrier
- D—Washer
- E—Gauge Mark
- F—Rear Spring Carrier
- G—Nut
- H—Nut

TM1545,HX110,AA-19-09AUG93

14. Connect reverser cable (D) under feeder house.




H42614
-UN-25SEP90

TM1545,11005,O -19-09AUG93

Feeder House/Conveyor/Install Feeder House

15. Install ends of parking brake cables (A) through support (B) and reassemble.



-UN-11JUN92
H44321

TM1545,11005,P -19-09AUG93


16. Pull wiring harness (C) through conveyor drive support (B) and connect.

17. Pull hose (A) through conveyor drive support on both sides.

18. Install hose clamps on both sides.

19. Install feeder house side shields.

- A—Hoses
- B—Support
- C—Harness
- E—Belt




-UN-25SEP90
H42371

TM1545,11005,S -19-09AUG93

110
05
6


20. Install feeder house drive belt (D) to electric clutch sheave.
21. Install cap screw to electric clutch module strap (C).
22. Install cap screw (B) in reel pump strap.
23. Tighten nuts (A) to align washer with gauge.



TM1545,11005,Q -19-09AUG93


DISASSEMBLE AND ASSEMBLE FEEDER CONVEYOR

1. Loosen nut (A) to release tension on conveyor chain on both sides.



HX,1545,1105,DA-19-18NOV92


2. Loosen nuts (A) to relieve spring tension.



TM1545,HX110,AC-19-09AUG93

Feeder House/Conveyor/Disassemble and Assemble Feeder Conveyor


3. Remove cap screw (A) and (B) to disconnect cables (C).



HX,1401,1105,AA-19-25AUG92

H44688
-UN-16JUN92

4. Remove two cap screws (B) to remove roller (A) on both sides.




HX,1401,1105,AB-19-25AUG92

H44689
-UN-16JUN92

CAUTION: Approximate weight of feeder house frame is 79 kg (175 lbs).

5. Attach lifting device (A) to frame.
6. Remove parts (B—D) and remove frame (E).


- A—Lifting Chain
- B—Lock Nut
- C—Nut
- D—Washer
- E—Frame



HX,TM1545,BD -19-09AUG93

H44692
-UN-16JUN92

7. Rotate conveyor to gain access to master link.
8. Remove hooks (A) to remove connector links.
9. Pull conveyor out of feeder house.
10. Inspect chain and slats. Repair or replace as required.




HX,1401,1105,AD-19-25AUG92

H40359
-UN-20MAR89

Feeder House/Conveyor/Disassemble and Assemble Feeder Conveyor

11. Grind off rivets to replace slats (A).

12. Rivet slats to chain. If riveting is not possible, a 1/4 x 3/4 in. cap screw and two nuts can be used. Be sure cap screw head is on chain link side.



HX,1401,1105,AE-19-25AUG92

H40370 -UN-20MAR89

13. Pull conveyor into feeder house using a rope (A).




HX,1401,1105,AF-19-25AUG92

H40371 -UN-20MAR89

IMPORTANT: When shortening conveyor chain, remove an offset link from each strand using a chain breaker. Connector link can be reused to connect chain.

14. Connect chain ends with connector links and new hooks (A). On outside chains, install connector links so hooks are toward outside edge of feeder house to prevent pins from striking drum ring.




HX,1401,1105,AG-19-09AUG93

H40359 -UN-20MAR89

15. Install frame (E) and parts (B—D).

16. Remove lifting device (A).

- A—Lifting Chain
- B—Lock Nut
- C—Nut
- D—Washer
- E—Frame




HX,TM1545,BE -19-09AUG93

H44692 -UN-16JUN92

Feeder House/Conveyor/Disassemble and Assemble Feeder Conveyor


17. Install roller (A) and cap screws (B) on both sides.



HX,1401,1105,AI-19-25AUG92

H44689 -UN-16JUN92


18. Install cap screw (A) and (B) to connect cables (C).



HX,1401,1105,AJ-19-25AUG92

H44688 -UN-16JUN92

19. Tighten nuts (A) to adjust tension.



HX,1401,1105,AK-19-25AUG92

H44687 -UN-16JUN92

110
05
10

Feeder House/Conveyor/Disassemble and Assemble Feeder Conveyor

20. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).


21. Washer (D) on rear spring should align with upper mark (E) on rear spring carrier (F).

22. To raise left-hand side of the header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring an equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.

23. To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.


24. Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.



- A—Washer
- B—Gauge Mark
- C—Front Spring Carrier
- D—Washer
- E—Gauge Mark
- F—Rear Spring Carrier
- G—Nut
- H—Nut


TM1545,HX110,AE-19-09AUG93

25. Tighten nut (A) to adjust conveyor chain tension on both sides.



HX,TM1545,BF -19-09AUG93

26. Tighten bolt (A).



HX,TM1545,FC -19-09AUG93


REMOVE AND INSTALL FLOOR PLATE

1. Raise feeder house.

CAUTION: Engine must be off and key removed.


CAUTION: Cracking of hydraulic line fittings to lower feeder house results in an instantaneous dropping of feeder house and header.

Hold handle (A) and release safety stop by removing spring locking pin (B). Lift stop off of latch and lower it down onto cylinder rod. Insert spring locking pin in handle.



-UN-18NOV92

H45378



-UN-18NOV92


H45379

HX,1545,1105,DB-19-18NOV92

2. Loosen nut (A) on reverser cable (B).

3. Remove parts (C—F).

- A—Nut
- B—Cable
- C—Pin
- D—Spring
- E—Pin
- F—Cap Screw



-UN-16JUN92

H44713

HX,1545,1105,DC-19-09AUG93

Feeder House/Conveyor/Adjusting Conveyor Tension

4. Remove floor extension (B) from rear of floor.
5. Remove 20 cap screws and nuts (A) from side and front of feeder house floor.
6. Remove floor.
7. Inspect floor and seal plate. Repair or replace as required.
8. Install floor. Attach with cap screws and nuts (A).



HX,1401,1105,AP-19-25AUG92


H44693
-UN-16JUN92

ADJUSTING CONVEYOR TENSION

Float cams are located on both sides of feeder house.

To set float:

1. Loosen nut (A).
2. For small grain, rotate bolt until hole (B) aligns through side sheet. A wrench flat is provided on bolt.
3. For grain slot clearance, loosen nut (C) and rotate cam (D) to get 3 mm (1/8 in.) slot clearance between slot and feeder house bottom on both sides.
4. To get the 25 mm (1 in.) clearance for corn, loosen nut (A). Rotate bolt until hole (B) is aligned in upper end of slot. Torque nut (A) to 115 N·m (85 lb-ft).
5. Retighten nut (A) and (C).



A—Nut
B—Hole
C—Nut
D—Cam

NOTE: The original cap screws and flange nuts in the feeder conveyor drum pivots were replaced by NEW cap screws (19 M 7399, M16 x 85) and lock nuts (W39621, M16). This will eliminate the need to reach through the inspection hole, with a wrench, to keep bolt from turning.

HX,1545,1105,DD-19-18NOV92

H44711
-UN-16JUN92

110
05
13

Feeder House/Conveyor/Adjusting Conveyor Tension

110
05
14


Group 10 Feeder House Conveyor Drum

SPECIFICATIONS

Item	Measurement	Specification
Conveyor Drum	Approximate Weight	36 kg (80 lb)

1401,11010,A -19-12SEP91

DISASSEMBLE AND ASSEMBLE FEEDER HOUSE CONVEYOR DRUM



- | | | | |
|----------------------------|----------------------------------|---------------------------------|----------------------------|
| A—Drum | H—Bushing (2 used) | N—Housing (2 used) | S—Cotter Pin (2 used) |
| B—Nut (4 used) | I—Nut, M12 (2 used) | O—Ball Bearing (2 used) | T—Pin (2 used) |
| C—Arm (2 used) | J—Cam (2 used) | P—Shaft | U—Bolt (2 used) |
| D—Flange Nut, M16 (6 used) | K—Plate (2 used) | Q—Lock Washer, 3/8 in. (6 used) | V—Strap (2 used) |
| E—Eyebolt | L—Bolt, M12 x 50 (2 used) | R—Cap Screw, M12 x 35 (6 used) | W—Flange Nut, M12 (2 used) |
| F—Eyebolt | M—Collar with Set Screw (2 used) | | |
| G—Washer (2 used) | | | |


HX,1545,1110,BA-19-18NOV92

110
10
UN-17JUL92
H44790

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

NOTE: It is not necessary to remove feeder house to service drum.


1. Loosen nuts (A) to relieve spring tension.



HX,1545,1110,BB-19-18NOV92

-UN-16/JUN92
H44687


2. Remove cap screw (A) and (B) to disconnect cables (C).



HX,1401,1102,G -19-25AUG92

-UN-16/JUN92
H44688

3. Remove two cap screws (B) to remove roller (A) on both sides.




HX,1401,1102,H -19-25AUG92

-UN-16/JUN92
H44689

⚠ CAUTION: Approximate weight of feeder house pivot frame is 79 kg (175 lb).

4. Attach lifting device (A) to frame (E).
5. Remove parts (B—D) and remove frame (E).

- A—Lifting Chain
- B—Lock Nut
- C—Nut
- D—Washer
- E—Frame




HX,1401,1102,I -19-25AUG92

-UN-16/JUN92
H44692

110
10
2

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

6. Loosen nut (A) to release tension on conveyor chain on both sides.




HX,1401,1102,J -19-25AUG92

H44664
-UN-16JUN92

7. Disconnect and remove chain.

8. Remove nut (B), washer (C) and sprocket (A).




HX,1401,1102,K -19-25AUG92

H44701
-UN-16JUN92

9. Remove parts (A—D) on both sides.

- A—Shaft Key
- B—Nut (6 used)
- C—Flange Housing (4 used)
- D—Bearing (2 used)




HX,1545,1110,BC-19-18NOV92

H44702
-UN-16JUN92

10. Loosen 36 nuts (B).

11. Remove shaft (A) from paddles.




HX,1401,1102,M -19-25AUG92

H44703
-UN-16JUN92

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

12. Remove three bolts (C) through access hole in deflector (B) on both sides.

13. Remove paddle assembly (A).




HX,1401,1102,N -19-25AUG92

-UN-16JUN92
H44704

14. Rotate chain so connector links are accessible.

15. Remove hooks (A) and master links.




HX,1401,1102,O -19-25AUG92

-UN-20MAR89
H40359

CAUTION: The approximate weight of conveyor drum is 36 kg (80 lb).

16. Remove cap screw (A) on both sides.

17. Remove drum assembly from feeder house.



HX,1401,1102,P -19-25AUG92


-UN-16JUN92
H44694

18. Remove cotter pin and pin (D) to remove arm (C).

19. Loosen set screw (B). Remove collar (E).

20. Remove three cap screws (A) and housing (F).

- A—Cap Screw (3 used)
- B—Set Screw
- C—Arm
- D—Cotter Pin and Pin
- E—Collar
- F—Housing




HX,1401,1102,Q -19-25AUG92

-UN-20MAR89
H40381

110
10
4

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

21. Rotate bearing (A) to align with oblong slots in housing (B). Remove bearing.
22. Inspect parts. Repair or replace as required.
23. Align bearing (A) with oblong slots in housing (B) and install bearing.




HX,1401,1102,R -19-25AUG92

H40382 -UN-20MAR89

24. Install housing (F) on drum using three cap screws (A).
25. Install collar (E) and set screw (B).
26. Install arm (C) on shaft with pin and cotter pin (D).

- | | |
|-------------------------|-------------------------|
| A—Cap Screw
(3 used) | D—Cotter Pin
and Pin |
| B—Set Screw | E—Collar |
| C—Arm | F—Housing |




HX,1401,1102,S -19-25AUG92

H40381 -UN-20MAR89

CAUTION: The approximate weight of conveyor drum is 36 kg (80 lb).

27. Install drum in feeder house.
28. Secure drum to feeder house with cap screws (A).




HX,1401,1102,T -19-25AUG92

H44694 -UN-16JUN92

29. Connect conveyor chain ends. Use connector links and new hooks (A).

On outside chains, install connector links so hooks are toward outside edge of feeder house to prevent pins from striking drum ring.




HX,1401,1102,U -19-25AUG92

H40359 -UN-20MAR89

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

30. Install paddle assembly (A).

31. Install bolt (C) through access hole in deflector (B).




HX,1401,1102,V -19-09AUG93

H44704
-UN-16JUN92

32. Install shaft (A).

33. Tighten nuts (B) to 4 N·m (30 lb-ft).




HX,1401,1102,W -19-25AUG92

H44703
-UN-16JUN92

34. Install parts (A—D) on both sides.

- A—Shaft Key
- B—Nut (6 used)
- C—Flange Housing (4 used)
- D—Bearing (2 used)




HX,1545,1110,BD-19-18NOV92

H44702
-UN-16JUN92

35. Install sprocket (A), washer (C), and nut (B).

36. Install and connect chain.



HX,1401,1102,Y -19-25AUG92

H44701
-UN-16JUN92


110
10
6

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

37. Install frame (E) using lifting device (A).


38. Install parts (B—D).

- A—Lifting Chain
- B—Lock Nut
- C—Nut
- D—Washer
- E—Frame




HX,1545,1110,BE-19-18NOV92

39. Install roller (A) and cap screw (B) on both sides.



HX,1401,1102,AA-19-25AUG92

40. Install cap screws (A) and (B) to connect cables (C).



HX,1401,1102,AB-19-25AUG92

41. Tighten nuts (A) to adjust spring tension.




HX,1401,1102,AC-19-25AUG92

Feeder House Conveyor Drum/Disassemble and Assemble Feeder House Conveyor Drum

42. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).
43. Washer (D) on rear spring should align with upper mark (E) on rear spring carrier (F).
44. To raise left-hand side of the header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring an equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.


45. To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.
46. Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.



- A—Washer
- B—Gauge Mark
- C—Front Spring Carrier
- D—Washer
- E—Gauge Mark
- F—Rear Spring Carrier
- G—Nut
- H—Nut


TM1545,HX110,AG-19-09AUG93

47. Tighten nut (A) to adjust conveyor chain tension on both sides.



HX, TM1545, BG -19-09AUG93

48. Tighten bolt (A).



HX, TM1545, BH -19-09AUG93

Group 15
Conveyor Shaft and Slip Clutch

OTHER MATERIAL

Number	Name	Use
T43512	Thread Lock and Sealer (Medium Strength)	To seal threads of bolts.

1401,11015.A -19-12SEP91


SPECIFICATIONS

Item	Measurement	Specification
Slip Clutch Shaft Nut	Torque	200 N·m (150 lb-ft)

1401,11015.B -19-12SEP91

110
15
1

Conveyor Shaft and Slip Clutch/Remove and Install Top Conveyor Shaft



A—Lock Nut, M24
B—Nut, M24
C—Washer
D—Spacer
E—Drive Sprocket—
34 Tooth

F—Spacer
G—Housing (2 used)
H—Screw, M12 x 25
(6 used)
I—Ball Bearing

J—Set Screw (6 used)
K—Nut, 3/8 in.
(6 used)
L—Chain Sprocket,
10 Tooth (3 used)


M—Shaft Key, 1/4 x 2 1/8 in.
N—Shaft
O—Ball Bearing
P—Shaft Support

HX,1545,1115,BA-19-09AUG93

110
15
2

REMOVE AND INSTALL TOP CONVEYOR SHAFT

1. Remove shield (A).
2. Remove five cap screws and nuts (G) to remove pulley (H).
3. Loosen nut (F) to release idler sprocket tension on chain.
4. Disconnect and remove chain (E).
5. Remove nuts and washer (C), spacer (D), sprocket (B) and spacer (I).
6. Remove feeder house. (See procedure in Group 05.)




A—Shield
B—Sprocket
C—Nut (2 used)
D—Spacer
E—Chain

F—Nut
G—Nut (5 used)
H—Pulley
I—Spacer

HX,1545,1115,BB-19-18NOV92

Conveyor Shaft and Slip Clutch/Remove and Install Top Conveyor Shaft

7. Loosen nut (A) to release tension on conveyor chain, both sides.




HX,1401,11015,U-19-25AUG92

H44664
-UN-16JUN92

8. Rotate conveyor chain so connecting links are over shaft.

9. Tie and secure conveyor to feeder house frame.

10. Remove hooks (A) and connecting links to separate chains.



TM1545,11015,A -19-29MAR93

H40433
-UN-20MAR89

11. Remove two cap screws to remove side strippers (G), both sides.


12. Remove cap screws (B), both sides.

13. Loosen screws (E) on side sprockets (D).

IMPORTANT: Note the alignment of sprocket screw indent on shaft.

14. Slide left side bearing housing (A) and sprocket toward center shaft.

15. Remove left end shaft through slot (C) in top shaft support to remove shaft (F).



- A—Bearing Housing
- B—Cap Screw
(6 used)
- C—Slot
- D—Sprocket
- E—Screw (4 used)
- F—Shaft
- G—Stripper
(2 used)

HX,1401,11015,W-19-25AUG92


H44688
-UN-16JUN92

110
15
3

Conveyor Shaft and Slip Clutch/Remove and Install Top Conveyor Shaft

16. Remove bearing housing (A) and sprocket (B), both sides from shaft (C).

17. Inspect shaft and sprocket for excessive wear. Replace as necessary.



HX,1401,11015,X-19-25AUG92


H44699
-UN-16JUN92

18. Tap down on one side of bearing (A) until bearing is vertical in housing (C).

19. Rotate bearing to cut-out (B) in housing (C). Remove bearing.

20. Inspect parts. Replace as necessary.


21. Install bearing (A) through cut-out (B).



HX,TM1545,FD -19-09AUG93

H44700
-UN-16JUN92

22. Install sprocket (B) and bearing housing (A) to shaft (C), both sides.



HX,1401,11015,Z-19-25AUG92

H44699
-UN-16JUN92

110
15
4

Conveyor Shaft and Slip Clutch/Remove and Install Top Conveyor Shaft

23. Install right end shaft (F) into upper shaft support.


24. Install left end shaft (A) through slot (C) in upper shaft support.

IMPORTANT: Be sure sprocket bores are aligned with screw indents, both sides.

25. Install and tighten screws (E), both sides of sprocket (D).

26. Install and tighten cap screws (B), both sides.

27. Install side strippers (G) to 7 mm (1/4 in.) from shaft.




- | | |
|-------------------------|---------------------|
| A—Bearing Housing | D—Sprocket |
| B—Cap Screw
(6 used) | E—Screw (4 used) |
| C—Slot | F—Shaft |
| | G—Stripper (2 used) |

HX, TM1545, FE -19-09AUG93

-UN-16JUN92
H44688


28. Join chains and connect links. Install hooks (A).



HX, 1401, 11015AB-19-25AUG92

-UN-20MAR89
H40433

29. Tighten nut (A) to tighten conveyor chain on both sides.




HX, TM1545, BI -19-09AUG93

-UN-16JUN92
H44664

Conveyor Shaft and Slip Clutch/Remove and Install Lower Paddle Shaft

30. Install feeder house. (See procedure in Group 05.)
31. Install spacer (I), sprocket (B), spacer (D), washer and nuts (C).
32. Install and connect chain (E).
33. Remove slack from chain and tighten nut (F).
34. Install pulley (H) and cap screws and nuts (G).
35. Install shield (A).




- | | |
|----------------|----------------|
| A—Shield | F—Nut |
| B—Sprocket | G—Nut (5 used) |
| C—Nut (2 used) | H—Pulley |
| D—Spacer | I—Spacer |
| E—Chain | |

HX,TM1545,FF -19-09AUG93


REMOVE AND INSTALL LOWER PADDLE SHAFT

1. Loosen nuts (A) to relieve spring tension.



HX,1545,1115,BD-19-18NOV92

2. Remove cap screw (A) and (B) to disconnect cables (C).




HX,1401,11015AF-19-25AUG92

110
15
6

Conveyor Shaft and Slip Clutch/Remove and Install Lower Paddle Shaft

3. Remove two cap screws (B) to remove roller (A), both sides.



HX,1401,11015AG-19-25AUG92


H44689 -UN-16/JUN92

CAUTION: Approximate weight of feeder house frame is 79 kg (175 lbs).

4. Attach lifting device (A) to frame.

5. Remove parts (B—D) and remove frame (E).

- A—Lifting Chain
- B—Lock Nut
- C—Nut
- D—Washer
- E—Frame




HX,1401,11015AH-19-25AUG92

H44692 -UN-16/JUN92

6. Disconnect and remove chain.

7. Remove nut (B), washer (C) and sprocket (A).




HX,1401,11015AI-19-25AUG92

H44701 -UN-16/JUN92

8. Remove parts (A—D), both sides.

- A—Shaft Key
- B—Nut (6 used)
- C—Flange Housing (4 used)
- D—Bearing (2 used)




HX,1401,11015AJ-19-25AUG92

H44702 -UN-16/JUN92

Conveyor Shaft and Slip Clutch/Remove and Install Lower Paddle Shaft

9. Loosen 36 nuts (B).

10. Remove shaft (A) from paddles.




HX,1401,11015AK-19-25AUG92

11. Remove three bolts (C) through access hole in deflector (B), both sides.

12. Remove paddle assembly (A).


13. Inspect parts. Repair or replace as necessary.



HX,1401,11015AL-19-25AUG92

14. Install paddle assembly (A).


15. Install bolt (C) through access hole in deflector (B).



HX,1401,11015AM-19-25AUG92

16. Install shaft (A).

17. Tighten nuts (B) to 40 N·m (30 lb-ft).




HX,1401,11015AN-19-25AUG92

110
15
8

Conveyor Shaft and Slip Clutch/Remove and Install Lower Paddle Shaft

18. Install parts (A—D), both sides.

- A—Shaft Key
- B—Nut (6 used)
- C—Flange Housing (4 used)
- D—Bearing (2 used)




HX,1401,11015AO-19-25AUG92

H44702 -UN-16JUN92

19. Install sprocket (A), washer (C) and nut (B).

20. Install and connect chain.



HX,1401,11015AP-19-25AUG92


H44701 -UN-16JUN92

21. Install frame (E).

22. Install parts (B—D).

23. Disconnect lifting device (A).


- A—Lifting Chain
- B—Lock Nut
- C—Nut
- D—Washer
- E—Frame



HX,1401,11015AQ-19-25AUG92

H44692 -UN-16JUN92

24. Install roller (A) and cap screws (B), both sides.




HX,1401,11015AR-19-25AUG92

H44689 -UN-16JUN92

Conveyor Shaft and Slip Clutch/Remove and Install Lower Paddle Shaft


25. Install cap screw (A) and (B) to connect cables (C).



HX,1401,11015AS-19-25AUG92

H44688
-UN-16JUN92

26. Tighten nuts (A) to adjust tension on spring assembly.



HX,1401,11015AT-19-25AUG92

H44687
-UN-16JUN92

27. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).


28. Washer (D) on rear spring should align with upper mark (E) on rear spring carrier (F).

29. To raise left-hand side of header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring and equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.

30. To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.

31. Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.



- A—Washer
- B—Gauge Mark
- C—Front Spring Carrier
- D—Washer
- E—Gauge Mark
- F—Rear Spring Carrier
- G—Nut
- H—Nut


TM1545,HX110,AJ-19-09AUG93

H44239
-UN-14APR92

110
15
10

REMOVE AND INSTALL DRIVE CHAIN IDLERS

1. Loosen nut (A) to relieve chain tension.



HX,1545,1115,BE-19-18NOV92

2. Disconnect chains (C) and (D) and remove.

3. Remove three nuts (A) to remove chain sprocket assembly (E).


4. Remove five cap screws (B) to remove drive sprocket assembly (F).

5. Inspect parts. Replace as necessary.

6. Install drive sprocket assembly (F) and five cap screws (B).

7. Install chain sprocket assembly (E) and three nuts (A).


8. Install and connect chains (C) and (D).



A—Nut (3 used)
B—Cap Screw (5 used)
C—Drive Chain
D—Chain-to-Paddle
 Shaft
E—Drive Sprocket
F—Chain Sprocket

HX,1401,11015AV-19-25AUG92

9. Tighten nut (A) to adjust chain tension.



HX,1401,11015AW-19-25AUG92

Conveyor Shaft and Slip Clutch/Remove and Install Lower Paddle Shaft

10. Washer (A) on front spring should align with lower mark (B) on front spring carrier (C).


11. Washer (D) on rear spring should align with upper mark (E) on rear spring carrier (F).

12. To raise left-hand side of header, tighten adjusting nut (G) on rear spring and loosen adjusting nut (H) on front spring an equal amount.

NOTE: Large cutting platforms are heavy on left-hand side which may require the rear spring to be adjusted approximately 3 mm (1/8 in.) above upper mark.

13. To lower left-hand side of header, loosen adjusting nut on rear spring and tighten adjusting nut on front spring an equal amount.


14. Check to be certain header is level by tilting combine to left and right. Readjust springs if necessary.



- A—Washer
- B—Gauge Mark
- C—Front Spring Carrier
- D—Washer
- E—Gauge Mark
- F—Rear Spring Carrier
- G—Nut
- H—Nut

TM1545,HX110,AK-19-09AUG93

DISASSEMBLE AND ASSEMBLE IDLERS




- | | | | |
|-------------------------------|--|--|------------------------------|
| A—Bolt, M10 x 30
(2 used) | F—Bearing | K—Sprocket | P—Flange Nut, M16 |
| B—Bracket | G—Snap Ring | L—Screw, M16 x 60 | Q—Support |
| C—Shaft | H—Washer, 3/16 x 2 x
0.149 in. (2 used) | M—Washer, 21/32 x
15/16 x 0.036 in.
(4 used) | R—Retainer |
| D—Screw, M12 x 30
(5 used) | I—Washer, 21.4 x 42 x
5 mm | N—Sprocket | S—Bolt, M10 x 20
(3 used) |
| E—Chain, 54 Links | J—Lock Nut, M24 | O—Washer (2 used) | T—Bolt, M8 x 20
(3 used) |

1. Disassemble parts (F—K; L—O). Inspect parts. Replace as necessary.

2. Assemble parts (F—K; L—O).

HX.1545.1115.BF-19-18NOV92

DISASSEMBLE AND ASSEMBLE LOWER SHAFT AND SLIP CLUTCH



A—Flange Nut, M12
(4 used)
B—Cover
C—Washer (8 used)
D—Spring
E—Jaw

F—Snap Ring
G—Hub
H—Washer
I—Bushing
J—Drive Sprocket
K—Wheel

L—Set Screw
M—Eccentric Locking
Collar
N—Bolt, M12 x 40
O—Housing

P—Bearing
Q—Bolt, M10 x 35
(3 used)
R—Flange Nut, M10
(3 used)


HX,1545,1115,BG-19-18NOV92

110
15
14

-UN-17JUL92
H44793

Conveyor Shaft and Slip Clutch/Disassemble and Assemble Lower Shaft and Slip Clutch

1. Remove side shield.
2. Loosen nut (A) to relieve chain tension.




HX,1401,11015AZ-19-25AUG92

H44705
-UN-16JUN92

3. Remove chain (A).

⚠ CAUTION: Spring under cover (C) is under tension. Remove cover slowly.

4. Remove four nuts and bolts (B), making certain all are removed equally to prevent binding.
5. Remove cover (C).




HX,1401,11015BA-19-25AUG92

H44707
-UN-16JUN92

6. Remove parts (A—F).

A—Spring
B—Jaw
C—Snap Ring
D—Hub
E—Washer
F—Drive Sprocket




HX,1401,11015BB-19-25AUG92

H44708
-UN-16JUN92

7. Remove parts (A—C).

A—Bushing
B—Wheel
C—Set Screw (2 used)




HX,1401,11015BC-19-25AUG92

H44709
-UN-16JUN92

Conveyor Shaft and Slip Clutch/Disassemble and Assemble Lower Shaft and Slip Clutch

8. Remove sensor (A) from bearing housing (E).
9. Remove eccentric locking collar (C).
10. Remove three carriage bolts, nuts (B) and bearing housing (E).
11. Inspect bearing (D). Replace if necessary.
12. Remove shaft (F).
13. Inspect all parts. Replace as necessary.




- A—Sensor
- B—Nut (3 used)
- C—Eccentric Locking Collar
- D—Bearing
- E—Housing
- F—Shaft

HX,1401,11015BD-19-25AUG92

H44710 -UN-16JUN92

14. Install shaft (F).
15. Install bearing housing (E).
16. Install three carriage bolts and nuts (B).
17. Install eccentric locking collar.
18. Install sensor (A).




- A—Sensor
- B—Nut (3 used)
- C—Eccentric Locking Collar
- D—Bearing
- E—Housing
- F—Shaft

HX,1401,11015BE-19-25AUG92

H44710 -UN-16JUN92

19. Install parts (A—C).

- A—Bushing
- B—Wheel
- C—Set Screw (2 used)



HX,1401,11015BF-19-25AUG92


H44709 -UN-16JUN92

110
15
16

Conveyor Shaft and Slip Clutch/Disassemble and Assemble Lower Shaft and Slip Clutch

20. Install parts (A—F).

- A—Spring
- B—Jaw
- C—Snap Ring
- D—Threshing Cylinder
- E—Washer
- F—Drive Sprocket



HX,1401,11015BG-19-25AUG92


H44708
-UN-16JUN92

21. Apply thread lock and sealer (medium strength) to threads of bolts used to hold cover.

22. Install cover (C).

23. Install bolts and nuts (B).

24. Install chain (A).




HX,1401,11015BH-19-25AUG92

H44707
-UN-16JUN92

25. Adjust chain tension and tighten nut (A).

26. Install side shield.



HX,1401,11015BI-19-25AUG92

H44705
-UN-16JUN92

110
15
17

Conveyor Shaft and Slip Clutch/Disassemble and Assemble Lower Shaft and Slip Clutch

110
15
18

Section 350

SIDEHILL 9500 LEVELING SYSTEM—DIAGNOSTICS

Contents

Page

Group 05—SideHill Leveling System	
How the System Works	350-05-1
Group 10A—SideHill 9500 Leveling System—Electrical Diagnostics	350-10A-1
Group 20A—SideHill 9500 Leveling System—Hydraulic Diagnostics	350-20A-1
Group 20B—SideHill 9500 Leveling System—Theory of Operation	350-20B-1

Contents

HOW THE SYSTEM WORKS


The SideHill Combine has been designed for use on slopes up to 18 percent. The electro-hydraulic leveling system automatically keeps the separator level as the combine moves across changing hill slopes.

A level sensing control box (A), located on the left-hand rear side contains a pendulum which senses if the combine separator is in a level position. As the combine moves onto a slope and starts to lean, the pendulum swings against either the right or left sensing switch, depending upon the direction of the slope. The sensing switch then activates the electrical leveling circuit which sends electrical current to the right or left tilt solenoid on the leveling control valve.

After the sensing switch has activated the solenoid on the leveling control valve, the spool in the control valve moves, directing hydraulic oil under pressure to the appropriate level cylinder, causing it to retract. Hydraulic oil under pressure is forced out the top of the retracting cylinder and into the top of the opposite cylinder, causing it to extend.

The hydraulic oil from the rod end of the extending cylinder then flows back through the control valve, and on to the main hydraulic reservoir. One cylinder continues to extend while the other cylinder continues to retract until the combine is level. The pendulum then returns to a vertical position, releasing the sensing switch.

Oil for the leveling hydraulic system is supplied from a flow divider in the main hydraulic system. This flow divider directs approximately 50 percent of the system's oil supply to the leveling system. The remaining 50 percent of the oil supply is used to operate the other various hydraulic functions in the combine.



TM1545.11020.A -19-09AUG93

SideHill Leveling System/How the System Works

350
05
2

SideHill 9500 Leveling System—Electrical Diagnostics

Group 10A

BRIEF DESCRIPTION

The leveling electrical system consists of level sensing control box, tilt limit switches, manual tilt switch, leveling control cut-out switch, circuit breaker, ignition switch, which is the source of electrical current, and the two solenoids on leveling control valve.

TM1545,35010,A -19-09AUG93

350
10A
1

BASIC OPERATION

As the combine comes into a slope, a pendulum in the level sensing control box swings to one side, causing a tilt switch in the box to close. Current is sent to the appropriate solenoid on the leveling control valve. The activated solenoid pushes the spool in, causing pressure oil to be always directed to the rod end of the retracting cylinder. Pressure oil is obtained from the proportional flow divider. Return oil is directed to a tee on the proportional flow divider and then returned to the reservoir.

TM1545,35010,B -19-05FEB93




ELECTRICAL SYSTEM

The electrical system consists of two sensing switches, a pendulum in the level sensing control box, right and left tilt solenoids located on leveling control valve, right and left tilt limit switches located on the left-hand final drive pivot, a manual leveling control switch and a leveling control cut-out switch. The electrical system actuates the hydraulic system.

The electrical system is protected from overload by a circuit breaker located in the central electronics box.

TM1545A,35010,A-19-29MAR93

SideHill 9500 Leveling System—Electrical Diagnostics



H45704

TM1545A,35010,B-19-29MAR93

TM1545 (04JAN01)


350-10A-3

040101
PN=144

350
10A
3

H45704 -19-20APR93

C201—POWER DISTRIBUTION BOARD CONNECTOR (J1) (A)



H39960
-UN-10OCT88

TM1545.35010.D -19-05FEB93


C221—HYDRAULIC VALVE STACK LOGIC MODULE CONNECTOR (A)



H39976
-UN-10OCT88

TM1545.35010.H -19-05FEB93


C222—HYDRAULIC VALVE STACK CONNECTOR (A)



H39977
-UN-10OCT88

TM1545.35010.I -19-05FEB93

C241—SIDEHILL LEVELING HARNESS TO LEFT-HAND MAIN HARNESS CONNECTOR (A)




H45706
-UN-01FEB93

TM1545.35010.O -19-05FEB93

350
10A
4


C242—LEFT TILT LIMIT SWITCH CONNECTOR (A)



H45698
-UN-01FEB93

TM1545,35010,K -19-09AUG93

C243—RIGHT TILT LIMIT SWITCH CONNECTOR (A)



H45697
-UN-01FEB93

TM1545,35010,L -19-05FEB93

350
10A
5


C244—LEFT TILT SOLENOID CONNECTOR (A)



TM1545,35010,M -19-05FEB93

H45696
-UN-01FEB93


C245—RIGHT TILT SOLENOID CONNECTOR (A)



TM1545,35010,N -19-05FEB93

H45705
-UN-01FEB93

C246—LEVELING CONTROL BOX CONNECTOR (A)




TM1545,35010,G -19-05FEB93

H45291
-UN-29SEP92

350
10A
6

C403—L.H.MAIN/ARMREST CONNECTOR (A)



H39987
-UN-10OCT88

TM1545,35010,F -19-05FEB93

C517—ARMREST P.C.BOARD CONNECTOR (J2) (A)



H40004
-UN-07AUG89

TM1545,35010,E -19-05FEB93


C601—STEERING COLUMN/L.H.MAIN HARNESS CONNECTOR (A)



H40011
-UN-10OCT88

TM1545,35010,J -19-05FEB93

350
10A
7



350
10A
8

The Service-Gard Automatic Header Height Control and SideHill 6620 Leveling Tester (D1402DJ) and (JT07186) SideHill 9500 Harness Adapter Kit is available for testing SideHill 9500 leveling system electrical problems. If tester and kit are not available, a voltmeter will be needed to diagnose problem from troubleshooting flowcharts.




H46041 -UN-06MAY93

TM1545,HX350,A -19-09AUG93

CHECKING SIDEHILL UPPER WIRING HARNESS

If using D1402DJ SideHill 6620 leveling tester, follow the procedure given.


1. Disconnect four pin connector C241 (A), located below hydraulic valve stack logic module.
2. Install four pin weatherpack adapter harness between connector C241 (A). Connect alligator clamp of adapter harness to a good frame ground.
3. Connect three pin connector of the tester to the adapter harness.



H45706 -UN-01FEB93

TM1545,HX350,B -19-09AUG93

4. Disconnect C246 four pin connector (A) from leveling control box.
5. Connect ground clamp of tester to frame ground on combine. Position tester for observation from cab seat.



H45291 -UN-29SEP92

TM1545,HX350,C -19-09AUG93


SideHill 9500 Leveling System—Electrical Diagnostics

6. Turn selector switch (A) on tester to position 1.
7. Turn ignition key to "ON". DO NOT START ENGINE.



TM1545,HX350,D -19-09AUG93

8. Move automatic level control ON/OFF switch at armrest, to the ON (1) position.



TM1545,HX350,E -19-09AUG93

9. Power test light (B) should glow. If it does not, check for loose connection at test box. If power test light still does not glow, refer to Electrical Diagnostics Flowchart for “Automatic Level Right Does Not Work”.

NOTE: Failure of the test light to glow indicates that the defective component lines between C241 connector and the armrest console.

10. Press RIGHT TILT position of MANUAL level control switch. The RIGHT TILT light (C) should glow. If it does not, GO TO ELECTRICAL DIAGNOSTIC FLOWCHART for “MANUAL LEVEL RIGHT DOES NOT WORK”.

11. Press the LEFT tilt position of the manual level control switch. The LEFT tilt light (D) should glow. If it does not, GO TO ELECTRICAL DIAGNOSTIC FLOWCHART for “MANUAL LEVEL LEFT DOES NOT WORK”.

12. Turn off ignition switch, disconnect tester. Connect C241 and C248.




H46043 -UN-06MAY93

TM1545,HX350,F -19-09AUG93

CHECKING SIDEHILL LOWER WIRING HARNESS

1. Disconnect four pin connector C248 (A), at leveling control box.
2. Install extension harness between the four pin connector (A). Connect opposite end of extension harness to tester.
3. Connect ground clamp of tester to frame ground of combine. Position tester for observation from cab seat.



H45291 -UN-28SEP92

TM1545,HX350,H -19-09AUG93

4. Turn selector switch (A) on the tester to Position 2.
5. Combine must be in level position. Turn on ignition key to "ON". DO NOT START ENGINE.
6. Press RIGHT tilt of the MANUAL level control switch. Right tilt test light (B) should glow. If it does not, check for loose connection at test box and adjustment of RIGHT limit switch. If the right tilt light still does not glow, refer to ELECTRICAL DIAGNOSTIC FLOWCHART for "MANUAL LEVEL RIGHT DOES NOT WORK".
7. Press LEFT tilt of the MANUAL level control switch. Left tilt test light (C) should glow. If it does not, check for loose connection at test box and adjustment of LEFT limit switch. If the left tilt light still does not glow, refer to ELECTRICAL DIAGNOSTIC FLOWCHART for "MANUAL LEVEL LEFT DOES NOT WORK".


NOTE: Failure of test light to glow at any point indicates defective component lies in harness between C241 and C248.



TM1545,HX350,I -19-09AUG93


CHECKING SIDEHILL LEVEL SENSING CONTROL BOX

1. Disconnect the four pin connector C248 (A), at leveling control box.
2. Connect mating four pin connectors of tester between C248 (A). Connect clamp of tester to frame ground.
3. Locate test box on ground so it is visible while moving level sensing control box.



TM1545,HX350,L -19-09AUG93

4. Turn on ignition key. DO NOT START ENGINE. Turn on automatic level switch (I) on armrest console.




TM1545,HX350,M -19-09AUG93

350
10A
12

5. Turn tester selector switch (A) to position 2.
6. Loosen control box mounting bolts and move bottom of box toward combine left side (counterclockwise). The **RIGHT** tilt light (B) should glow. If it does not proceed to step 8.
7. Rotate bottom of control box toward combine right side (clockwise). The **LEFT** tilt light (C) should glow. If it does not, proceed to step 8.
8. GO TO SIDEHILL LEVELING BOX DIAGNOSTICS.



TM1545,HX350,N -19-09AUG93




350
10A
14

H45700

H45700 -19-27APR93

TM1545,35010,Q -19-05FEB93




H45701

TM1545,35010,R -19-05FEB93

350
10A
15

H45701 -19-20APR93




350
10A
16

H45702

H45702 -19-20APR93

TM1545,35010,S -19-05FEB93




CONTINUED ON NEXT PAGE

H45703

350
10A
17

H45703 -19-20APR83

TM1545,35010,T -19-05FEB93




350
10A
18

H45783


TM1545, HX3510, A-19-09AUG93

H45783 -19-20APR93



H45784


TM1545, HX3510, B-19-09AUG93



350
10A
20

H45785


TM1545, HX3510, C-19-09AUG93



H45787

TM1545, HX3510, D-19-09AUG93

350
10A
22



H45788

TM1545, HX3510, E-19-09AUG93

SIDEHILL LEVELING BOX DIAGNOSTICS


NOTE: Be sure shipping screw (C) is not restricting movement of pendulum.

1. Remove front cover on control box and disconnect control box harness.

2. Check for continuity between left leg of resistor (A) and C246 connector pin (B) CC #10 WHITE wire.

NOTE: Scratch contact point with probe to remove insulating coating to get a good contact.

3. If NO continuity, repair CC #10.



H45721 -UN-08FEB93

TM1545,35010.U -19-05FEB93

4. Check continuity between (A) and C246 connector pin (B) CC #428 RED wire.

5. If NO continuity, repair CC #428.



H45722 -UN-08FEB93

TM1545,35010.V -19-05FEB93

6. Check continuity between (A) top transistor and C246 connector pin (B) CC #448 BLACK wire.

7. If no continuity, repair CC #448.

NOTE: Scratch contact point on top of transistor with probe to remove insulating coating to get a good contact.




TM1545,35010,W -19-05FEB93

H45723 -UN-08FEB93

8. Check continuity between (A) bottom transistor and C246 connector pin (B) CC #449 GREEN wire.


9. If NO continuity, repair CC #449.



TM1545A,35010,C-19-29MAR93

H45727 -UN-08FEB93


350
10A
24



10. Check continuity between (A) left switch WHITE wire and C246 connector pin (B) CC #10 WHITE wire.

11. Check continuity between (C) right switch WHITE wire and C246 connector pin (B) CC #10 WHITE wire.


12. If NO continuity, check wire solder joints from switches and printed circuit board.



13. ATTACH continuity tester probes to left leg of top large diameter resistor (A) and C246 connector pin (B) CC #10 WHITE wire. Swing pendulum (C) to left to close left switch (D).

14. If NO continuity, replace switch (D).

TM1545,35010,Z -19-05FEB93



15. ATTACH continuity tester probes to left leg of bottom large diameter resistor (A) and C246 connector pin (B) CC #10 WHITE wire. Swing pendulum (C) to right to close right switch (D).

16. If NO continuity, replace switch (D).

TM1545,35010,AA-19-05FEB93

- 17. Connect leveling control box harness.
- 18. Turn ignition key to IGN position.
- 19. Turn on automatic leveling armrest switch.

TM1545,35010,AB-19-05FEB93

350
10A
27

20. Check voltage at (A). Voltmeter should read 10—11 volts.

NOTE: Scratch contact point with probe to remove insulating coating to get a good contact.

21. Check voltage at (B) and (C) with pendulum centered. Voltmeter should indicate battery voltage 10—12 volts.

If NOT, control box is defective.

22. Check voltage at (B) with pendulum swung to left. Voltmeter should indicate a drop in voltage.

If NOT replace control box.


23. Check voltage at (C) with pendulum swung to right. Voltmeter should indicate a drop in voltage.

If NOT, replace control box.

24. Check voltage to top of transistor (D). With pendulum swung right, voltmeter should indicate 9—10 volts. Center pendulum. Voltmeter should indicate zero volts. If either voltage is incorrect, replace transistor. John Deere service part transistor is supplied with installation instructions.


NOTE: Scratch top of transistor with probe to remove insulating coating to get a good contact.

25. Check voltage to top of transistor (E). With pendulum swung left, voltmeter should indicate 9—10 volts. Center pendulum. Voltmeter should indicate zero volts. If either voltage is incorrect, replace transistor.



H45728 -UN-08FEB93

26. Pendulum dashpot (A) should not allow the pendulum to swing freely. Pendulum should sluggishly swing when control box is tilted. If not, adjust or replace.



TM1545,35010,AE-19-09AUG93

H45729 -UN-08FEB93

350
10A
29

350
10A
30

SideHill 9500 Leveling System—Hydraulic Diagnostics

Group 20A

BRIEF DESCRIPTION

The hydraulic leveling system consists of proportional flow divider, leveling control valve, and leveling cylinders.

HX,1546,350,A -19-18DEC92

BASIC OPERATION


As the combine comes into a slope, a pendulum in the level sensing control box swings to one side, causing a tilt switch in the box to close. Current is sent to the appropriate solenoid on the leveling control valve. The activated solenoid pushes the spool in, causing pressure oil to be always directed to the rod end of the retracting cylinder. Pressure oil is obtained from the proportional flow divider. Return oil is directed to a tee on the proportional flow divider and then returned to the reservoir.

HX,TM1545,FG -19-09AUG93

350
20A
1

HYDRAULIC RESERVOIR


- A—Hydraulic Reservoir
- B—Reservoir Cap
- C—Oil Temp Sensor
- D—Oil Line From Hydraulic Filter
- E—Oil Line to Hydraulic Pump
- F—Oil Line to Charge Pump
- G—Oil Line From Four Wheel Drive (Optional)
- H—Oil Line to Oil Cooler
- I—Oil Filter/Screen



TM1545,35020,A -19-29MAR93

H45132 -UN-14SEP92

HYDRAULIC PUMP (A)




HX,1546,350,E -19-18DEC92

H45103 -UN-14SEP92

350
20A
2


HYDRAULIC VALVE STACK DIAGNOSTIC RECEPTACLE (A)



HX,1546,350,F -19-18DEC92

H45089 -UN-10SEP92

PROPORTIONAL FLOW DIVIDER (A)



H45294
-UN-29SEP92

TM1545,35020,B -19-29MAR93

SIDEHILL CIRCUIT RELIEF VALVE (A)



H45733
-UN-22FEB93

TM1545,35020,C -19-29MAR93

350
20A
3

LEVELING VALVE (A)




H45290
-UN-28SEP92

HX,1546,350,I -19-18DEC92

LEFT-HAND LEVELING CYLINDER (A)

B—Diagnostic Receptacle



H45296
-UN-28SEP92

HX,1546,350,J -19-18DEC92

350
20A
4


RIGHT-HAND LEVELING CYLINDER (A)



H45295
-UN-29SEP92

HX,1546,350,K -19-18DEC92

THERMAL RELIEF VALVES (A)



H45734
-UN-22FEB93

TM1545,35020,D -19-29MAR93

350
20A
5

LEVELING CYLINDERS

There are two double-acting cylinders located at the front of the separator.

As oil is delivered to the rod end of one cylinder, the cylinder retracts. Displaced oil from the head end of this cylinder is forced out and into the head end of opposite cylinder, causing that cylinder to extend. Oil in the lower end of the extending cylinder is forced out and flows through the leveling control valve and to the main hydraulic reservoir.

Cylinders are equipped with pressure operated safety check valves to prevent loss of oil from extended cylinder in case a hose or line ruptures.

TM1545,35020,E -19-09AUG93

If combine sits for a period of time, the feeder house picture frame may tilt slightly, this is due to settling in one or both leveling cylinders.



CAUTION: Do not readjust leveling cables until combine leveling cylinders have been rephased.

IMPORTANT: When park brake is applied and locked, leveling system could be impaired. Park brake must be released before manually tilting machine.

To rephase leveling cylinders:


Start engine and tilt combine to each side.

Hold leveling switch in this position for 15 seconds.

Allow combine to return to level position.

Repeat procedure three times to insure complete rephasing of cylinders.

TM1545,35020,F -19-29MAR93




H45457

H45457 -19-06NOV97

350
20A


SIDEHILL 9500 LEVELING DIAGNOSTICS HYDRAULIC




H46037

TM1545, HX3520, A-19-10AUG93

350
20A-8







350
20A
10

H46039

TM1545, HX3520, C-19-10AUG93



H46040



TM1545, HX3520, D-19-10AUG93

350
20A
12

SideHill 9500 Leveling System—Theory of Operation **Group 20B**

350
20B
1

SideHill 9500 Leveling System—Theory of Operation



H45454

A—From Main Hydraulic Pump
 B—Proportional Flow Divider
 C—Leveling Relief Valve
 D—Return to Reservoir

E—To Solenoid Control Valve
 F—Leveling Valve
 G—Left Tilt Solenoid
 H—Right Tilt Solenoid
 I—To Rod of Left Leveling Cylinder

J—To Rod of Right Leveling Cylinder
 K—Left Leveling Cylinder
 L—Drain Line
 M—Valve Block

N—Balance Beam Line
 O—Right Leveling Cylinder
 P—Pressure Free Oil
 Q—Trapped Oil
 R—Pressure Oil

350
20B
2

LEVELING SYSTEM IN NEUTRAL

When the leveling system is not activated, the solenoids on the leveling valve (F) are not activated.


Valve blocks (K and O) trap oil in the head ends of both leveling cylinders. The leveling valve (F) traps oil in the rod end of the cylinders.

Pressure free oil from the proportional flow divider (B) flows to the leveling valve (F) and then flows back to the reservoir.

HX,1546,350,S -19-18DEC92

350
20B
3

SideHill 9500 Leveling System—Theory of Operation



H45455

A—From Main Hydraulic Pump
 B—Proportional Flow Divider
 C—Leveling Relief Valve
 D—Return to Reservoir

E—To Solenoid Control Valve
 F—Leveling Valve
 G—Left Tilt Solenoid
 H—Right Tilt Solenoid
 I—To Rod of Left Leveling Cylinder

J—To Rod of Right Leveling Cylinder
 K—Left Leveling Cylinder
 L—Drain Line
 M—Valve Block

N—Balance Beam Line
 O—Right Leveling Cylinder
 P—Return Oil
 Q—Pressure Oil

LEVELING TO THE RIGHT (LEFT CYLINDER EXTEND, RIGHT CYLINDER RETRACT)

When the combine moves onto a slope that causes the combine to lean to the left, the electrical system activates the forward solenoid or right tilt solenoid (H). The activated solenoid pushes in the spool, causing a demand for pressure oil from the main hydraulic pump. This pressure oil flows from the main hydraulic pump (A) to the proportional flow divider (B).

The proportional flow divider directs 50 percent of the oil to the leveling valve (F). The remaining 50 percent is sent to the solenoid control valve. The proportional flow divider will always maintain the 50-50 percent flow regardless of pressure and flow requirements in either the leveling system or the main hydraulic system.

Leveling valve (F) directs pressure oil to the valve block on top of the right hand leveling cylinder (M) through hydraulic line (J).

The valve block directs the pressure oil to the rod side of the right leveling cylinder causing it to retract. The oil is forced out of the head side of the right cylinder and sent through balance beam line (N) to the head side of the left hand cylinder (K) causing it to extend.

Oil from the rod side of the left cylinder is returned to the leveling valve (I) and on to the reservoir through line (D).


When the leveling system brings the combine separator to a level position, the electrical system shuts off the current to the right tilt solenoid (H). The spool in the leveling valve centers, causing the leveling system to then trap oil in the cylinders and maintain a leveled position.

If the combine is leveled to its maximum tilt capability, limit switches in the electrical system shuts off current to the right tilt solenoid, preventing unnecessary pressure oil and oil heating.

Drain line (L) provides a drain for both valve blocks (K and O) on the top of each leveling cylinder. A small amount of internal leakage can occur that would affect the operation of the valve blocks if there was no drain line. The drain line is also used if the bleed screw is opened to allow the cylinders to retract.

Pressure oil can occur in the line to the solenoid control valve (E) when a hydraulic function is used at the same time when leveling or when the manual tilt switch is used (the manual tilt switch activates coil one on the solenoid control valve, this is not required for operation.)

SideHill 9500 Leveling System—Theory of Operation



H45456

A—From Main Hydraulic Pump
 B—Proportional Flow Divider
 C—Leveling Relief Valve
 D—Return to Reservoir

E—To Solenoid Control Valve
 F—Leveling Valve
 G—Left Tilt Solenoid
 H—Right Tilt Solenoid
 I—To Rod of Left Leveling Cylinder

J—To Rod of Right Leveling Cylinder
 K—Left Leveling Cylinder
 L—Drain Line
 M—Valve Block

N—Balance Beam Line
 O—Right Leveling Cylinder
 P—Return Oil
 Q—Pressure Oil

350
20B
6

LEVELING TO THE LEFT (RIGHT CYLINDER EXTEND, LEFT CYLINDER RETRACT)

When the combine moves onto a slope that causes the combine to lean to the right, the electrical system activates the rear solenoid or left tilt solenoid (G). The activated solenoid pushes in the spool, causing a demand for pressure oil from the main hydraulic pump. This pressure oil flows from the main hydraulic pump (A) to the proportional flow divider (B).

The proportional flow divider directs 50 percent of the oil to the leveling valve (F). The remaining 50 percent is sent to the solenoid control valve (E). The proportional flow divider will always maintain the 50-50 percent flow regardless of pressure and flow requirements in either the leveling system or the main hydraulic system.

Leveling valve (F) directs pressure oil to the valve block on top of the left hand leveling cylinder (K) through hydraulic line (I).

The valve block directs the pressure oil to the rod side of the left leveling cylinder, causing it to retract. The oil is forced out of the head side of the left cylinder and sent through balance beam line (N) to the head side of the right hand cylinder (O), causing it to extend.

Oil from the rod side of the right hand cylinder is returned to the leveling valve (J) and on to the reservoir through line (D).


When the leveling system brings the combine separator to a level position, the electrical system shuts off the current to the left tilt solenoid (G). The spool in the leveling valve centers, causing the leveling system to then trap oil in the cylinders and maintain a leveled position.

If the combine is leveled to its maximum tilt capability, limit switches in the electrical system shuts off current to the left tilt solenoid, preventing unnecessary pressure oil and oil heating.

Drain line (L) provides a drain for both valve blocks (K and O) on the top of each leveling cylinder. A small amount of internal leakage can occur that would affect the operation of the valve blocks if there was no drain line. The drain line is also used if the bleed screw is opened to allow the cylinders to retract.

Pressure oil can occur in the line to the solenoid control valve (E) when a hydraulic function is used at the same time when leveling or when the manual tilt switch is used (the manual tilt switch activates coil one on the solenoid control valve, this is not required for operation).

**PROPORTIONAL FLOW DIVIDER
LEVELING SYSTEM AND MAIN
SYSTEM NOT ACTIVATED**



H45322

H45322

- | | | | |
|-----------------------|----------------------------|--------------------------------|----------------|
| A—Main System Orifice | D—From Main Hydraulic Pump | F—Leveling System Orifice | H—To Reservoir |
| B—Spool | E—Leveling System Port | G—Leveling System Relief Valve | I—Return Oil |
| C—Main System Port | | | |

The proportional flow divider directs 50 percent of the pump output to the leveling valve and 50 percent to the solenoid control valve. The 50/50 ratio is maintained regardless of pressure requirements in the leveling system or the main hydraulic system.

For an equal 50/50 flow division, half of the flow must pass thru orifice (A). The other half of flow must pass thru orifice (F) with equal flow thru (A) and (F). There are equal pressure drops across orifices (A and F) and spool (B) remains centered.


350
20B
8

Oil flows from the main hydraulic pump to port (D).
Oil flows through four holes into spool (B).

The flow divider directs 50 percent of the oil to the leveling system through port (E) and 50 percent to the main system (C).

TM1545.35020.L -19-10AUG93

**LEVELING SYSTEM NOT ACTIVATED
HYDRAULIC SYSTEM IS ACTIVATED**



A—Main System Orifice
B—Spool
C—Main System Port
D—From Main Hydraulic Pump

E—Leveling System Port
F—Leveling System Orifice
G—Leveling System Relief Valve

H—To Reservoir
I—Pressure Oil

J—Low Pressure Oil
K—Return Oil


When one or more hydraulic systems are activated and the leveling system is not activated, the pressure drop across orifice (F) moves the spool (B) down. The pressure drop occurs since the other side of

orifice (F) is seeing reservoir pressure. The other side of orifice (A) sees the load of the leveling cylinders and builds high pressure.

TM1545.35020_M -19-10AUG93

350
20B
9

**LEVELING SYSTEM ACTIVATED
HYDRAULIC SYSTEM NOT ACTIVATED**



A—Main System Orifice
B—Spool
C—Main System Port
D—From Main Hydraulic Pump

E—Leveling System Port
F—Leveling System Orifice
G—Leveling System Relief Valve

H—To Reservoir
I—Pressure Oil


J—Low Pressure Oil
K—Return Oil

When the leveling system is activated and the main hydraulic system is not activated, the pressure drop across orifice (A) moves the spool (B) up. The pressure drop occurs since the other side of orifice (A) is seeing reservoir pressure. The other side of orifice (F) sees the load of the hydraulic system and builds high pressure.

If the high pressure reaches 3000 psi the relief valve (G) will open and the oil will flow to the reservoir through port (H).

350
20B
10

**LEVELING SYSTEM ACTIVATED
HYDRAULIC SYSTEM ACTIVATED**



H45325

H45325
-JUN-10NOV97

A—Main System Orifice
B—Spool
C—Main System Port

D—From Main Hydraulic Pump
E—Leveling System Port

F—Leveling System Orifice
G—Leveling System Relief Valve

H—To Reservoir
I—Pressure Oil
J—Return Free Oil

When the leveling system and the main hydraulic system are both activated, 50 percent of the high pressure oil flows to each system.


Because high pressure oil is required for both the leveling system and the main hydraulic system, the pressure drop across the orifices (A and F) is equal and spool (B) remains centered.

If the pressure requirement increases on either side of the flow divider, the spool will shift accordingly. This shift in the spool will maintain the 50/50 percent divided flow and will also maintain the speed at which the function should operate.

TM1545,35020,O -19-10AUG93

350
20B
11

**LEVELING CONTROL VALVE
LEVELING SYSTEM NOT ACTIVATED**



H45333

A—Left Tilt Solenoid
B—Spool
C—Pilot Check Valve
D—Thermal Relief Valve

E—To R.H. Leveling Cylinder
F—Thermal Relief Valve
G—Pilot Check Valve
H—To L.H. Leveling Cylinder

I—Pressure Port
J—Right Tilt Solenoid
K—Slotted Washer
L—Return Port


M—Spool
N—Slotted Washer
O—Return Oil
P—Trapped Oil

With the combine level, electric current is shut off and solenoids (A and J) are not activated. Spool (M) is kept centered by spring pressure, allowing oil to flow into port (I) around spool (M), through slotted washers (N and K). Oil then flows out port (L) and returns to reservoir.

The thermal relief valves (D and F) are primarily for manufacturing purposes. When the combine moves through the painting process at the factory, temperatures reach 93°C (200°F). The thermal relief valves will leak, this prevents the leveling cylinders and hydraulic hoses from bursting.

TM1545,35020,P -19-10AUG93

LEVELING TO THE RIGHT



H45335

A—Left Tilt Solenoid
 B—Spool
 C—Pilot Check Valve
 D—Thermal Relief Valve

E—To R.H. Leveling Cylinder
 F—Thermal Relief Valve
 G—Pilot Check Valve
 H—To L.H. Leveling Cylinder

I—Pressure Port
 J—Right Tilt Solenoid
 K—Slotted Washer
 L—Return Port

M—Spool
 N—Slotted Washer
 O—Return Oil
 P—Pressure Oil

The right tilt solenoid is activated by the electrical leveling system.

The activated right tilt solenoid (J) pushes spool (M) in, permitting pressure oil from port (I) to flow around spool (M) to pilot check valve (C) causing it to open.

This allows pressure oil to flow to the retracting right leveling cylinder (E).

The pressure oil also forces spool (B) to the left, causing pilot check valve (G) to open. This allows oil from the extending left leveling cylinder to flow around spool (M), through slotted washer (N), to port (L). The oil then returns to the reservoir.

TM1545,35020,Q -19-10AUG93


TM1545 (Only A/N) Under.

350-20B-13

H45335 -UN-10NOV97

**350
20B
13**

LEVELING TO THE LEFT



H45334

A—Left Tilt Solenoid
 B—Spool
 C—Pilot Check Valve
 D—Thermal Relief Valve

E—To R.H. Leveling Cylinder
 F—Thermal Relief Valve
 G—Pilot Check Valve
 H—To L.H. Leveling Cylinder

I—Pressure Port
 J—Right Tilt Solenoid
 K—Slotted Washer
 L—Return Port

M—Spool
 N—Slotted Washer
 O—Pressure Oil
 P—Return Oil

The left tilt solenoid is activated by the electrical leveling system.
 The activated left tilt solenoid (A) pushes spool (M) in, permitting pressure oil from port (I) to flow around spool (M) to pilot check valve (G) causing it to open. This allows pressure oil to flow to the retracting left side leveling cylinder.


The pressure oil also forces spool (B) to the right, causing pilot check valve (C) to open. This allows oil from the extending right leveling cylinder to flow around spool (M), through slotted washer (K) to port (L). The oil then returns to the reservoir.

TM1545,35020,R -19-10AUG93

350
 20B
 14

-UN-10NOV97
 H45334

**LEVELING CYLINDERS
LEVELING SYSTEM NOT ACTIVATED**



H45374

A—Transfer Tube
B—Pressure Port From
Leveling Control Valve
C—Valve Block

D—Piston
E—Balance Beam Hose
F—Transfer Tube
G—Pressure Port from
Leveling Control Valve

H—Valve Block
I—Piston
J—R.H. Leveling Cylinder

K—L.H. Leveling Cylinder
L—Trapped Oil

When the leveling system is not activated, pilot check valve in valve blocks (C and H) trap oil in the head end of both leveling cylinders (J and K).

Pilot check valves (inside leveling control valve), trap oil in lines going to ports (B and G). Oil is also trapped in transfer tubes (A and F) and the rod ends of both cylinders (J and K).

TM1545,35020,S -19-11AUG93

LEVELING CYLINDERS LEVELING TO THE RIGHT

A—Transfer Tube
B—Pressure Port from
Leveling Control Valve
C—Valve Block

D—Piston
E—Balance Beam Hose
F—Transfer Tube
G—Pressure Port from
Leveling Control Valve


H—Valve Block
I—Piston
J—R.H. Leveling Cylinder

K—L.H. Leveling Cylinder
L—Pressure Oil
M—Return Oil

When the electrical system activates the leveling control valve, pressure oil flows to port (G) of the right hand leveling cylinder (J), valve block (H) directs oil down the transfer tube (F) to the rod end of cylinder, causing it to retract. Oil is forced out of the head end of right-hand cylinder (J) and flows through

balance beam hose (E) to valve block (C). The valve block directs the oil to the head end of left hand cylinder (K), causing it to extend. Oil is then forced out of the rod end of cylinder (K), flows up the transfer tube to the valve block (C). Oil is then returned through port (B) to the leveling control valve.

SideHill 9500 Leveling System—Theory of Operation



H45375

H45375
-UN-10NOV97

350
20B
17

DXJSSA1071 -19-04JAN01

LEVELING TO THE LEFT

A—Transfer Tube
B—Pressure Port From
Leveling Control Valve
C—Valve Block

D—Piston
E—Balance Beam Hose
F—Transfer Tube
G—Pressure Port From
Leveling Control Valve


H—Valve Block
I—Piston
J—R.H. Leveling Cylinder

K—L.H. Leveling Cylinder
L—Pressure Oil
M—Return Oil

When the electrical system activates the leveling control valve, pressure oil flows to port (B) of the left-hand leveling cylinder (K), valve block (C) directs oil down the transfer tube (A) to the rod end of cylinder, causing it to retract. Oil is forced out of the head end of left-hand cylinder (K) and flows through

balance beam hose (E) to valve block (H). The valve block directs the oil to the head end of right-hand cylinder (J), causing it to extend. Oil is then forced out of the rod end of cylinder (J), flows up the transfer tube to the valve block (H). Oil is then returned through port (G) to the leveling control valve.

SideHill 9500 Leveling System—Theory of Operation



H45376

H45376
-UN-10NOV97

350
20B
19

DXJSSA1072 -19-04JAN01

OPERATION OF VALVE BLOCK— LEVELING CYLINDER NOT ACTIVATED

A—Plunger and Dowel Pin
B—Pressure Port to
Leveling Control Valve

C—To Rod End
D—To Opposite Leveling
Cylinder

E—Pilot Check Valve
F—Bleed Valve
G—Drain Line


H—Return Oil
I—Trapped Oil

With the leveling cylinders not activated, both pilot check valves in the leveling control valve are closed, trapping oil in the hoses going to port (B). This also traps the oil in the rod end of both leveling cylinders.

Pilot check valve (E) in both leveling cylinders, is closed, trapping oil in the head end of the cylinder. This head of oil supports the weight of the combine. Oil is also trapped in the balance beam hose connected between the cylinders at port (D).

Bleed valve (F) can be opened to drain oil from the head end of the leveling cylinders. This will lower the front of the combine for transporting or storage. With the bleed valve (F) closed, the cylinders can be rephased to fill the head ends with the proper volume of oil to raise the combine to its operating height.

SideHill 9500 Leveling System—Theory of Operation



H44598

DXJSSA1073 -19-04JAN01

H44598 -UN-10NOV97

350
20B
21

OPERATION OF VALVE BLOCK— LEVELING CYLINDER RETRACTING

A—Plunger and Dowel Pin
B—Pressure Port to
Leveling Control Valve

C—To Rod End
D—To Opposite Leveling
Cylinder

E—Pilot Check Valve
F—Bleed Valve
G—Drain Line

H—Return Oil
I—Pressure Oil


Pressure oil from the leveling control valve flows into the valve block through port (B). This oil moves plunger and dowel pin (A), causing pilot check valve (E) to open.

Pressure oil also flows to the rod end of the cylinder by flowing through port (C) to the transfer tube along side the cylinder.

Oil, forced out of the head end, flows through the open pilot check valve (E) and to port (D). Then the oil flows to the opposite leveling cylinder through the balance beam hose.

Port (G) is a drain to the reservoir. Any internal leakage is drained off, preventing a hydrostatic lock of plunger and dowel pin (A).

SideHill 9500 Leveling System—Theory of Operation



H44600

DXJSSA1074 -19-04JAN01

H44600 -UN-10NOV97

350
20B
23

OPERATION OF VALVE BLOCK— LEVELING CYLINDER EXTENDING

A—Plunger and Dowel Pin
B—Pressure Port to
Leveling Control Valve

C—To Rod End
D—To Opposite Leveling
Cylinder

E—Pilot Check Valve
F—Bleed Valve
G—Drain Line

H—Return Oil
I—Pressure Oil


Pressure oil, from the head end of the retracting cylinder, flows through the balance beam hose into port (D) of the extending cylinder.

As the cylinder extends, oil is forced out of the rod end and flows up the transfer tube to port (C). This

oil then returns out of port (B) to the leveling control valve.

Port (G) is a drain to the reservoir. Any internal leakage is drained off preventing a hydrostatic lock of the plunger and dowel pin (A).

SideHill 9500 Leveling System—Theory of Operation



H44599

DXJSSA1075 -19-04JAN01

H44599 -UN-10NOV97

350
20B
25

350
20B
26

Index

	Page		Page
B			
Brake drum		Gearshift linkage	
Install	60-05-2	Adjust	50-05-4
Brake drum, remove	60-05-1	H	
C		Header drive shaft	
Check valve, repair	70-05-10	Repair	100-05-1
Combine Identification Number	10-10-1	Hydraulic diagnostics leveling system . . .	350-20A-1
Complete control box, replacing	40-10-5	I	
Control box		Idlers	
Replace	40-10-5	Disassemble and assemble	110-15-13
Control Panel, Armrest	40-05-1	Inch torque values	10-15-9
Conveyor shaft and slip clutch		L	
Remove and install	110-15-2	Level sensing controls	
Conveyor tension,		Remove and install	40-10-2
Adjusting	110-05-13	Leveling cylinder	
D		Disassemble and assemble	70-05-24
Dashpot orifice		Leveling cylinder left	
Adjustment	40-10-4	Remove and install	70-05-16
Dimensions	10-15-7	Leveling cylinder right	
Drive chain idlers,		Remove and install	70-05-12
Remove and install	110-15-11	Leveling header	70-05-27
E		Leveling system	
Electrical diagnostics leveling system	350-05-1	Theory of operation	350-20B-2
Engine Serial Number	10-10-1	Lower paddle shaft,	
F		Remove and install	110-15-6
Feeder conveyor,		Lower shaft and slip clutch,	
Disassemble and assemble	110-05-7	Disassemble and assemble	110-15-14
Feeder house conveyor drum,		M	
Disassemble and assemble	110-10-1	Metric torque values	10-15-8
Final drive		O	
Install	50-10-5	Operating Speeds	10-15-3
Final drive, remove	50-10-1	S	
Floor plate,		Sidehill leveling limit switches	
Remove and install	110-05-12	Remove and install	40-10-6
Flow divider valve	70-05-5	Sidehill leveling limit switches,	
G		Adjust	40-10-7
		Solenoid valve and flow divider, leveling .	70-05-2
		Specifications	10-15-1

	Page
Switches, Transistor and Dashpot	
Remove and install	40-10-2

T

Top conveyor shaft,	
Remove and install	110-15-2
Torque values	
Inch	10-15-9
Metric	10-15-8
Torque Valves	
Flat Face O-Ring Seal Fitting	10-15-11
SAE Four Bolt Flange Fitting	10-15-12
Transmission	
Install	50-05-3
Transmission, remove	50-05-2

V

Valve block solenoid,	
Remove and install	70-05-6
Valve block, cylinder	
Remove and install	70-05-21
Valve oil lines and hoses, leveling	70-05-4

