# John Deere C440R Round Hay and forage Wrapping Baler Service Repair Technical Manual (TM301119)



Covers: C440R

**Type:** Service Manual **Language:** English

Pages: 166
Format: PDF

**Features:** Bookmarked, searchable, printable **Compatibility:** Windows/Mac/Tablet/Mobile


This service manual contains important information for the maintenance, troubleshooting and servicing of the **John Deere C440R Round Hay and forage Wrapping Baler Service Repair Technical Manual (TM301119)** 

In this manual you will find detailed specifications, illustrations, schematics, diagrams and step-by-step procedures to properly service and diagnose the machine to the manufacturer's standards.

#### **Contents:**

- General Information
- Specifications
- · Serial Number Location
- Engine Specifications
- · Engine Diagnostics
- · Engine Tests and Adjustments
- · Engine Repair
- · Power Train
- Transmission
- Axles
- · Differential
- PTO
- Hydraulic System
- Electrical System
- · Electrical Tests and Diagnostics
- Wiring Diagram / Schematic
- · Ignition and Charging
- Steering
- Brakes
- · Wheels
- Operator's Platform
- Body Panels
- · Disassembly and Assembly
- · Diagnostics, Tests and Adjustments
- Troubleshooting
- · and much more...

Please note this manual is in <b>downloadable PDF format only.</b> If you have any questions about this product or would like to request sample pages, please contact us and reference the product name or SKU.	




W25 GROUND AT STARTER MOTOR

Embedded Payload Scale (EPS) Circuit Schematic

TX1103657

Section 9020 - POWER TRAIN Group 05: Theory of Operation

## Torque Converter With Lockup Clutch Operation—If Equipped



### Torque Converter with Lockup Clutch (Cross-Sectional View)

## LEGEND:

LEGEND.	
1	Turbine
2	Impeller
3	Converter Relief Valve
4	PTO Drive
5	Engine Speed Sensor
6	Transmission Pump
7	PTO Drive 1
3 4 5 6 7 8	PTO Shaft
9	Drive Gear
10	Turbine Shaft
11	Stator
12	Free Wheel
13	Piston
14	Spring
15	Clutch Plate (2 used)
16	Separator Plate (2 used)
17	Backplate
600	Torque Converter Lockup Pressure
601	Converter Pressure (in)
604	Converter Return Pressure (out)

The torque converter is a single-stage, dual phase unit with lockup clutch that consists of the following components:

- Turbine (1)
- Impeller (2)
- Stator (11)
- Piston (13)
- Spring (14)
- Clutch Plate (15) Separator plate (16)
- Backplate (17)



Thank you very much for your reading.

Please click here to get more information.