
BW28, BW38 REPAIR MANUAL COMPLETE CONTENTS

SECTION A - DISTRIBUTION SYSTEMS	2
SECTION B - POWER PRODUCTION	23
SECTION C - POWER TRAIN	32
SECTION D - TRAVELLING	33
SECTION E - BODY AND STRUCTURE	45
SECTION K - CROP PROCESSING	56

The sections listed above are the sections utilized for the BW28, BW38 Bale Wagons.

