

Figure Search for SK100 MARK III EXCAVATOR ASN YW02801

004-01 Filter List
 011-01 Frame Assy, Upp
 015-28 Counter-Weight Assy
 026-01 Reduction Unit
 041-01 Tank Assy, Hydr
 045-45 Tank Assy, Fuel
 051-45 Install, Cab
 055-45 Cab Assy
 064-28 Plate Assy, Floor
 071-45 Seat Assy
 081-45 Guard Assy
 1 Cyl. Head and Cover Other Parts
 10 Oil Filter and Fuel Filter (Fixing Parts)
 11 Oil Pipe and Fixing Parts
 115-01 Cover Assy, Under
 12 Cooling System (Fan, Water and Oil)
 121-28 Control Assy
 13 Air Intake and Exhaust System
 15 Fuel System (Inj. Nozzle, Fuel Pipe)
 16 Engine Foot, Hanger and Fixing Parts
 161-45 Remote-Control Assy
 18 Injection Pump
 19 Electrical Parts
 2 Cyl. Block and Other Parts
 201-28 Lever Assy, Control
 221-45 Hydr Lines, Upp
 24100J5144 Joint Assy, Swivel
 24100J6668 Joint Assy, Swivel
 2420U235 Plug Assy
 2436R1094 Valve Assy, Main Relief
 2436R593 Spool Assy
 2436R680 Valve Assy, (Clamshell)
 2436R683 Valve Assy, Relief
 2436R721 Valve Assy, Over-Load Relief
 2436R727 Valve Assy, Relief
 2436R769 Valve Assy Relief
 2436R790 Valve Assy
 2436R807 Spool Assy
 2436R837 Valve Assy, Port Relief
 2436R839 Valve Assy, Main Relief
 2436R884 Valve Assy, Solenoid
 2436R886 Spool Assy
 2436R906 Valve Assy, Shuttle
 2436R913 Valve Assy, Relief
 2436U1142 Valve Assy, Pilot
 2436U1200 Valve Assy, Pilot
 2436U1213 Valve Assy, Control
 2436U1236 Valve Assy, Control



Figure Search for SK100 MARK III EXCAVATOR ASN YW02801

2436U1237 Valve Assy, Control
2436U1283 Valve Assy, Reduction
2436U1303 Valve Assy, Flow-Divided
2436U1310 Valve Assy
2436U1314 Valve Assy, Solenoid
2436U1421 Valve Assy, Control
2436U1426 Valve Assy, Control
2436U1453 Valve Assy, Solenoid
2436U1456 Valve Assy, Control
2436U1471 Regulator Assy (Rear)
2436U1472 Regulator Assy (Front)
2436U2529 Valve, Sequence
2436U2584 Valve Assy, Bypass (Independent Travel)
2436U2590 Valve Assy, Solenoid
2436U2606 Valve Assy, Pilot
2436U2623 Valve Assy, Holding
2436U2633 Valve Assy, Control
2436U2642 Valve Assy, Pilot
2436Z416 Section Assy, Inlet
2437U157 Pump Assy, Gear
2437U405 Pump Assy
2437U412 Pump Assy
2438U1013 Cylinder Assy
2438U1097 Cylinder Assy (Bucket)
2438U1123 Cylinder Assy (R. II Boom)
2438U1125 Cylinder Assy (Arm)
2438U1126 Cylinder Assy (L. II Boom)
2438U1131 Cylinder Assy (Bucket)
2438U1157 Cylinder Assy (Clamshell)
2438U696 Cylinder Assy (Telescopic)
2438U738 Cylinder Assy (Dozzer)
2441U825 Motor Assy
2441U829 Motor Assy (Propelling)
291-01 Power-Plant Assy
295-01 Engine Assy
3 Timing Gear Case Other Parts
301-01 Pump Assy, Connect
321-01 Radiator Assy
371-01 Control Assy, Engine
381-45 Panel Assy, Inst
386-01 Gauge, Cluster
397-32 Heater and Defroster
398-32 Heater Assy
4 Fly Wheel Housing and Other Parts
411-45 Wiring Assy, Elec
421-01 Battery Assy
424-01 Light Assy
425-01 Lamp Assy

Figure Search for SK100 MARK III EXCAVATOR ASN YW02801

441-01 Install, Low
441-09 Install, Low
451-01 Idler Assy
451-09 Idler Assy
461-01 Roller Assy
461-09 Roller Assy
467-01 Roller Assy
467-09 Roller Assy
471-01 Spring Assy, Track
491-01 Hydr Lines, Low
5 Oil Pan and Other Parts
511-01 Install, Crawler Track
511-09 Rubber Crawler
52 Injection Pump; Proper (Diesel Kiki)
53 Governor (Mechanical) (Diesel Kiki)
54 Feed Pump; Injection Pump (Diesel Kiki)
58 Nozzle Holder (Diesel Kiki)
6 Oil Pump and Fixing Parts
62 Starter (Nikko)
621-01A Boom Assy, 4.26M
63 Generator (Nikko)
631-45 Arm Assy, 2.27M
641-45 Bucket Assy, 0.4M{3}
7 Crank Shaft, Crank Brg., Piston, Conn. Rod and Flywheel
701-01 Pump Assy, Fuel
711-45 Guard Assy, Cab
712-45 Vandalism Pro. Group
775-28 Rework, Power-Plant
794-52 Fan Assy, Automobile
795-32 Light, Boom
798-45 Alarm Assy
851-45 Arm Assy, 1.9M
852-45 Arm Assy, 2.77M
856-01A Arm Assy, Extension
9 Valve Mechanism (Cam Shaft, Idle Gear, Rocker Arm)
912-45 Bucket Assy, 0.25M{3}
913-45 Bucket Assy, 0.3M{3}
914-45 Bucket Assy, 0.35M{3}
915-45 Bucket Assy, 0.45M{3}
961-45 Label, Name-Plate
981-45 Tool Assy
986-45 Element Kit



DealerNation@aol.com

How To Use Figure Search

1). Locate the figure list index at the beginning of manual

examples:

01A01 FRONT WHEEL ASSEMBLY -
2100,2110,2120,2150,2300,2310,3055,3100,3120,3150,3190,3300,3310,3550,4140

01A01[C] FRONT WHEEL ASSEMBLY, W/16" WHEELS - 3400, 3500, 3550, 4400,
4500, 4410, 5100, 5200, 5190, 7100, 7200

01B01 STANDARD REAR WHEELS - 2000, 4100 & 3000 EXCEPT 3550

01B01[A] STANDARD REAR WHEELS - 3500, 3550, 5000, 7000, 4000 EXCEPT 4110

01B02 POWER ADJUSTABLE REAR WHEELS - 2000, 3000, 4140

Use the "search" feature in adobe to jump to the **figure number**.

Press **Ctrl** key, and letter **F** on the keyboard, at the same time. This will bring up the "search" feature in Adobe Acrobat. Then simply type in the **figure number** you wish to locate, and press enter.

Adobe takes you immediately to that page!



Thank you very much
for your reading.
Please click here
to get more information.