




Bobcat®

Operation & Maintenance Manual Three-Point PTO Sprayer

(3 PT Sprayer) S/N ABKT00101 & Above



CONTENTS

FOREWORD..... III
SAFETY & TRAINING RESOURCES..... XI
OPERATING INSTRUCTIONS OI-1
PREVENTIVE MAINTENANCE PM-1
MACHINE SIGN TRANSLATIONS MST-1
SPECIFICATIONS..... SPEC-1
WARRANTY WARRANTY-1
ALPHABETICAL INDEX INDEX-1

REFERENCE INFORMATION

Write the correct information for YOUR three-point PTO sprayer in the spaces below. Always use these numbers when referring to your three-point PTO sprayer.

Three-Point PTO Sprayer Serial Number _____

NOTES:

YOUR BOBCAT® DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Drève Richelle 167
B-1410 WATERLOO
Belgium

FOREWORD

**SAFETY &
TRAINING
RESOURCES**

**OPERATING
INSTRUCTIONS
(OI)**

**PREVENTIVE
MAINTENANCE
(PM)**

**MACHINE SIGN
TRANSLATIONS
(MST)**

**SPECIFICATIONS
(SPEC)**

WARRANTY

**ALPHABETICAL
INDEX**



FOREWORD

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the three-point PTO sprayer. **READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR three-point PTO sprayer.** If you have any questions, see your Bobcat dealer.

BOBCAT COMPANY IS ISO 9001:2000 CERTIFIED	V
DELIVERY REPORT	VII
FEATURES AND ACCESSORIES	IX
Standard Items	IX
IDENTIFICATION AND MACHINE SIGNS (DECALS)	VIII
SERIAL NUMBER LOCATION	VII
Implement Serial Number Location	VII



Thank you very much
for your reading.
Please click here
to get more information.