
70/70A SERIES REPAIR MANUAL

COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	2
SECTION 21 - TRANSMISSION	7
SECTION 23 - DRIVE LINES	12
SECTION 25 - FRONT MECHANICAL DRIVE	12
SECTION 27 - REAR DRIVE AXLE	15
SECTION 31 - POWER TAKE-OFF	16
SECTION 33 - BRAKES AND CONTROLS	17
SECTION 35 - HYDRAULIC SYSTEMS	20
SECTION 41 - STEERING	29
SECTION 44 - TWO-WHEEL DRIVE AXLE AND WHEELS	30
SECTION 50 - CLIMATE CONTROL	32
SECTION 55 - ELECTRICAL SYSTEMS	33
SECTION 90 - PLATFORM, CAB, AND BODYWORK	40

The following pages are the collation of the contents pages from each section and chapter of the 70/70A Series Repair manual.

The sections used throughout the New Holland product Repair manuals may not be used for each product. Each book will be labeled with the section number and which sections are in each book.



The sections listed above are the sections utilized for the 70/70A Series Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87018723

Chapter 1 - General Information

CONTENTS

Section	Description	Page
00 000	Forward	2
	Precautionary Statements	3
	Safety Precautions	4
	Health and Safety Precautions	7
	Tractor Identification	14
	Service Techniques	21
	Sealer Specifications	23
	Hardware Torque Values	23
	Lubrication	26
	Recommended Lubricants and Coolants	26

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 1 - Engine and Lubrication System

CONTENTS

Section	Description	Page
10 000	Specifications	3
	Torque Values	12
	Grease and Sealants	14
	Special Tools	15
	Description of Operation	16
	Cylinder Head Assembly	22
	Camshaft Assembly	22
	Crankshaft Assembly	22
	Connecting Rods	22
	Pistons	22
	Manifolds	22
	Cylinder Block Assembly	22
	Timing Gears	22

SECTION 10 - ENGINE

BOOK 1 - 87018723

Chapter 1 - Engine and Lubrication System (Continued)

CONTENTS

Section	Description	Page
	Engine Lubrication	23
	Troubleshooting	27
	Disassembly and Repair	30
	Cylinder Head	30
	Cylinder Head Reassembly	42
	Additional Information	45
	Crankcase Front Cassette Seal	47
	Parts Affected	47
	Additional Information	47
	Removal of Old Style Seal and Installation of the New Cassette Seal	47
	Front Cassette Seal Removal	53
	Engine Front Cover and Timing Gear	58
	Oil Pan	60
	Connecting Rods, Bearings, Pistons and Rings	61
	Cylinder Block Overhaul	64
	Piston Assembly Installation	69
	Main Bearings, Flywheel and Crankshaft	70
	Rear Cover Plate	72
	Oil Pump	75
	Oil Filter Support Assembly	77
	Crankshaft	78
	Camshaft	82
	Engine Timing Gears	84
	Engine Compression Test	85
	Test Procedure	85
	Test Reading	85
	Test Conclusion	85



Thank you very much
for your reading.
Please click here
to get more information.