

tm1452 - 670B, 672B 770B, 770BH 772B, 772BH Motor Graders Operation and Tests Technical Manual

Table of Contents

Foreword

Section 9000: General Information

Group 01: Safety

Handle Fluids Safely-Avoid Fires

Prevent Battery Explosions

Prepare for Emergencies

Prevent Acid Burns

Handle Chemical Products Safely

Avoid High-Pressure Fluids

Park Machine Safely

Support Machine Properly

Wear Protective Clothing

Work in Clean Area

Service Machines Safely

Work In Ventilated Area

Illuminate Work Area Safely

Replace Safety Signs

Use Proper Lifting Eq

Remove Paint Before Weldi

Avoid Heating Near Pressurized Fluid Lines

Keep ROPS Installed Properly

Service Tires Safely

Avoid Harmful Asbestos Dust

Practice Safe Maintenance

Use Proper Tools

Dispose of Waste Properly

Live With Safety

Group 02: General Specifications



670B And 672B Specifications

770B, 770BH, And 772BH Specifications

Group 03: Torque Values

Hardware Torque Specifications

Metric Bolt and Cap Screw Torque Values

Additional Metric Cap Screw Torque Values

Unified Inch Bolt and Cap Screw Torque Values

Check Oil Lines And Fittings

Service Recommendations for O-Ring Boss Fittings

Service Recommendations for Flat Face O-Ring Seal Fittings

Service Recommendations for Metric Series Four Bolt Flange Fitting

Service Recommendations For Inch Series Four Bolt Flange Fittings

Group 04: Fuels And Lubricants

Fuel Specifications

Low Sulfur Diesel Fuel Conditioner

Storing Fuel

Do Not Use Galvanized Containers

Fuel Tank

Engine Oil

Transmission, Hydraulic System, Tandem Drive, And Wheel Motor Oil

Circle Drive Gearbox Oil

Grease

Alternative and Synthetic Lubricants

Lubricant Storage

Mixing of Lubricants

Diesel Engine Coolant

Section 9005: Operational Checkout Procedure

Group 10: Operational Checkout Procedure

Operational Checkout Record Sheet 670B, 672B, 770B, 770BH, 772B, 772BH Motor Graders

Complete Machine Operational Checkout

Section 9010: Engine

Group 05: Theory Of Operation

6414 John Deere Engine-Use CTM4

6068 John Deere Engine-Use CTM8

6466 John Deere Engine-Use CTM1

6076 John Deere Engine-Use CTM42 (SN 500000-)

Air Cleaner Operation

Radiator Surge Tank-770B, 770BH, 772BH (SN 543490-)

Aspirator Muffler Operation-770B, 770BH, 772B, 772BH

Dual Power Control System Operation In Low Power Mode-770BH, 772BH (SN -543489)

Dual Power Control System Operation In High Power Mode-770BH, 772BH (SN -543489)

Electronic Fuel Injection System-770BH, 772BH (SN 543490-)

Fuel System Operation-770BH, 772BH (SN 543490-)

Turbocharger Operation

Wastegated Turbochargers

Group 10: System Operational Checks

Engine Operational Checks

Group 15: Diagnostic Information

Diagnose Engine Malfunctions

Group 20: Adjustments

JT05801 Clamp-On Electronic Tachometer Installation

Electronic Injection Pump Service Connectors-J3, J4, J5, J6-770BH, 772BH (SN 543490-)

Using The Electronic Governor Tester, JT05829-770BH, 772BH(SN 543490-)

Bleed The Fuel System

Fan Belt Tension Adjustment

Slow And Fast Idle Adjustment-670B, 672B

Slow And Fast Idle Adjustment-770B, 770BH, 772B, 772BH (SN -543489)

Slow And Fast Idle Adjustment-770B (SN 543490-)

Slow And Fast Idle Adjustment-770BH, 772BH (SN 543490-)

Engine Speed Linkage Adjustment-670B, 672B

Engine Speed Linkage Adjustment-770B, 770BH, 772B, 772BH (SN -543489)

Engine Speed Linkage Adjustment-770B (SN 543490-)

Engine Speed Linkage Adjustment-770BH, 772BH (SN 543490-)

Dual Horsepower Check-770BH, 772BH (SN 543490-)

Fuel Shut-Off Cable And Linkage Adjustment-770B, 770BH, 772B, 772BH (SN -543489)

Fuel Shut-Off Solenoid Adjustment-770B (SN 543490-)

Do Engine Break-In-670B, 672B

Do Engine Break-In-770B, 770BH, 772B, 772BH

Group 25: Tests

JT05801 Clamp-On Electronic Tachometer Installation

Electronic Injection Pump Service Connectors-J3, J4, J5, J6-770BH, 772BH (SN 543490-)

Using The Electronic Governor Tester, JT05829-770BH, 772BH(SN 543490-)

Air Filter Restriction Indicator Switch Test

Radiator Air Flow Test-670B, 672B, 770B, 770BH, 772B, 772BH (SN -543489)

Radiator Air Flow Test-670B, 672B, 770B (SN 543490-)

Radiator Air Flow Test-770BH, 772BH (SN 543490-)

Engine Power Test Using Turbocharger Boost Pressure-670B, 672B, 770B, 772B, 770BH, And 772BH (SN -543489)

Engine Power Test Using Turbocharger Boost Pressure-670B, 672B, And 770B (SN 543490-)

Engine Power Test Using Turbocharger Boost Pressure-770BH, 772BH (SN 543490-)

Dual Power Solenoid Valve Test-770BH, 772BH (SN -543489)

Section 9015A: Electrical System (SN -543489)

Group 00: Electrical System Operation And Test (SN -543489)

Battery Specifications (SN -543489)

Battery Operation

Diagnose Battery Malfunctions

Check Battery Electrolyte Level And Terminals

Procedure For Testing Batteries

Using Booster Batteries-24 Volt System

Visually Inspect Electrical System

Electrical Circuit Malfunctions

High Resistance Circuit

Open Circuit

Grounded Circuit

Shorted Circuit

Multimeter

Seven Step Electrical Test Procedure



Thank you very much
for your reading.
Please click here
to get more information.