

John Deere 8235R, 8260R, 8285R, 8310R, 8335R and 8360R Tractors Repair  
Technical Manual (TM110319)


John Deere Agriculture

**8235R, 8260R, 8285R, 8310R, 8335R,  
and 8360R Tractors Repair**




**REPAIR MANUAL**

**Covered models: 2WD or MFWD - PIN  
prefix YH models 8235R, 8260R,  
8285R, 8310R, 8335R, 8360R**

TM110319, May 2013






# John Deere 8235R, 8260R, 8285R, 8310R, 8335R and 8360R Tractors Repair Technical Manual (TM110319)

Download Technical Manual For John Deere 8235R, 8260R, 8285R, 8310R, 8335R and 8360R (2WD or MFWD  PIN prefix YH models) Tractors Repair.

Publication No. TM110319, May 2013

This Technical Manual offers all the Service and Repair Information for John Deere 8235R, 8260R, 8285R, 8310R, 8335R, and 8360R Tractors. With this in-depth & highly detailed manual you will be able to work on your vehicle with the absolute best resources available, which will not only save you money in repair bills but will also help you to look after your business. The information on this manual covered everything you need to know when you want to repair or service on John Deere 8235R, 8260R, 8285R, 8310R, 8335R, and 8360R Tractors.

Models Covered:

2WD or MFWD  PIN prefix YH models 8235R, 8260R, 8285R, 8310R, 8335R, 8360R

This manual is INSTANT DOWNLOAD. It means no shipping cost or waiting for getting a CD package for several days. you will receive this manual today via instant download on completion of payment via our secure payment processor.

Manual Contents:

FOREWORD

DEALER PREDELIVERY INFORMATION FORM

Section 10  GENERAL INFORMATION

Group 05  Safety

Group 10  General Information

Section 20  ENGINE

Group 00  Component Removal and Installation

Group 05  Engine Repair

Section 30  FUEL AND COOLING SYSTEMS

Group 05  Diesel Fuel System

Group 10  Air Intake System

Group 15  Engine Cooling System

Group 20  Coolers and Air Conditioning Condenser

Group 25  Exhaust System

Section 40  ELECTRICAL

Group 05  Connectors

Group 10  Wire Harness Routings




Group 15  Charging Circuit

Group 20  Starting Circuit

Group 25  Relays, Fuses, Solenoids, and Switches

Group 30  Monitoring Systems and Sensors

Group 35  Armrest Control

Group 40  Implement and Accessory Connectors



Thank you very much  
for your reading.  
Please click here  
to get more information.