

Shop Manual

HYDRAULIC
EXCAVATOR

GALEO

PC2000-8

SERIAL NUMBERS 20001 and up

PDF



DOWNLOAD



KOMATSU

HYDRAULIC EXCAVATOR

PC2000-8

Machine model	Serial number
PC2000-8	20001 and up

00 Index and foreword

Index

Composition of shop manual	2
Table of contents	4

Composition of shop manual

The contents of this shop manual are shown together with Form No. in a list.

Note 1: Always keep the latest version of this manual in accordance with this list and utilize accordingly.

The marks shown to the right of Form No. denote the following:

O: New issue (to be filed additionally) ●: Revision (to be replaced for each Form No.)

Note 2: This shop manual can be supplied for each Form No.

Note 3: To file this shop manual in the special binder for management, handle it as follows:

- Place a divider on the top of each section in the file after matching the Tub No. with No. indicated next to each Section Name shown in the table below:
- File overview and other materials in sections in the order shown below and utilize them accordingly.

Section Title	Form Number
Shop Manual, contents binder, binder label and tabs	SEN01607-06
00 Index and foreword	SEN01608-06
Index	SEN01609-06 ●
Foreword and general information	SEN01610-02
01 Specification	SEN01611-01
Specification and technical data	SEN01612-01 ●
10 Structure, function and maintenance standard	SEN01613-02
Engine and cooling system	SEN01614-00
Power train	SEN01615-00
Undercarriage and frame	SEN01616-00
Hydraulic system, Part 1	SEN01618-02 ●
Hydraulic system, Part 2	SEN01619-01
Hydraulic system, Part 3	SEN01620-01
Work equipment	SEN01621-02 ●
Cab and its attachments	SEN01622-00
Electrical system	SEN01623-01
20 Standard value table	SEN01624-00
Standard service value table	SEN02006-00
30 Testing and adjusting	SEN01625-00
Testing and adjusting, Part 1	SEN02007-00
Testing and adjusting, Part 2	SEN02008-00
Testing and adjusting, Part 3	SEN02009-00
Testing and adjusting, Part 4	SEN02010-00
40 Troubleshooting	SEN01626-00
Failure code table and fuse locations	SEN02011-00
General information on troubleshooting	SEN02012-00
Troubleshooting by failure code, Part 1	SEN02096-00
Troubleshooting by failure code, Part 2	SEN02097-00
Troubleshooting by failure code, Part 3	SEN02098-00
Troubleshooting by failure code, Part 4	SEN02099-00

Troubleshooting by failure code, Part 5	SEN02100-00
Troubleshooting by failure code, Part 6	SEN02101-00
Troubleshooting by failure code, Part 7	SEN02102-00
Troubleshooting of electrical system (E-mode)	SEN02103-00
Troubleshooting of hydraulic and mechanical system (H-mode)	SEN02104-00
Troubleshooting of mechanical system (S-mode)	SEN02105-00
50 Disassembly and assembly	SEN01627-01
General information on disassembly and assembly	SEN02133-00
Engine and cooling system (12V140E-3)	SEN02134-01
Engine (12V140E-3)	SEN02135-01
Power train	SEN02136-00
Undercarriage and frame	SEN02137-00
Hydraulic system	SEN02138-00
Work equipment	SEN02139-00
Cab and its attachments	SEN02140-00
Electrical system	SEN02141-00
90 Diagrams and drawings	SEN01628-03
Hydraulic diagrams and drawings	SEN01629-00
Electrical diagrams and drawings	SEN01630-03



Thank you very much
for your reading.
Please click here
to get more information.