





# Bobcat®

---

## Operation & Maintenance Manual Mower

---

(Finish Mower 72) S/N A8WB00101 & Above  
(Finish Mower 90) S/N A8SD00101 & Above





# OPERATOR SAFETY WARNINGS




## WARNING

Operator must have instructions before operating the machine. Untrained operators can cause injury or death.


W-2001-0502




**Safety Alert Symbol:** This symbol with a warning statement, mean: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




⚠ Never use the mower without instructions. See machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.




⚠ Always install approved lift arm support device when servicing the mower. Raise lift arms and tilt Bob-Tach fully forward.




⚠ Always use the seat bar and fasten seat belt snugly.  
⚠ Always keep feet on the pedals when operating loader.




⚠ Always check work area before operating mower.  
⚠ Never use loader without operator cab with ROPS and FOPS approval. Fasten your seat belt.




⚠ Do not use loader or mower in atmosphere with explosive dust, explosive gas, or where exhaust can contact flammable material.




⚠ Never allow riders on mower.  
⚠ Keep bystanders away when operating mower.



⚠ Keep bystanders away when operating mower.  
⚠ Do not operate without blade shutoff device.



⚠ Always carry attachment as low as possible.  
⚠ Do not travel or turn with lift arms up.



⚠ Do not put hands, feet, or objects under mower when engine is running.  
⚠ To park, engage parking brake and put attachment flat on the ground and stop engine.

## SAFETY EQUIPMENT

The Bobcat Loader must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

1. SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
2. SEAT BAR: When up, it must lock the controls.
3. OPERATOR CAB (ROPS and FOPS): It must be on the loader with all fasteners tight.
4. OPERATOR'S HANDBOOK: Must be in the cab.
5. MACHINE AND ATTACHMENT SAFETY SIGNS (DECALS): Replace if damaged.
6. SPECIAL APPLICATIONS KIT: Available from your dealer.
7. GRAB HANDLES: Replace if damaged.
8. SAFETY TREADS: Replace if damaged.
9. LIFT ARM SUPPORT DEVICE
10. PARKING BRAKE
11. BLADE SHUTOFF DEVICE

OSW39-0409



**Bobcat®**

# CONTENTS

FOREWORD .....	5
SAFETY AND TRAINING RESOURCES .....	13
OPERATING INSTRUCTIONS .....	21
PREVENTIVE MAINTENANCE .....	85
MACHINE SIGN TRANSLATIONS .....	103
SPECIFICATIONS .....	111
WARRANTY .....	117
ALPHABETICAL INDEX .....	121

## REFERENCE INFORMATION

Write the correct information for YOUR Bobcat attachment in the spaces below. Always use these numbers when referring to your Bobcat attachment.

Attachment Serial Number \_\_\_\_\_

NOTES:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

YOUR BOBCAT DEALER:

ADDRESS: \_\_\_\_\_

PHONE: \_\_\_\_\_

Bobcat Company  
P.O. Box 128  
Gwinner, ND 58040-0128  
UNITED STATES OF AMERICA

Doosan Benelux SA  
Drève Richelle 167  
B-1410 Waterloo  
BELGIUM



Thank you very much  
for your reading.  
Please click here  
to get more information.