




PLANER

S/N 052300701 & 303600101 & Above

Operation & Maintenance Manual



**MELROE
INGERSOLL-RAND**

6722362(4-93)



bobcat
© Melroe Company 1996
Printed in U.S.A.

CONTENTS

FOREWORD	iii
SAFETY	vii
OPERATING INSTRUCTIONS	1
PLANER SERVICE	19
SPECIFICATIONS	31

FOREWORD

SAFETY

**OPERATING
INSTRUCTIONS**

**PLANER
MAINTENANCE**

SPECIFICATIONS

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat Planer in the spaces below. Always use these numbers when referring to your Bobcat Planer.

Planer Serial Number _____

NOTES: _____

The Attachment Service Manual P/N 6722922 gives complete repair procedures for your attachment components. You can order the Melroe Attachment Service Manual from your Melroe dealer.


YOUR LOADER PLANER DEALER:

ADDRESS:

PHONE:

Melroe Company
P.O. Box 128
Gwinner, ND 58040-0128

Melroe Europe
J. Huysmanslaan 59
B-1651 LOT
Belgium





FOREWORD

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Planer. **READ AND UNDERSTAND THIS MANUAL BEFORE OPERATING YOUR PLANER.** If you have any questions, see your Bobcat loader dealer.

SERIAL NUMBER LOCATION	v
ATTACHMENT DELIVERY REPORT	v
PLANER IDENTIFICATION AND MACHINE SIGNS	v



Thank you very much
for your reading.
Please click here
to get more information.