




Bobcat®

Operation & Maintenance Manual Three-Point Finish Mower

(3FM84) S/N AF4500101 & Above



OPERATOR SAFETY WARNINGS




WARNING

Operator must have instructions before running the machine. Untrained operators can cause injury or death.


W-2001-1285




Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




- ⚠ Never use the three-point finish mower without instructions. See machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.




- ⚠ Securely block up the implement before working underneath.




- ⚠ Fasten seat belt securely when Roll-Over Protective Structure (ROPS) is up and locked.
- ⚠ DO NOT wear seat belt if ROPS is down.



- ⚠ USE ROPS AND FASTEN SEAT BELT.
- ⚠ Always check work area before operating three-point finish mower.




- ⚠ Do not use compact tractor or three-point finish mower in atmosphere with explosive dust, explosive gas, or where exhaust can contact flammable material.



- ⚠ Never allow riders on three-point finish mower.
- ⚠ Keep bystanders away when operating three-point finish mower.




- ⚠ Keep PTO master shield, implement shield, and driveline guards in place.
- ⚠ Keep away from moving parts.
- ⚠ Only operate from the operator's position.



- ⚠ Obey all traffic regulations when on public roads. Use slow moving vehicle (SMV) emblem and hazard flashers when required.

- ⚠ Lock brake pedals together for road travel.



- ⚠ Do not put hands, feet, or objects under three-point finish mower when engine is running.
- ⚠ To park, engage PARKING BRAKE, put all controls in NEUTRAL, move PTO lever(s) to OFF, put attachment and implement flat on the ground and stop engine.

SAFETY EQUIPMENT

The Compact Tractor and Three-Point Finish Mower Implement must be equipped with safety items necessary for each job. Ask your dealer about implements and accessories.

1. SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
2. OPERATOR CAB (ROPS): It must be on the compact tractor with all fasteners tight.
3. MACHINE AND IMPLEMENT WARNING SIGNS: Replace if damaged.
4. COMPACT TRACTOR PTO SHIELD: Replace if damaged.
5. PARKING BRAKE.
6. IMPLEMENT PTO SHIELD: Replace if damaged.
7. PTO DRIVELINE GUARD: Replace if damaged.



Bobcat®

CONTENTS

FOREWORD

FOREWORD.....	III
SAFETY & TRAINING RESOURCES.....	IX
OPERATING INSTRUCTIONS.....	OI-1
PREVENTIVE MAINTENANCE.....	PM-1
MACHINE SIGN TRANSLATIONS.....	MST-1
SPECIFICATIONS.....	SPEC-1
WARRANTY.....	WARRANTY-1
ALPHABETICAL INDEX.....	INDEX

SAFETY & TRAINING RESOURCES

OPERATING INSTRUCTIONS (OI)

PREVENTIVE MAINTENANCE (PM)

MACHINE SIGN TRANSLATIONS (MST)

SPECIFICATIONS (SPEC)

WARRANTY

ALPHABETICAL INDEX

REFERENCE INFORMATION

Write the correct information for YOUR three-point finish mower in the spaces below.
Always use these numbers when referring to your three-point finish mower.

Three-Point Finish Mower Serial Number

NOTES:

YOUR BOBCAT® DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128

Bobcat Company Europe
Drève Richelle 167
B-1410 WATERLOO
Belgium



Thank you very much
for your reading.
Please click here
to get more information.