

5310, 5055E, 5060E, 5065E and 5075E Tractors (India and Asia)

DIAGNOSTIC TECHNICAL MANUAL

5310, 5055E, 5060E, 5065E, 5075E

TM902019 14APR15 (ENGLISH)

For complete service information also see:

5055E, 5060E, 5065E And 5075E
Tractors Repair Technical Manual (India and Asia Edition) TM901919

PowrReverser™ Transmission - John Deere™ Pune Works. CTM901219

Drive Train 9X3 (TSS) CTM901119

Alternators and Starting Motors CTM77

00.16, 20.09, 20.09C, 20.11, 20.16, G20.16 and G20.09 Front Wheel Axles CTM70

725, 730, 733, 735, 740, 745, 750, 755 and 755HD Front Drive Axles, 2-Piece DANA CTM125

PowerTech 2.9L Diesel Engines CTM125

PDF



DOWNLOAD



Table of contents

FOREWORD

Section 210 - GENERAL

- Group 05 - Safety
- Group 10 - General Specifications
- Group 15 - General References

Section 211 - DIAGNOSTIC TROUBLE CODES

- Group CCU - CCU Code Diagnostics
- Group ICC - ICC Code Diagnostics
- Group PTR - PTR Code Diagnostics

Section 212 - OBSERVABLE SYMPTOMS

- Group 20 - Engines
- Group 30 - Fuel and Air
- Group 40 - Electrical
- Group 45 - Control Units
- Group 55 - PowrReverser™ Transmissions
- Group 56 - Drive Systems
- Group 60 - Steering and Brakes
- Group 70 - Hydraulics
- Group 90 - Operator Station

Section 213 - SYSTEM DIAGNOSIS

- Group 40 - Starting, Charging and Start Aid
- Group 55 - PowrReverser™ Transmission
- Group 56A - Differential Lock
- Group 56B - MFWD
- Group 56C - PTO
- Group 60A - Steering
- Group 60B - Rear Brakes
- Group 70A - Rear SCV System Diagnosis
- Group 70B - Mid-Mount Control Valve System Diagnosis
- Group 70C - Rear Hitch System Diagnosis
- Group 90 - Air Conditioning

Section 220 - ENGINES

- Group 05 - General Information
- Group 15 - Tests and Adjustments
- Group 20 - Engine System Theory of Operation

Section 230 - FUEL AND AIR

- Group 05 - General Information
- Group 20 - Fuel and Air Theory of Operation

Section 240 - ELECTRICAL SYSTEM

- Group 05 - Fuse/Relay Block
- Group 15 - Tests and Adjustments
- Group 20 - Theory of Operation
- Group 25 - Functional Schematics (Cab)
- Group 25A - Functional Schematics (IOOS)
- Group 30 - Wiring Harnesses (Cab)
- Group 30A - Wiring Harnesses (IOOS)
- Group 35 - Connector Information

Section 245 - CONTROL UNITS

- Group 05 - General References
- Group 15 - Tests and Adjustments
- Group CCU - CCU
- Group ICC - ICC

Group PTR - PTR

Section 255A - POWRREVERSER™ TRANSMISSION

Group 05 - General Information

Group 10 - Preliminary and Operational Checks

Group 15 - Tests and Adjustments

Group 20 - Theory of Operation

Group 25 - Schematics and Diagrams

Section 255B - TSS TRANSMISSION

Group 15 - Tests and Adjustments

Group 20 - Theory of Operation

Group 25 - Schematics and Diagrams

Section 256 - DRIVE SYSTEMS

Group 05 - General Information

Group 10 - Preliminary and Operational Checks

Group 15 - Tests and Adjustments

Group 20 - Theory of Operation

Group 25 - Schematics and Diagrams

Section 260 - STEERING AND BRAKES

Group 05 - General Information

Group 10 - Preliminary and Operational Checks

Group 15 - Test and Adjustments

Group 20 - Theory of Operation

Section 270 - HYDRAULICS

Group 05 - General Information

Group 10 - Preliminary and Operational Checks

Group 15 - Tests and Adjustments

Group 20 - Theory of Operation

Section 290 - OPERATOR'S STATION

Group 05 - General Information

Group 10 - Preliminary and Operational Checks

Group 15 - Tests and Adjustments

Group 20 - Theory of Operation

Section 299 - SERVICE TOOLS

Group 05 - Dealer-Fabricated Tools

Group 10 - Service Tools and Kits



Thank you very much
for your reading.
Please click here
to get more information.