

210LJ LANDSCAPE LOADER REPAIR



JOHN HARE



COLLECTION

REPAIR TECHNICAL MANUAL

210LJ Landscape Loader

TM10731 27 DEC 15 (English)

For complete service information also see:

210LJ Landscape Loader	TM10730
PowerTech E 4.5 and 6.8L Diesel Engines Level 16 Electronic Fuel System With Denso HPCR	CTM502
Super Caddy Oil Cleanup Procedure	CTM310
Hydraulic Cylinders	CTM120519
120 Series Hydraulic Cylinders	CTM114319
PowerTech 4.5L & 6.8L Diesel Engine IIIA, Tier 3/Stage IIA Tier 3/Stage III, (Base E	
100 Series Hydraulic Cylinders	CTM103519



TABLE OF CONTENTS

FOREWORD

TECHNICAL INFORMATION FEEDBACK FORM

Section 00 - GENERAL INFORMATION

Group 0001 - Safety

Group 0003 - Torque Values

Section 01 - WHEELS

Group 0110 - Wheels and Fastenings

Section 02 - AXLES AND SUSPENSION SYSTEMS

Group 0225 - Input Drive Shafts and U-Joints

Group 0240 - Powered Wheel Axle (MFWD)

Group 0250 - Axle Shaft, Bearings, and Reduction Gears

Section 03 - TRANSMISSION

Group 0300 - Removal and Installation

Group 0315 - Controls Linkage

Group 0350 - Gears, Shafts, and Power Shift Clutches

Group 0360 - Hydraulic System

Section 04 - ENGINE

Group 0400 - Removal and Installation

Section 05 - ENGINE AUXILIARY SYSTEMS

Group 0505 - Cold Weather Starting Aid

Group 0510 - Cooling Systems

Group 0515 - Speed Controls

Group 0520 - Intake System

Group 0530 - Exhaust System

Group 0560 - External Fuel Supply System

Section 06 - TORQUE CONVERTER

Group 0651 - Turbine, Gears and Shaft

Section 09 - STEERING SYSTEM

Group 0960 - Hydraulic System

Section 10 - SERVICE BRAKES

Group 1011 - Active Elements

Group 1060 - Hydraulic System

Section 11 - PARK BRAKE

Group 1111 - Active Elements

Section 15 - HITCH ATTACHMENTS

Group 1511 - Hitch, Drawbar, and Weights

Group 1520 - Three-Point Hitch

Section 17 - FRAMES, CHASSIS OR SUPPORTING STRUCTURE

Group 1740 - Frame Installation

Section 18 - OPERATOR'S STATION

Group 1800 - Removal and Installation

Group 1810 - Operator Enclosure

Group 1821 - Seat and Seat Belt

Group 1830 - Heating and Air Conditioning

Section 19 - SHEET METAL AND STYLING

Group 1910 - Hood and Engine Enclosure

Group 1913 - Miscellaneous Shields

Group 1921 - Grille and Grille Housing

Group 1927 - Fenders

Section 20 - SAFETY, CONVENIENCE, AND MISCELLANEOUS

Group 2004 - Horn and Warning Devices

Section 21 - MAIN HYDRAULIC SYSTEM

Group 2160 - Hydraulic System

Section 31 - LOADER

Group 3100 - Loader

Group 3102 - Bucket

Group 3115 - Control Linkages

Group 3160 - Hydraulic System

Section 40 - PTO

Group 4000 - Removal and Installation

Group 4051 - Gears, Shafts, and Bearings

Group 4060 - Hydraulic System

Section 99 - DEALER FABRICATED TOOLS

Group 9900 - Dealer Fabricated Tools



Thank you very much
for your reading.
Please click here
to get more information.