





Bobcat®

Operation & Maintenance Manual Chipper

(WC-8B Chipper) S/N A02B00101 & Above



OPERATOR SAFETY WARNINGS

WARNING

Operator must have instructions before operating the machine. Untrained operators can cause injury or death.

W-2001-0502

Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.

CORRECT

P-90216

Never operate without instructions. See machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.

CORRECT

B-15288

Wear eye, face, and hearing protection and wear tight fitting clothing when operating.

Stand to the side of the feed table and chute when feeding branches.

WRONG

B-15227

Do not operate machine and chipper near steep banks or drop offs.

Operate chipper only on flat and level surfaces.

WRONG

B-15225

Never climb on or reach into the feed table. Do not overreach. Keep proper balance and footing.

WRONG

B-15224

Do not use machine and chipper in atmosphere with explosive dust, explosive gas, or where exhaust can contact flammable material.

WRONG

B-15221

Never carry riders.

Keep bystanders away from work area.

WRONG

B-15222

Always carry chipper attachment as low as possible.

Do not travel or turn with lift arm(s) up.

WRONG

B-15226

Keep bystanders away from discharge chute. Position discharge chute away from bystanders or property.

Keep metal objects, rocks, bottles, cans, and other foreign objects out of chipper.

WRONG

B-15228

Check for clearance under overhead electrical lines.

WRONG

B-15223

Do not operate chipper when not properly attached to loader or utility work machine.

SAFETY EQUIPMENT

The Bobcat machine and attachment must be equipped with safety items necessary for each job. Ask your dealer for information on the safe use of attachments and accessories.

1. SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
2. SEAT BAR OR ARM REST: When up, it must lock the machine's lift, tilt and traction functions.
3. OPERATOR CAB (ROPS and FOPS): It must be on the machine with all fasteners tight.
4. OPERATOR'S HANDBOOK: Must be in the cab.
5. SAFETY SIGNS (DECALS): Replace if damaged.
6. SAFETY TREADS: Replace if damaged.
7. GRAB HANDLES: Replace if damaged.
8. LIFT ARM SUPPORT DEVICE: Replace if damaged
9. PARKING BRAKE: Check function.
10. BOBCAT INTERLOCK CONTROL SYSTEM (BICS) OR TOOLCAT INTERLOCK CONTROL SYSTEM (TICS): Check function.
11. REMOTE ATTACHMENT CONTROL (RAC) WITH EMERGENCY STOP: Check function.
12. FEED ROLLER STOP BAR: Check function.



Bobcat®

CONTENTS

FOREWORD	5
SAFETY & TRAINING RESOURCES	13
OPERATING INSTRUCTIONS	23
PREVENTIVE MAINTENANCE	85
MACHINE SIGN TRANSLATIONS	99
SPECIFICATIONS	117
WARRANTY	121
ALPHABETICAL INDEX	125

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat attachment in the spaces below. Always use these numbers when referring to your Bobcat attachment.

Attachment Serial Number _____

NOTES:

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128
UNITED STATES OF AMERICA

Doosan Benelux SA
Drève Richelle 167
B-1410 Waterloo
BELGIUM



Thank you very much
for your reading.
Please click here
to get more information.