





Bobcat®

EN

Operation & Maintenance Manual Cutter Crusher

(30 Cutter Crusher) S/N 991100101 & Above
(40 Cutter Crusher) S/N 991300101 & Above



OPERATOR SAFETY WARNINGS



WARNING


Operator must have instructions before operating the machine. Untrained operators can cause injury or death.

W-2001-0502



Safety Alert Symbol: This symbol is used for important safety messages. When you see this symbol, follow the safety messages to avoid personal injury or death.

CORRECT




P-90216



Never use the loader without instructions. See machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.

CORRECT




B-15869



Always install approved lift arm support device when servicing loader when lift arms are raised.

CORRECT



B-15570




Always use the seat bar and fasten seat belt snugly.



Always keep feet on the pedals when operating loader.

CORRECT




B-15864



Never use loader without operator cab with ROPS and FOPS approval.

WRONG



B-15867




Do not use loader in atmosphere with explosive dust, gas, or where exhaust can contact flammable material.



Avoid cutting gas, electric, or other utility lines.

WRONG



B-15868




Never demolish load bearing walls. Keep other personnel away from work area.



Always use special applications kit.

WRONG



B-15870



Do not undercut machine which can cause machine to fall.




Check rules and regulations at your location.



Operator and bystanders must wear goggles, hard hats, and hearing protection.

WRONG



B-15863




Always carry attachment as low as possible.



Do not travel or turn with lift arms up.

WRONG



B-15866




Never leave machine with engine running or with lift arms up.



To park, engage parking brake and put attachment on the ground.

WRONG



B-15865



Never modify equipment or add attachments not approved by Bobcat Company.



Never demolish ceilings or overhead structure.

SAFETY EQUIPMENT

The Bobcat Loader must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

1. SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
2. SEAT BAR: When up, it must lock the pedals.
3. OPERATOR CAB (ROPS and FOPS): It must be on the loader with all fasteners tight.
4. OPERATOR'S HANDBOOK: Must be in the cab.
5. MACHINE AND ATTACHMENT SAFETY SIGNS (DECALS): Replace if damaged, clean if soiled.
6. SPECIAL APPLICATIONS KIT
7. GRAB HANDLES: Replace if damaged.
8. SAFETY TREADS: Replace if damaged.
9. LIFT ARM SUPPORT DEVICE
10. PARKING BRAKE

OSW36-0409



Bobcat®

CONTENTS

FOREWORD	5
SAFETY & TRAINING RESOURCES	15
OPERATING INSTRUCTIONS	23
PREVENTIVE MAINTENANCE	95
SPECIFICATIONS	107
WARRANTY	111
ALPHABETICAL INDEX	115

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat attachment in the spaces below. Always use these numbers when referring to your Bobcat attachment.

Attachment Serial Number _____

NOTES:

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:



Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128
UNITED STATES OF AMERICA

Doosan Benelux SA
Drève Richelle 167
B-1410 Waterloo
BELGIUM



Thank you very much
for your reading.
Please click here
to get more information.