



# ECONO LANDPLANE

72" (S/N 989800101 & Above)  
78" (S/N 989900101 & Above)

## Operation & Maintenance Manual



**MELROE  
INGERSOLL-RAND**

6900960(10-99) Revised (5-12) (1)

Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.



© Melroe Company 1999  
Printed in U.S.A.



# CONTENTS

FOREWORD .....	iii
SAFETY .....	vii
OPERATING INSTRUCTIONS .....	1
ECONO LANDPLANE MAINTENANCE .....	11
SPECIFICATIONS .....	15

**FOREWORD**

**SAFETY**

## REFERENCE INFORMATION

Write the correct information for YOUR Econo Landplane in the spaces below  
Always use these numbers when referring to your Econo Landplane.

Econo Landplane Serial Number . . . . \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**OPERATING  
INSTRUCTIONS**

**ECONO  
LANDPLANE  
MAINTENANCE**

**SPECIFICATIONS**

**NOTES:** \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

**YOUR LOADER ECONO LANDPLANE DEALER:**

\_\_\_\_\_  
**ADDRESS:**

\_\_\_\_\_  
**PHONE:**

Melroe Company  
P.O. Box 128  
Gwinner, ND 58040-0128

Melroe Europe  
J. Huysmanslaan 59  
B-1651 LOT  
Belgium



## Melroe Company is ISO 9001 certified

---

**ISO 9001** is a set of international standards that control the processes and procedures which we use to design, develop, manufacture, distribute, and service Melroe Company products.

British Standards Institute (**BSI**) is the Certified Registrar Melroe chose to assess the Company's compliance with the ISO 9001 set of standards. The BSI registration certifies that the two Melroe manufacturing plants and the Melroe corporate offices (Gwinner, Bismarck & Fargo) in North Dakota are in compliance with ISO 9001. Only certified assessors, like BSI, can grant registrations. Since registration requires this *third-party auditing*, it is irrefutable evidence of conformance. Continued certification is subject to periodic audits.

ISO 9001 means that as a company we say what we do and do what we say. In other words, we have established procedures and policies, and we provide evidence that the procedures and policies are followed.

What does ISO 9001 mean to Bobcat Customers? It means that Melroe Company produces your Bobcat loader, Excavator and attachments with strict attention to details, using the latest technology and proven techniques.

# FOREWORD

## FOREWORD

This Operator's Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Econo Landplane. **READ AND UNDERSTAND THIS OPERATOR'S MANUAL BEFORE OPERATING YOUR ECONO LANDPLANE.** If you have any questions, see your Bobcat loader dealer.

SERIAL NUMBER LOCATION .....v . .

ATTACHMENT DELIVERY REPORT .....v . .

ECONO LANDPLANE IDENTIFICATION & MACHINE SIGNS (DECALS) . vi



Thank you very much  
for your reading.  
Please click here  
to get more information.