


# 595D Excavator Operation and Tests



For complete service information also see:

595D Excavator	
Repair .....	TM1445
4276 Engine .....	CTM4
4045 Engine .....	CTM8
Engine Accessories .....	CTM11

**TM1444 (24SEP90)**

LITHO IN U.S.A.

# Dealer Presentation Sheet

**IMPORTANT: Please remove this page and route through your service department.**

This is complete revision TM1444, 595D Excavator.

Listed below is a brief explanation of "WHAT" was changed and "WHY" it was changed.

This manual was revised:

1. To update Section I with added safety information and new specifications.
2. To correct art on Slow and Fast Idle Adjustment.
3. To update Travel Motor Displacement Control Valve Test and Adjustment in Group 9020-25.
4. To add Swing Bearing Wear Test.
5. To add Theory for Flow Sensing Valve.
6. To add Diagnose Steering Circuit Malfunctions to Group 9025-15.
7. To correct miscellaneous art and specifications.
8. To update miscellaneous procedures.

*Dealer Presentation Sheet*

# Contents

## **SECTION I—GENERAL INFORMATION**

- Group I —Safety Information
- Group II —General Specifications
- Group III —Torque Values
- Group IV —Fuels and Lubricants

## **SECTION 9005—OPERATIONAL CHECKOUT PROCEDURE**

- Group 10—Operational Checkout Procedure

## **SECTION 9010—ENGINE**

- Group 05—Theory of Operation
- Group 10—System Operational Checks
- Group 15—Diagnostic Information
- Group 20—Adjustments
- Group 25—Tests

## **SECTION 9015—ELECTRICAL SYSTEM**

- Group 00—Electrical System Operation And Test

## **SECTION 9020—POWER TRAIN**

- Group 05—Theory of Operation
- Group 10—System Operational Checks
- Group 15—Diagnostic Information
- Group 20—Adjustments
- Group 25—Tests

## **SECTION 9025—HYDRAULIC SYSTEM**

- Group 05—Theory Of Operation
- Group 10—System Operational Checks
- Group 15—Diagnostic Information
- Group 20—Adjustments
- Group 25—Tests

## **SECTION 9030—AIR SYSTEM**

- Group 05—Theory Of Operation
- Group 10—System Operational Checks
- Group 15—Diagnostic Information
- Group 20—Adjustments
- Group 25—Tests

## **SECTION 9031—HEATING AND AIR CONDITIONING**

- Group 05—Theory Of Operation
- Group 10—System Operational Checks
- Group 15—Diagnostic Information
- Group 20—Adjustments
- Group 25—Tests

*All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

TM1444-19-24SEP90

COPYRIGHT® 1990  
DEERE & COMPANY  
Moline, Illinois  
All rights reserved  
A John Deere ILLUSTRATION™ Manual  
Previous Editions  
Copyright® 1988 Deere & Company

*Contents*



Thank you very much  
for your reading.  
Please click here  
to get more information.