



60 Skid-Steer Loader



JOHN DEERE

TECHNICAL MANUAL

60 Skid-Steer Loader

TM1185 (01APR81) English



John Deere
Lawn & Grounds Care Division
TM1185 (01APR81)

LITHO IN U.S.A.
ENGLISH



60 SKID-STEER LOADER

Technical Manual
TM-1185 (Apr-81)

CONTENTS

SECTION 10 - GENERAL

- Group 05 - Specifications
- Group 10 - Lubrication and Periodic Service
Serial No. (-120,000)
- Group 12 - Lubrication and Periodic Service
Serial No. (120,001-)

SECTION 20 - ENGINE REPAIR Serial No. (-120,000)

- Group 05 - Specifications and Tools
- Group 10 - Engine Separation
- Group 15 - Cylinder Head, Breather and Valves
- Group 20 - Piston Assembly and Cylinder Bore
- Group 25 - Crankcase and Assemblies

SECTION 25 - ENGINE REPAIR Serial No. (120,001-)

- Group 05 - Specifications and Special Tools
- Group 10 - Engine Removal and Installation
- Group 15 - Internal Components

SECTION 30 - FUEL AND AIR REPAIR

- Group 05 - Specifications
- Group 10 - Carburetor - Serial No.
(-120,000)
- Group 12 - Carburetor - Serial No.
(120,001-)
- Group 15 - Governor - Serial No.
(120,001-)
- Group 20 - Fuel Tank - Serial No.
(120,001-)
- Group 25 - Fuel Pump and Fuel Filter
- Group 30 - Air Cleaner

SECTION 40 - ELECTRICAL REPAIR

- Group 05 - Specifications and Special Tools
- Group 10 - Cranking System - Serial No.
(-120,000)
- Group 12 - Cranking System - Serial No.
(120,001-)
- Group 15 - Ignition System - Serial No.
(-120,000)
- Group 17 - Ignition System - Serial No.
(120,001-)
- Group 20 - Charging System - Serial No.
(-120,000)

- Group 22 - Charging System - Serial No.
(120,001-)

- Group 25 - Neutral Start Switches

SECTION 50 - POWER TRAIN REPAIR

- Group 05 - Specifications and Special Tools
- Group 10 - Drive Clutch - Serial No.
(-120,000)
- Group 12 - Drive Clutch - Serial No.
(120,001-)
- Group 15 - Hydrostatic Pump
- Group 20 - Hydrostatic Motor
- Group 25 - Drive Components

SECTION 60 - STEERING AND BRAKE REPAIR

- Group 10 - Steering - Serial No.
(-120,000)
- Group 12 - Steering - Serial No.
(120,001-)
- Group 15 - Brakes

SECTION 70 - HYDRAULIC REPAIR

- Group 05 - Specifications and Special Tools
- Group 10 - Hydraulic Pump - Serial No.
(020,303)
- Group 15 - Hydraulic Pump - Serial No.
(020,304-)
- Group 20 - Hydraulic Cylinders
- Group 25 - Control Valves

SECTION 80 - OPERATOR'S STATION

- Group 10 - ROLL-GARD
- Group 15 - Floor Plate
- Group 20 - Seat and Heat Shield
- Group 25 - Pedal Assembly

SECTION 220 - ENGINE OPERATION AND TESTS - Serial No. (-120,000)

- Group 05 - Specifications and Special Tools
- Group 10 - System Operations
- Group 15 - Engine Analysis
- Group 20 - Diagnosing Malfunctions

(All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice).

Copyright© 1981
DEERE & COMPANY
Previous Editions
Copyright© 1977
DEERE & COMPANY

CONTENTS — Continued

SECTION 225 - ENGINE OPERATION AND TESTS - Serial No. (120,001-)

- Group 05 - Specifications and Special Tools
- Group 10 - System Operation
- Group 15 - Engine Analysis
- Group 20 - Diagnosing Malfunctions

SECTION 230 - FUEL SYSTEM OPERATION AND TESTS

- Group 05 - Specifications
- Group 10 - System Operation - Serial No. (-120,000)
- Group 12 - System Operation - Serial No. (120,001-)
- Group 15 - System Testing - Serial No. (-120,000)
- Group 17 - System Testing - Serial No. (120,001-)
- Group 20 - Diagnosing Malfunctions

SECTION 240 - ELECTRICAL OPERATION AND TESTS

- Group 05 - Specifications and Special Tools
- Group 10 - Wiring Diagrams
- Group 15 - Cranking System
- Group 20 - Ignition System
- Group 25 - Charging System

SECTION 250 - POWER TRAIN OPERATION AND TESTS

- Group 05 - Specifications and Special Tools
- Group 10 - System Operation
- Group 15 - System Testing
- Group 20 - Diagnosing Malfunctions

SECTION 270 - HYDRAULIC OPERATION AND TESTS

- Group 05 - Specifications and Special Tools
- Group 10 - System Operation
- Group 15 - System Testing
- Group 20 - Diagnosing Malfunctions

INTRODUCTION

This technical manual contains service and maintenance information for the John Deere 60 Skid-Steer Loader.

The manual is divided into sections. Each section pertains to a certain component or operational system of the loader. The information is divided into groups within each section.

All sections of this technical manual should be carefully studied by the service technician. Much basic information such as the principles of 4-cycle engine operation, carburetion and ignition have been omitted. Such information can be found in any good library and is recommended reading for the new service technician before consulting this manual for service procedures.

Emphasis is placed on diagnosing malfunctions, analysis and testing. Diagnosing malfunctions lists possible troubles, their causes and how to correct them. Under specific components these troubles are analyzed to help the service technician understand what is causing the problem so it can be corrected rather than just replace parts and have the same problem keep recurring.

Specifications are found at the beginning of each Section for easy reference.




This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

Metric equivalents have been included, where applicable, throughout this technical manual.

FOR YOUR CONVENIENCE

Vertical lines appear in the margins of many of the pages. These lines identify new material and revised information that affects specifications, procedures, and other important instructions.

INTRODUCTION



Use FOS Manuals for Reference



Use Technical Manuals for Actual Service

This technical manual is part of a twin concept of service:

- **FOS Manuals — for reference**
- **Technical Manuals — for actual service**

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced service technicians.

Technical Manuals are concise on-the-job service guides containing only the vital information needed for a specific machine.



When a service technician should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you — an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.

SI UNITS OF MEASURE

Because John Deere sells its products worldwide, U.S. units of measure are shown with their respective Metric equivalents throughout this technical manual. These equivalents are the SI (International System) Units of Measure.



Thank you very much
for your reading.
Please click here
to get more information.