
640D Skidder 648D Grapple Operation and Tests







Introduction

FOREWORD

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and diagnostics. Repair sections tell how to repair the components. Diagnostic sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Binders, binder labels, and tab sets can be ordered by John Deere dealers direct from the John Deere Distribution Service Center. This manual is part of a total product support program.

FOS MANUALS—REFERENCE

TECHNICAL MANUALS—MACHINE SERVICE

COMPONENT MANUALS—COMPONENT SERVICE

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand-alone manuals covering multiple machine applications.

JOHN DEERE DEALERS

IMPORTANT: Please remove this page and route through your service department.

This is a complete revision for TM1441, 640D Skidder and 648D Grapple Skidder.

To make miscellaneous additions and corrections.

TX,1441,DCL -19-06JUL90

Contents

SECTION I-GENERAL INFORMATION

Group I-Safety Information

Group II—General Specifications

Group III-Torque Values

Group IV-Fuels and Lubricants

SECTION 9005—OPERATIONAL CHECKOUT PROCEDURE

Group 10-Operational Checkout Procedure

SECTION 9010—ENGINE OPERATION AND TESTS

Group 05—Theory of Operation

Group 15-Diagnostic Information

Group 20—Adjustments

Group 25—Tests

SECTION 9015—ELECTRICAL OPERATION AND TESTS

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25—Tests

SECTION 9020—POWER TRAIN OPERATION AND TESTS

Group 05—Theory of Operation

Group 15-Diagnostic Information

Group 20—Adjustments

Group 25—Tests

SECTION 9025—HYDRAULIC SYSTEM OPERATION AND TESTS

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25-Tests

SECTION 9030—MISCELLANEOUS COMPONENTS (WINCH) OPERATION AND TEST

Group 05-Theory of Operation

Group 15-Diagnostic Information

Group 20-Adjustments

Group 25-Tests

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

TM1441-19-24JUL90

COPYRIGHT® 1990
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRUCTION™ Manual
Previous Editions
Copyright® 1988, 1984 Deere & Company



Thank you very much for your reading.

Please click here to get more information.