

# TM

## Technical Manual

### John Deere 670A and 672A Motor Grader Operation and Tests



TM-1188 (Dec-87)



LITHO IN U.S.A.

**REFERENCE COPY**



TO JOHN DEERE DEALERS

IMPORTANT: Please remove this page and route through your service department.

This is a complete revision for TM-1188, JD670-A and JD672-A Motor Graders Operation and Test.

Binders and tabs from old manual may be saved and used with this bound manual.

The new pages are dated (Dec-87). Listed below is a brief explanation of "WHAT" was changed and "WHY" it was changed.

This manual was revised:

To add Section I.

To update HFWO story showing different front sensor on later units.

To add information on hour meter.

To delete automatic Blade Control material. This material covered by manufacturer.



# JD670-A AND JD672-A MOTOR GRADERS

**Technical Manual  
 TM-1188 (Dec-87)**

## SECTION AND GROUP CONTENTS

|   | Page    |   | Page     |
|---|---------|---|----------|
| SECTION I - GENERAL INFORMATION   |         | GROUP 9020 - POWER TRAIN                            |          |
| GROUP I - Contents (not used)   |         | General Information . . . . .                       | 9020-6   |
| GROUP II - Introduction and Safety Information  |         | Diagnosing Malfunctions . . . . .                   | 9020-12  |
| GROUP III - General Specifications  |         | Visual Inspection . . . . .                         | 9020-13  |
| GROUP IV - Predelivery, Delivery and After-Sales Services (not used)                    |         | Testing and Adjustment . . . . .                    | 9020-14  |
| GROUP V - Lubrication   |         | GROUP 9025 - HYDRAULIC SYSTEM<br>(Flow Meter)       |          |
| SECTION 90 - SYSTEM TESTING   |         | General Information . . . . .                       | 9025-11  |
| GROUP 9005 - GENERAL INFORMATION - SEVEN BASIC STEPS OF DIAGNOSIS AND TESTING . . . . . | 9005-1  | Diagnosing Malfunctions . . . . .                   | 9025-45  |
| GROUP 9010 - ENGINE   |         | Visual Inspection . . . . .                         | 9025-49  |
| General Information . . . . .   | 9010-1  | Testing and Adjustment . . . . .                    | 9025-50  |
| Diagnosing Malfunctions . . . . .   | 9010-5  | GROUP 9025A - HYDRAULIC SYSTEM<br>(Analyzer)        |          |
| Visual Inspection . . . . .   | 9010-8  | General Information . . . . .                       | 9025A-1  |
| Testing and Adjustment . . . . .  | 9010-10 | Pretest Inspection and Operational Checks . . . . . | 9025A-3  |
| GROUP 9015 - ELECTRICAL SYSTEM  |         | Pretest Check Sheet . . . . .                       | 9025A-4  |
| General Information . . . . .   | 9015-1  | Symptom Index . . . . .                             | 9025A-5  |
| Visual Inspection . . . . .   | 9015-12 | Testing and Adjustment . . . . .                    | 9025A-9  |
| Diagnosing Malfunctions . . . . .   | 9015-13 | List of Parts for Tests . . . . .                   | 9025A-29 |
| Testing and Adjustment . . . . .  | 9015-28 |   |          |
| GROUP 9016 - HYDRAULIC FRONT WHEEL DRIVE  |         |   |          |
| General Information . . . . .   | 9016-5  |   |          |
| Pretest Information . . . . .   | 9016-27 |   |          |
| Testing and Adjustment . . . . .  | 9016-31 |   |          |

*Continued on page 2*

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

**Copyright© 1987  
 DEERE & COMPANY  
 Moline, Illinois  
 All Rights Reserved**

Previous Editions  
 Copyright© 1983 Deere & Company  
 Copyright© 1980 Deere & Company  
 Copyright© 1979 Deere & Company  
 Copyright© 1978 Deere & Company



Thank you very much  
for your reading.  
Please click here  
to get more information.