

**770B, 770BH, 772B
772BH MOTOR GRADERS**



JOHN DEERE

PARTS CATALOG

**770B, 770BH, 772B
772BH MOTOR GRADERS**

PC2064 (Mar-06)



Worldwide Construction and Forestry Division

Worldwide Edition


Litho in U.S.A (Revised)

1A2

770B, 770BH, 772B, 772BH MOTOR GRADERS

INTRODUCTION AND CUSTOMER INFORMATION

TP16311 -UN-01JAN94



*LEFT SIDE VIEW OF JOHN DEERE 770B MOTOR GRADER
(MANUFACTURED 1986-1997)*

TO THE CUSTOMER

THE PART NUMBERS IN THIS PARTS CATALOG WERE CORRECT AT THE TIME THIS CATALOG WAS PUBLISHED. IT IS OUR POLICY TO CONSTANTLY IMPROVE OUR MACHINES, AND THEREFORE, PART NUMBERS MAY CHANGE. WHEN ORDERING PARTS, VERIFY PART NUMBERS THROUGH YOUR DEALER'S MICROFICHE WHICH IS UP-TO-DATE.

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.)

1A3

770B, 770BH, 772B, 772BH MOTOR GRADERS

INTRODUCTION AND CUSTOMER INFORMATION

TP15159 -UN-01JAN94



*LEFT SIDE VIEW OF JOHN DEERE 772B MOTOR GRADER
(MANUFACTURED 1986-)*

TO THE CUSTOMER

THE PART NUMBERS IN THIS PARTS CATALOG WERE CORRECT AT THE TIME THIS CATALOG WAS PUBLISHED. IT IS OUR POLICY TO CONSTANTLY IMPROVE OUR MACHINES AND, THEREFORE, PART NUMBERS MAY CHANGE. WHEN ORDERING PARTS, VERIFY PART NUMBERS THROUGH YOUR DEALER'S MICROFICHE WHICH IS UP-TO-DATE.

(SPECIFICATIONS AND DESIGN SUBJECT TO CHANGE WITHOUT NOTICE.)

1A4

770B, 770BH, 772B, 772BH MOTOR GRADERS

SERIAL NUMBER LOCATION

EACH 770B AND 772B MOTOR GRADER MAY HAVE SIX SERIAL NUMBER PLATES. A BASIC GRADER SERIAL NUMBER PLATE, A PRODUCT IDENTIFICATION NUMBER PLATE, AN ENGINE SERIAL NUMBER PLATE, A TRANSMISSION SERIAL NUMBER PLATE, A HYDRAULIC PUMP SERIAL NUMBER PLATE AND A GEAR REDUCTION MOTOR SERIAL NUMBER PLATE.

THE BASIC GRADER SERIAL NUMBER PLATE IS LOCATED BELOW THE OPERATOR'S PLATFORM ON THE RIGHT-HAND SIDE OF THE MAIN FRAME. THIS IS THE SERIAL NUMBER USED IN THIS CATALOG UNLESS OTHERSIDE NOTED IN THE SERIAL NUMBER COLUMN.

THE PRODUCT IDENTIFICATION NUMBER PLATE IS LOCATED BELOW THE OPERATOR'S PLATFORM ON THE RIGHT-HAND SIDE OF THE MAIN FRAME. THIS IS THE SERIAL NUMBER USED IN THIS CATALOG UNLESS OTHERWISE NOTED IN THE SERIAL NUMBER COLUMN.

THE ENGINE SERIAL NUMBER PLATE IS LOCATED ON THE RIGHT-HAND SIDE OF THE ENGINE BEHIND THE ENGINE OIL FILTERS.

THE TRANSMISSION SERIAL NUMBER PLATE IS LOCATED ON THE LEFT-HAND SIDE OF THE CLUTCH HOUSING.

THE HYDRAULIC PUMP SERIAL NUMBER PLATE IS LOCATED ON THE UPPER RIGHT-HAND CORNER OF THE HYDRAULIC PUMP.

LEFT SIDE AND RIGHT SIDE, FRONT AND REAR OF THE MOTOR GRADER ARE VIEWED BY FACING IN THE DIRECTION OF MOTOR GRADER FORWARD TRAVEL.

WHENEVER SERIAL NUMBERS ARE REQUIRED ON ALL WARRANTY CLAIMS OR CORRESPONDENCE PERTAINING TO THIS PRODUCT, IT IS EXTREMELY IMPORTANT THAT ALL CHARACTERS BE FURNISHED. THIS POINT CANNOT BE OVEREMPHASIZED.



Thank you very much
for your reading.
Please click here
to get more information.