

GEHL

R260

R260 (EU)

R260 X-Series

Skid-Steer Loader

PDF  **DOWNLOAD**  **Parts manual**

GEHL R260 R260 (EU) R260 X-Series Skid-Steer Loader Parts Manual

Download Complete Parts Manual for GEHL R260 R260 (EU) R260 X-Series Skid-Steer Loader. This Factory Parts Manual offers all the Parts informations for GEHL R260 R260 (EU) R260 X-Series Skid-Steer Loader. The information on this manual covered everything you need to know when you want to GEHL R260 R260 (EU) R260 X-Series Skid-Steer Loader.

[Click Here Preview Online](#)

GEHL R260 R260 (EU) R260 X-Series Skid-Steer Loader

Form No. 50950172 Revision A 03/14

Parts Manual Covers:

SECTION A: MAIN LOADER COMPONENT

Chassis (includes HVAC, Heater-Only and Power-A-Tach)	21
1 Grille and Engine Cover.	21
ROPS/FOPS Structure/Interior (includes Non-HVAC, Heater-Only and HVAC)	25
Restraint Bar.	33
Seat and Seat Belt Options	35
Lift Arm	43
Attachment Bracket (includes Power-A-Tach)	
45 Wheel Drives	49
Engine.	51
Air Cleaner/Exhaust	57
Radiator/Cooler	61
Hydrostatic System with Drive Motors	63
Hydraulics Chassis (with Auxiliary Hydraulics and Hydraglide)	71
Hydraulics Lift Arm.	95
Controls Wheel Drives Lift/Tilt.	99
Controls Engine	111
Electrical Chassis (includes Hydraglide)	113
Electrical ROPS/FOPS.	119
Electrical Lights	125
Electrical Engine	127
Electrical Control	131
Electrical 14-Pin Auxiliary Connector.	133
Four-Point Lift	135
Sound Suppression	137
Brake Release	149
Tires	151
Decals	154

SECTION B: HYDRAULIC COMPONENTS and HVAC/HEATER HOUSINGS



Thank you very much
for your reading.
Please click here
to get more information.