John Deere Agriculture

5050E, 5055E, 5065E and 5075E Tractors

TECHNICAL MANUAL

5055E, 5065E, 5075E, 5050E



TM900319, July 2013



Table of contents

FOREWORD

Section 10 - GENERAL INFORMATION

- Group 05 Safety
- Group 10 General Specifications
- Group 20 Fuel and Lubricants
- Group 25 Serial Number Locations
- Group 30 Features and Accessories

Section 20 - ENGINE REPAIR

- Group 05 Engine
- Group 10 Cylinder Head and Valves
- Group 15 Cylinder Block, Liners, Pistons and Rods
- Group 20 Crankshaft, Main Bearings and Flywheel
- Group 25 Camshaft and Timing Gear Train
- Group 30 Lubrication System
- Group 35 Cooling System

Section 30 - FUEL AND AIR INTAKE SYSTEM REPAIR

- Group 05 Fuel System
- Group 10 Air Intake and Exhaust System
- Group 15 Speed Control Linkage

Section 40 - ELECTRICAL REPAIR

- Group 05 Battery, Starter and Alternator
- Group 10 Electrical System Components
- Group 15 Wiring Harness

Section 50 - POWER TRAIN REPAIR

- Group 05 Clutch Housing
- Group 10 Clutch Assembly
- Group 15 Transmission
- Group 20 Rear PTO Drive Shaft
- Group 25 Differential
- Group 30 Final Drives
- Group 35 Mechanical Front Wheel Drive If Equipped

Section 60 - STEERING AND BRAKE REPAIR

- Group 05 Steering Repair
- Group 10 Brake Repair

Section 70 - HYDRAULIC REPAIR

- Group 05 Hydraulic Pump and Filter
- Group 10 JD Rockshaft
- Group 15 Selective Control Valve (SCV)

Section 80 - MISCELLANEOUS REPAIR

- Group 05 Front Axle
- Group 10 Wheels
- Group 15 3-Point Hitch
- Group 20 Hood
- Group 25 Ballast

Section 90 - OPERATOR STATION REPAIR

- Group 05 Seat and Support
- Group 06 Right Console
- Group 10 Roll-GardRoll-Gard is a trademark of Deere & Company.
- Group 15 Center Console

- Group 20 Operator Station
- Group 25 Fenders

Section 210 - OPERATIONAL CHECKOUT PROCEDURES

Group 10 - Operational Checkout Procedures

Section 220 - ENGINE OPERATION, TESTS AND ADJUSTMENTS

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis, Tests and Adjustments

Section 230 - FUEL/AIR OPERATION, TESTS AND ADJUSTMENTS

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis, Tests and Adjustments

Section 240 - ELECTRICAL SYSTEM OPERATION, TESTS AND ADJUSTMENTS

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis, Tests and Adjustments
- Group 20 Wiring Schematics
- Group 25 Component Information—Connectors

Section 250 - POWER TRAIN OPERATION, TESTS AND ADJUSTMENTS

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis, Tests and Adjustments

Section 260 - STEERING AND BRAKE OPERATION, TESTS & ADJUSTMENTS

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis, Tests and Adjustments

Section 270 - HYDRAULIC SYSTEM OPERATION, TESTS AND ADJUSTMENTS

- Group 05 Component Location
- Group 10 Theory of Operation
- Group 15 Diagnosis
- Group 20 Hydraulic Tests—With SCV
- Group 25 Hydraulic Tests—With Mid-Mount Control Valve
- Group 30 Hydraulic Tests—Whole System
- Group 40 Adjustments—Hitch
- Group 45 Hydraulic Schematics





Thank you very much for your reading.

Please click here to get more information.