

SG-50 STUMP GRINDER

(S/N 702100101 & Above)

Operation & Maintenance Manual **DOWNLOAD**



Doosan purchased Bobcat Company from Ingersoll-Rand Company in 2007. Any reference to Ingersoll-Rand Company or use of trademarks, service marks, logos, or other proprietary identifying marks belonging to Ingersoll-Rand Company in this manual is historical or nominative in nature, and is not meant to suggest a current affiliation between Ingersoll-Rand Company and Bobcat Company or the products of either.



CONTENTS

iii vii 1
RMATION
cat Stump Grinder in the spaces erring to your Bobcat Stump

Bobcat P.O. Box 128 Gwinner, ND 58040–0128

Bobcat Europe J. Huysmanslaan 59 B-1651 LOT Belgium **FOREWORD**

SAFETY

OPERATING INSTRUCTIONS

MAINTENANCE

SPECIFICATIONS





Bobcat is ISO 9001 certified

ISO 9001 is a set of international standards that control the processes and procedures which we use to design, develop, manufacture, distribute, and service Bobcat products.

British Standards Institute (BSI) is the Certified Registrar Bobcat chose to assess the Company's compliance with the ISO 9001 set of standards. The BSI registration certifies that the two Bobcat manufacturing plants and the Bobcat corporate offices (Gwinner, Bismarck & Fargo) in North Dakota are in compliance with ISO 9001. Only certified assessors, like BSI, can grant registrations. Since registration requires this third-party auditing, it is irrefutable evidence of conformance. Continued certification is subject to periodic audits.

ISO 9001 means that as a company we say what we do and do what we say. In other words, we have established procedures and policies, and we provide evidence that the procedures and policies are followed.

What does ISO 9001 mean to Bobcat Customers? It means that Bobcat produces your Bobcat loader , Excavator, and attachments with strict attention to details, using the latest technology and proven techniques.

FOREWORD

FOREWORD

This Operation & Maintenance Manual was written to give the owner/operator instructions on the safe operation and maintenance of the Stump Grinder. READ AND UNDERSTAND THIS OPERATION & MAINTENANCE MANUAL BEFORE OPERATING YOUR STUMP GRINDER. If you have any questions, see your Bobcat loader dealer.

SERIAL NUMBER LOCATIONv	
ATTACHMENT DELIVERY REPORT	
SG-50 STUMP GRINDER IDENTIFICATIONvi	



Thank you very much for your reading.

Please click here to get more information.