

463




Bobcat®

Parts Manual

S/N 5222 11001 & Above
S/N 5221 11001 & Above



DOWNLOAD



**EQUIPPED WITH
BOBCAT INTERLOCK
CONTROL SYSTEM (BICS™)**

6902178 (9-02)



Printed in U.S.A.

© Bobcat Company 2002

463AF ALPHABETICAL INDEX

AIR CLEANER	136	PUMP, INJECTION	118
ALTERNATOR	82	PUMP, WATER	130
ANTI-FREEZE	222	RADIATOR	84
AXLE	32	RENTAL KIT	200
BATTERY	74	RIMS	216
BELT, ALT	90	RING GEAR	88
BELT, DRIVE	88	ROCKER ARM COVER	96
BICS CONTROL VALVE	48	SEAT BELT	202
BLACK GOLD	222	SEAT	212, 214
BLOCK HEATER	144	SIDE INSTR PANEL KIT	204
BOB-TACH	22	SOLENOID	74
BOOT, RUBBER	28	SOUND OPTION	184
BRAKE, CALIPER	170	STARTER	80
BRAKE	34	STROBE LIGHT	210
CAB ENCLOSURE	152	SWITCH, ENG. OIL PRESS	74, 102
CAB	14	SWITCH, HYDRO. PRESS	74
CABLE, BATTERY	74	SWITCH, HYDRO. TEMP	74
CAMSHAFT	106	TANK, FUEL	24
CAP, FUEL	24	THERMOSTAT	128
CAP, HYD. OIL	54	THROTTLE	92
CAP, RADIATOR,	84	TIRES	216
CHAIN, DRIVE	30	TOW VALVE KIT	218
CHAINCASE	12	VALVE, ENGINE	100
CONTROLS HAND	60	VALVE, HYD.	44
CRANKCASE	102	WEIGHT	12
CRANKSHAFT	110	WINDOW, REAR	160
CYLINDER HEAD	98	WINDOW, SIDE	160
CYLINDER, LIFT	40		
CYLINDER, TILT	42		
DECAL KIT	162, 164		
DIPSTICK, ENGINE	132		
DOOR, CAB	152		
DOOR, REAR	26		
ENGINE	94		
EXT RMVL R WIN KIT	186		
FILTER AIR	136		
FILTER, ENG. OIL	90, 104		
FILTER, FUEL	24		
FILTER, HYD. OIL	54		
FIRE EXTINGUISHER	188		
FLYWHEEL	88		
FUEL SYSTEM	24		
GAUGE	24		
GEARCASE	104		
GLOW PLUGS	124		
GOVERNOR	120		
HARNESS CAB	72		
HARNESS, ENGINE	74		
HARNESS, LIGHTS	194		
LEVER, PINTLE	60		
LEVER, STEERING	60		
LIFT ARM	20		
LIFT, SINGLE POINT	206		
MAIN FRAME	12		
MANIFOLDS	134		
MOTOR, HYDRO	70		
MOUNT, ENGINE	90		
MUFFLER	86		
NOZZLE, INJECTOR	126		
OIL COOLER	54		
OIL PAN	132		
OIL	222		
PAINT	222		
PINTLE LEVER	60		
PISTON	110		
PUMP, FUEL	116		
PUMP, GEAR	68		
PUMP, HYDROSTATIC	62, 64, 66		



Thank you very much
for your reading.
Please click here
to get more information.