



PDF



DOWNLOAD





**HONDA**

**HONDA**



**CB600F<sub>w</sub>**

# HOW TO USE THIS MANUAL

This service manual describes the service procedures for the CB600F.

Follow the Maintenance Schedule (Section 3) recommendations to ensure that the vehicle is in peak operating condition.

Performing the first scheduled maintenance is very important. It compensates for the initial wear that occurs during the break-in period.

Sections 1 and 3 apply to the whole motorcycle. Section 2 illustrates procedures for removal/installation of components that may be required to perform service described in the following sections. Sections 4 through 19 describe parts of the motorcycle, grouped according to location.

Find the section you want on this page, then turn to the table of contents on the first page of the section.

Most sections start with an assembly or system illustration, service information and troubleshooting for the section.

The subsequent pages give detailed procedure.

If you don't know the source of the trouble, go to section 21 Troubleshooting.


ALL INFORMATION, ILLUSTRATIONS, DIRECTIONS AND SPECIFICATIONS INCLUDED IN THIS PUBLICATION ARE BASED ON THE LATEST PRODUCT INFORMATION AVAILABLE AT THE TIME OF APPROVAL FOR PRINTING. HONDA MOTOR CO., LTD. RESERVES THE RIGHT TO MAKE CHANGES AT ANY TIME WITHOUT NOTICE AND WITHOUT INCURRING ANY OBLIGATION WHATEVER. NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT WRITTEN PERMISSION. THIS MANUAL IS WRITTEN FOR PERSONS WHO HAVE ACQUIRED BASIC KNOWLEDGE OF MAINTENANCE ON HONDA MOTORCYCLES, MOTOR SCOOTERS OR ATVS.

HONDA MOTOR CO., LTD.  
SERVICE PUBLICATION OFFICE

# CONTENTS

	GENERAL INFORMATION
	FRAME/BODY PANELS/EXHAUST SYSTEM
	MAINTENANCE
ENGINE AND DRIVE TRAIN	LUBRICATION SYSTEM
	FUEL SYSTEM
	COOLING SYSTEM
	ENGINE REMOVAL/INSTALLATION
	CYLINDER HEAD/VALVES
	CLUTCH/GEARSHIFT LINKAGE
	ALTERNATOR/STARTER CLUTCH
	CRANKCASE/PISTON/CYLINDER
CHASSIS	CRANKSHAFT/TRANSMISSION
	FRONT WHEEL/SUSPENSION/STEERING
	REAR WHEEL/SUSPENSION
ELECTRICAL	HYDRAULIC BRAKE
	BATTERY/CHARGING SYSTEM
	IGNITION SYSTEM
	ELECTRIC STARTER
	LIGHTS/METERS/SWITCHES
	WIRING DIAGRAMS
	TROUBLESHOOTING







Thank you very much  
for your reading.  
Please click here  
to get more information.