



# Bobcat®



EN

---

## Operation & Maintenance Manual Flail Mower

---

**(30FM) S/N B1YS00400 & Above**  
**(40FM) S/N B1YT00400 & Above**





# OPERATOR SAFETY WARNINGS




## WARNING

Operator must have instructions before operating the machine. Untrained operators can cause injury or death.


W-2001-0502




**Safety Alert Symbol:** This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




⚠ Never use the flail mower without instructions. See machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.




⚠ Fasten seat belt securely.  
⚠ Operate controls only from operator's seat.




⚠ Never operate without approved cab.  
⚠ Always lower front window and close door before operating flail mower.



⚠ Keep bystanders away when operating flail mower.  
⚠ Never modify equipment.



⚠ Avoid steep areas or banks that could break away.



⚠ Do not put hands, feet, or objects under flail mower when engine is running.  
⚠ To leave excavator, lower the work equipment and the blade to the ground. Stop the engine.

## SAFETY EQUIPMENT

The excavator must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

1. **SEAT BELT:** Check belt fasteners and check for damaged webbing or buckle.
2. **OPERATOR CAB (ROPS and TOPS):** Check condition and mounting hardware.
3. **OPERATOR'S HANDBOOK:** Must be in the cab / canopy.
4. **LEFT HAND CONSOLE:** When raised must deactivate the travel and hydraulic functions.
5. **SAFETY SIGNS (DECALS):** Replace if damaged.
6. **GRAB HANDLES:** Replace if damaged.
7. **INTEGRATED SLEW LOCK BRAKE.**
8. **SAFETY TREAD.:** Replace if damaged.

OSW80-0314



**Bobcat®**

# CONTENTS

FOREWORD .....	5
SAFETY AND TRAINING RESOURCES .....	15
OPERATING INSTRUCTIONS .....	25
PREVENTIVE MAINTENANCE .....	57
SPECIFICATIONS .....	67
WARRANTY .....	71
ALPHABETICAL INDEX .....	75

## REFERENCE INFORMATION

Write the correct information for YOUR Bobcat attachment in the spaces below. Always use these numbers when referring to your Bobcat attachment.

Attachment Serial Number \_\_\_\_\_

NOTES:

---

---

---

---

---

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:

---



Bobcat Company  
P.O. Box 128  
Gwinner, ND 58040-0128  
UNITED STATES OF AMERICA

Doosan Benelux SA  
Drève Richelle 167  
B-1410 Waterloo  
BELGIUM



Thank you very much  
for your reading.  
Please click here  
to get more information.