





Bobcat®

Operation & Maintenance Manual Flail Mower

(30FM) S/N B1YS00101 & Above
(40FM) S/N B1YT00101 & Above
(40FMR) S/N B1YU00101 & Above



OPERATOR SAFETY WARNINGS




WARNING

Operator must have instructions before operating the machine. Untrained operators can cause injury or death.


W-2001-0502




Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




! Never use the flail mower without instructions. See machine signs (decals), Operation & Maintenance Manual, and Operator's Handbook.




! Fasten seat belt securely.
! Operate controls only from operator's seat.




! Never operate without approved cab.
! Always lower front window and close door before operating flail mower.



! Keep bystanders away when operating flail mower.
! Never modify equipment.



! Avoid steep areas or banks that could break away.



! Do not put hands, feet, or objects under flail mower when engine is running.
! To leave excavator, lower the work equipment and the blade to the ground. Stop the engine.

SAFETY EQUIPMENT

The excavator must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

1. SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
2. OPERATOR CAB (ROPS and TOPS): Check condition and mounting hardware.
3. OPERATOR'S HANDBOOK: Must be in the cab / canopy.
4. LEFT HAND CONSOLE: When raised must deactivate the travel and hydraulic functions.
5. SAFETY SIGNS (DECALS): Replace if damaged.
6. GRAB HANDLES: Replace if damaged.
7. INTEGRATED SLEW LOCK BRAKE.
8. SAFETY TREAD.: Replace if damaged.



Bobcat®

CONTENTS

FOREWORD	3
SAFETY AND TRAINING RESOURCES	11
OPERATING INSTRUCTIONS	19
PREVENTIVE MAINTENANCE	47
MACHINE SIGN TRANSLATIONS	57
SPECIFICATIONS	63
WARRANTY	67
ALPHABETICAL INDEX	71

REFERENCE INFORMATION

Write the correct information for YOUR Bobcat attachment in the spaces below. Always use these numbers when referring to your Bobcat attachment.

Attachment Serial Number _____

NOTES:

YOUR BOBCAT DEALER:

ADDRESS:

PHONE:

Bobcat Company
P.O. Box 128
Gwinner, ND 58040-0128
UNITED STATES OF AMERICA

Doosan Benelux SA
Drève Richelle 167
B-1410 Waterloo
BELGIUM



Thank you very much
for your reading.
Please click here
to get more information.