



Operation & Maintenance Manual Forestry Cutter

(FRST CTTR FRC50) S/N ADTN00101 & Above (FRST CTTR FRC50) S/N ANR600101 & Above (FRST CTTR FRC50 2SPD) S/N ATSY00101 & Above (Forestry Cutter) S/N A6ZB00101 & Above (FRST CTTR FRC60) S/N ANR500101 & Above (FRST CTTR FRC60 2SPD) S/N ATV100101 & Above (FRST CTTR FRC70 2SPD) S/N B48D00101 & Above





OPERATOR SAFETY WARNINGS




Operator must have instructions before operating the machine. Untrained operators can cause injury or death.


W-2001-0502




Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




Never use the forestry cutter without instructions. See machine signs (decals), Operation & Maintenance Manual. Operator's Handbook and Maintenance Training Video.



When servicing the forestry cutter always fully lower the lift arms, place the forestry cutter flat on the ground, engage the parking brake and stop the engine.




Always use the seat bar and fasten seat belt snugly. Always keep feet on the pedals when operating loader.




Always check work area before operating forestry cutter.

Never use loader without operator cab with ROPS and FOPS approval. Fasten your seat



Do Not operate forestry cutter without a Level II FOPS kit installed on the cab of the loader. Do Not operate without forestry

door installed.




Flammable debris, can cause a fire hazard. Inspect the loader and forestry cutter and clean as necessary to avoid debris accumulation.




Keep bystanders away when operating forestry cutter.

Never allow riders on forestry cutter.



Always carry attachment as low as possible.

Do not travel or turn with lift arms



Do not put hands, feet, or objects under forestry cutter when engine is running.

To park, engage parking brake and put attachment flat on the ground and stop engine.

SAFETY EQUIPMENT

The Bobcat Loader and Forestry Cutter Attachment must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

- 1. SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
- SEAT BAR: When up, it must lock the loader controls.

 OPERATOR CAB (ROPS and FOPS): Must have Level II FOPS kit for use with Forestry Cutter
- MACHINE AND ATTACHMENT SAFETY SIGNS (DECALS): Replace if damaged.
- 6. FORESTRY APPLICATIONS KIT: Required for additional operator and machine protection
- 8. PARKING BRAKE:
- GRAB HANDLES & SAFETY TREADS: Replace if damaged. 9.
- **DEBRIS CHAINS: Replace if damaged.**
- 11. FORESTRY CUTTER HYDRAULIC BRAKE: Check for proper function.

attachment. Keep all fasteners tight.
OPERATOR'S HANDBOOK: Must be in the cab.

when using the Forestry Cutter attachment. Available from your dealer.
7. FORESTRY DOOR: Check for proper function of Interlock and Emergency Exit.

OSW54-0409



CONTENTS

Bobcat Company	Doosan Benelux SA
PHONE:	
ADDRESS:	
YOUR BOBCAT DEALER:	
NOTES:	
_	
Forestry Cutter Serial Number _	
Write the correct information for Y referring to your Bobcat forestry	YOUR Bobcat forestry cutter in the spaces below. Always use these numbers when cutter.
REFERENCE INFORMATION	
ALPHABETICAL INDEX	
WARRANTY	99
SPECIFICATIONS	89
MACHINE SIGN TRANSLA	ATIONS81
PREVENTIVE MAINTENA	NCE71
OPERATING INSTRUCTION	NS
SAFETY & TRAINING RES	SOURCES15
FOREWORD	5

Bobcat Company P.O. Box 128 Gwinner, ND 58040-0128 UNITED STATES OF AMERICA Doosan Benelux SA Drève Richelle 167 B-1410 Waterloo BELGIUM



Thank you very much for your reading.

Please click here to get more information.