




Operation & Maintenance Manual Forestry Cutter

(FRC150HT) S/N B4A800101 & Above (FRC200HT) S/N B48J00101 & Above





OPERATOR SAFETY WARNINGS




Operator must have instructions before operating the machine. Untrained operators can cause injury or death.


W-2001-0502




Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.




Never use the forestry cutter without instructions. See machine signs (decals), Operation & Maintenance Manual Handbook Operator's and Maintenance Training Video.




Always check work area before operáting forestry cutter. loader use without operator cab with ROPS and FOPS approval. Fasten your seat




Keep bystanders away when operating forestry cutter. Never allow riders on forestry cutter.



When servicing the forestry cutter always fully lower the lift When arms, place the forestry cutter flat on the ground, engage the parking brake and stop engine.




Do Not operate forestry cutter without a Level II FOPS kit installed on the cab of the loader. Do Not operate without forestry door installed.




Always carry attachment as low as possible.


Do not travel or turn with lift arms



Always use the seat bar and fasten seat belt snugly. Always keep feet on the pedals when operating loader.



Flammable debris, can cause a fire hazard. Inspect the loader and forestry cutter and clean as necessary to avoid debris accumulation.



put hands. Dα not feet. or objects under forestry cutter when engine is running.

To park, engage parking brake and put attachment flat on the ground and stop engine.

SAFETY EQUIPMENT

The Bobcat Loader and Forestry Cutter Attachment must be equipped with safety items necessary for each job. Ask your dealer about attachments and accessories.

- SEAT BELT: Check belt fasteners and check for damaged webbing or buckle.
- SEAT BAR: When up, it must lock the loader controls.

 OPERATOR CAB (ROPS and FOPS): Must have Level II FOPS kit for use with Forestry Cutter attachment. Keep all fasteners tight.
- OPERATOR'S HANDBOOK: Must be in the cab.
 MACHINE AND ATTACHMENT SAFETY SIGNS (DECALS): Replace if damaged.
- FORESTRY APPLICATIONS KIT: Required for additional operator and machine protection when using the Forestry Cutter attachment. Available from your dealer.
- FORESTRY DOOR: Check for proper function of Interlock and Emergency Exit.
- **PARKING BRAKE:**
- GRAB HANDLES & SAFETY TREADS: Replace if damaged.
- 10. DEBRIS CHAINS: Replace if damaged.
- 11. FORESTRY CUTTER HYDRAULIC BRAKE: Check for proper function.

OSW54-0409



CONTENTS

FOREWORD
SAFETY AND TRAINING RESOURCES
OPERATING INSTRUCTIONS
PREVENTIVE MAINTENANCE
SPECIFICATIONS
WARRANTY
ALPHABETICAL INDEX
REFERENCE INFORMATION
Write the correct information for YOUR Bobcat loader in the spaces below. Always use these numbers when referring to your Bobcat loader.
Loader Serial Number
Engine Serial Number
NOTES:
YOUR BOBCAT DEALER:
ADDRESS:
PHONE:

CE

Bobcat Company P.O. Box 128 Gwinner, ND 58040-0128 UNITED STATES OF AMERICA Doosan Bobcat Manufacturing s.r.o. U Kodetky 1978 26312 Dobris CZECH REPUBLIC



Thank you very much for your reading.

Please click here to get more information.